

NOTE

This manual documents the Model 2180A and its assemblies at the revision levels shown in Appendix 7A. If your instrument contains assemblies with different revision letters, it will be necessary for you to either update or backdate this manual. Refer to the supplemental change/errata sheet for newer assemblies, or the backdating sheet in Appendix 7A for older assemblies.

2180A

Digital Thermometer

Instruction Manual

P/N 489211
June 1978
Rev. 1 6/79



WARRANTY

Notwithstanding any provision of any agreement the following warranty is exclusive:

The JOHN FLUKE MFG. CO., INC., warrants each instrument it manufactures to be free from defects in material and workmanship under normal use and service for the period of 1-year from date of purchase. This warranty extends only to the original purchaser. This warranty shall not apply to fuses, disposable batteries (rechargeable type batteries are warranted for 90-days), or any product or parts which have been subject to misuse, neglect, accident, or abnormal conditions of operations.

In the event of failure of a product covered by this warranty, John Fluke Mfg. Co., Inc., will repair and calibrate an instrument returned to an authorized Service Facility within 1 year of the original purchase; provided the warrantor's examination discloses to its satisfaction that the product was defective. The warrantor may, at its option, replace the product in lieu of repair. With regard to any instrument returned within 1 year of the original purchase, said repairs or replacement will be made without charge. If the failure has been caused by misuse, neglect, accident, or abnormal conditions of operations, repairs will be billed at a nominal cost. In such case, an estimate will be submitted before work is started, if requested.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS, OR ADEQUACY FOR ANY PARTICULAR PURPOSE OR USE. JOHN FLUKE MFG. CO., INC., SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT, TORT, OR OTHERWISE.

If any failure occurs, the following steps should be taken:

1. Notify the JOHN FLUKE MFG. CO., INC., or nearest Service facility, giving full details of the difficulty, and include the model number, type number, and serial number. On receipt of this information, service data, or shipping instructions will be forwarded to you.
2. On receipt of the shipping instructions, forward the instrument, transportation prepaid. Repairs will be made at the Service Facility and the instrument returned, transportation prepaid.

SHIPPING TO MANUFACTURER FOR REPAIR OR ADJUSTMENT

All shipments of JOHN FLUKE MFG. CO., INC., instruments should be made via United Parcel Service or "Best Way" prepaid. The instrument should be shipped in the original packing carton; or if it is not available, use any suitable container that is rigid and of adequate size. If a substitute container is used, the instrument should be wrapped in paper and surrounded with at least four inches of excelsior or similar shock-absorbing material.

CLAIM FOR DAMAGE IN SHIPMENT TO ORIGINAL PURCHASER

The instrument should be thoroughly inspected immediately upon original delivery to purchaser. All material in the container should be checked against the enclosed packing list. The manufacturer will not be responsible for shortages against the packing sheet unless notified immediately. If the instrument is damaged in any way, a claim should be filed with the carrier immediately. (To obtain a quotation to repair shipment damage, contact the nearest Fluke Technical Center.) Final claim and negotiations with the carrier must be completed by the customer.

The JOHN FLUKE MFG. CO., INC., will be happy to answer all applications or use questions, which will enhance your use of this instrument. Please address your requests or correspondence to: JOHN FLUKE MFG. CO., INC., P.O. BOX C9090, EVERETT, WASHINGTON 98206, ATTN: Sales Dept. For European Customers: Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands.

*For European customers, Air Freight prepaid.

John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, Washington 98206

Section 1

Introduction & Specifications

1-1. INTRODUCTION

1-2. The Model 2180A Digital Thermometer is a portable, five digit RTD thermometer. Temperature measurements are possible, depending on RTD type employed, over a range of -219°C to $+664^{\circ}\text{C}$ (-394°F to $+1435^{\circ}\text{F}$) with 0.1° or $.01^{\circ}$ resolution. The instrument features:

1. Front Panel switch selection of Fahrenheit or Celsius readings.
2. Switch selectable RTD inputs.
3. Switch selectable input line voltage.
4. Dual slope measurement techniques.
5. Digital linearization of the RTD inputs.

1-3. DESCRIPTION

1-4. The instrument display features seven, high-intensity, seven segment LEDs, and leading zero suppression. Six of the LEDs are used to display numeric data, with a minus sign for negative temperature readings. The remaining LED displays the selected temperature scale character ($^{\circ}\text{F}$ or $^{\circ}\text{C}$).

1-5. A four connection, screw-type terminal block is provided on the removable Input PCB for RTD connections. Input switch settings on this module will determine the microcomputer program necessary to linearize the desired RTD's input. A precision, four-wire resistance measurement of the RTD is routed through this module to the thermometer's input circuitry.

1-6. Selection of the temperature scale for display is made with a front panel pushbutton. The scale selected, Celsius or Fahrenheit, is displayed as the last character in the temperature reading ($^{\circ}\text{C}$ or $^{\circ}\text{F}$). A scale change can be made at any time, and has no effect on calibration of the instrument.

1-7. Options and accessories available for the 2180A are listed in Table 1-1. More information concerning these items is given in Section 6 of this manual, Option and Accessory Information.

1-8. The measurement range of the 2180A Digital Thermometer is determined by the type of RTD used as the input device. RTD Types and total instrument accuracy specifications are listed in Table 1-2. Linearization of the RTD input is accomplished through toggling of the input switch segments on the RTD Input Module. Switch positions, numbers and applications are printed on the removable module beside the switch.

1-9. Four input line voltages are available for switch selection. Selection may be made for 100, 120, 220 or 240 volts $\pm 10\%$ as required to meet local conditions. Frequency may vary between 50 and 440 Hertz for all voltage selections. Refer to Section 4 of this manual when changing the selected input line voltage.

1-10. SPECIFICATIONS

1-11. Specifications for the 2180A Digital Thermometer are given in Table 1-3.

Table 1-1. 2180A Options and Accessories

| DESIGNATION | DESCRIPTION |
|-------------|--|
| 21X0A-002 | Output Option |
| 21X0A-006 | Limits Option |
| Y2000 | Multipoint Selector, RTD |
| Y2002 | Alarms Output |
| Y2009 | Battery Pack, 12V Rechargeable |
| Y2010 | Rack Panel PTI, single, A size (for Y2000) |
| Y2011 | Rack Panel PTI, double, A size (for Y2000) |
| Y2012 | Rack Panel PTI, single, B size (for Y2009) |
| Y2013 | Rack Panel PTI, double, B size (for Y2009) |
| Y2014 | Rack Panel PTI, single, C size (for 2180A and Y2002) |
| Y2015 | Rack Panel PTI, double, C size (for 2180A and Y2002) |
| Y2018 | Panel Mount PTI-DIN, A size (for Y2000) |
| Y2019 | Panel Mount PTI-DIN, B size (for Y2009) |
| Y2020 | Panel Mount PTI-DIN, C size (for 2180A and Y2002) |
| Y2022 | Divider, Thermometer Calibration |
| Y2023 | Accessory Case |
| Y2024 | 3-Module Power Cord |
| Y2025 | Probe, RTD, 100 Ω , 385 Pf |
| Y2026 | Cable, Output Unit, RS-232-C |

Table 1-2. RTD Total Instrument Accuracy Specifications

| RTD TYPE | RESOLUTION | APPLICABLE PORTION OF TEMPERATURE RANGE | | MAXIMUM ERROR* | | | | | |
|-------------------------|----------------|---|--------------|-----------------|---|--|-----------------|---|--|
| | | | | \pm DEGREES C | | | \pm DEGREES F | | |
| | | $^{\circ}$ C | $^{\circ}$ F | AT CAL | 90 DAYS 20 $^{\circ}$ to 30 $^{\circ}$ | 1 YEAR 15 $^{\circ}$ to 35 $^{\circ}$ | AT CAL | 90 DAYS 68 $^{\circ}$ to 86 $^{\circ}$ | 1 YEAR 59 $^{\circ}$ to 95 $^{\circ}$ |
| 100 Ω 385 Pt | .01 $^{\circ}$ | -220 to 0 | -364 to 32 | .160 | .204 | .229 | .288 | .367 | .412 |
| | | 0 to 204 | 32 to 399.2 | .052 | .093 | .119 | .094 | .167 | .214 |
| | .1 $^{\circ}$ | -220 to 0 | -364 to 32 | .280 | .300 | .320 | .600 | .540 | .680 |
| | | 0 to 779 | 32 to 1434.2 | .400 | .509 | .557 | .720 | .920 | 1.000 |
| 100 Ω 390 Pt | .01 $^{\circ}$ | -229 to 0 | -380.2 to 32 | 0.095 | 0.141 | 0.166 | 0.155 | 0.235 | 0.281 |
| | | 0 to 204 | 32 to 399.2 | 0.095 | 0.136 | 0.162 | 0.155 | 0.239 | 0.285 |
| | .1 $^{\circ}$ | -229 to 0 | -380.2 to 32 | 0.140 | 0.161 | 0.181 | 0.200 | 0.249 | 0.290 |
| | | 0 to 773 | 32 to 1423.4 | 0.140 | 0.247 | 0.296 | 0.200 | 0.429 | 0.521 |
| 100 Ω 3902 Pt | .01 $^{\circ}$ | -218 to 0 | -360.4 to 32 | 0.020 | 0.064 | 0.089 | 0.035 | 0.112 | 0.158 |
| | | 0 to 204 | 32 to 399.2 | 0.020 | 0.061 | 0.087 | 0.035 | 0.119 | 0.165 |
| | .1 $^{\circ}$ | -218 to 0 | -360.4 to 32 | 0.140 | 0.160 | 0.180 | 0.200 | 0.246 | 0.287 |
| | | 0 to 771 | 32 to 1419.8 | 0.140 | 0.247 | 0.295 | 0.200 | 0.429 | 0.520 |

Table 1-2. RTD Total Instrument Accuracy Specifications (cont)

| RTD TYPE | RESOLUTION | APPLICABLE PORTION OF TEMPERATURE RANGE | | MAXIMUM ERROR* | | | | | |
|-----------------|------------|---|--------------|----------------|-----------------------|----------------------|------------|-----------------------|----------------------|
| | | | | ± DEGREES C | | | ±DEGREES F | | |
| | | °C | °F | AT CAL | 90 DAYS 20° to 30° | 1 YEAR 15° to 35° | AT CAL | 90 DAYS 68° to 86° | 1 YEAR 59° to 95° |
| 100Ω 392 Pt | .01° | -237 to 0 | -394.6 to 32 | 0.080 | 0.127 | 0.153 | 0.140 | 0.223 | 0.269 |
| | | 0 to 204 | 32 to 399.2 | 0.080 | 0.121 | 0.147 | 0.140 | 0.224 | 0.270 |
| | .1° | -237 to 0 | -394.6 to 32 | 0.140 | 0.162 | 0.182 | 0.200 | 0.251 | 0.292 |
| | | 0 to 767 | 32 to 1412.6 | 0.140 | 0.246 | 0.294 | 0.200 | 0.427 | 0.518 |
| 100Ω 617 Ni | .01° | -60 to 0 | -76 to 32 | 0.095 | 0.118 | 0.142 | 0.155 | 0.198 | 0.242 |
| | | 0 to 93 | 32 to 199.4 | 0.095 | 0.121 | 0.145 | 0.155 | 0.209 | 0.253 |
| | .1° | -60 to 0 | -76 to 32 | 0.140 | 0.147 | 0.162 | 0.200 | 0.219 | 0.255 |
| | | 0 to 177 | 32 to 350.6 | 0.140 | 0.155 | 0.173 | 0.200 | 0.245 | 0.285 |
| 120Ω 6721 Ni | .01° | -57 to 0 | -70.6 to 32 | 0.095 | 0.118 | 0.142 | 0.155 | 0.197 | 0.242 |
| | | 0 to 177 | 32 to 350.6 | 0.095 | 0.121 | 0.145 | 0.155 | 0.209 | 0.253 |
| | .1° | -57 to 0 | -70.6 to 32 | 0.140 | 0.147 | 0.162 | 0.200 | 0.219 | 0.254 |
| | | 0 to 177 | 32 to 350.6 | 0.140 | 0.155 | 0.173 | 0.200 | 0.245 | 0.285 |

* Maximum error depends on the temperature measured and the resolution used. Of the four temperature ranges presented for each RTD, the first two represent .01° resolution.

Table 1-3. General Specifications

| | |
|---|--|
| DIMENSIONS 10.49 cm H x 20.45 cm W x 32.64 cm D (4.13 in H x 8.05 in W x 12.85 in D) | RELATIVE HUMIDITY ≤80%, non-condensing, 0 to 50°C |
| WEIGHT 2.1 kg (4 lbs. 9 oz.) | SHOCK AND VIBRATION Meets MIL-T-28800 specifications |
| OPERATING POWER 12V dc or 100, 120, 220, 240V ac ±10%, selectable 50 to 400 Hz; 8W typical, 14W max. | INPUT CONNECTION 4-wire to screw terminal block |
| WARM-UP to RATED ACCURACY 5 minutes | INPUT IMPEDANCE 1000 Mohms at DC |
| STORAGE TEMPERATURE -40°C to +75°C (storage for Y2009 is 0 to 40°C) | STABILITY ±175 ppm in 90 days, ±200 ppm per year |
| OPERATING TEMPERATURE 0 to 50°C (Y2009: 0 to 40°C) | TEMPERATURE COEFFICIENT ±15 ppm/°C from 25°C |

Table 1-3. General Specifications (cont)


| | |
|---|---|
| ACCURACY vs WIRE LENGTH No lead resistance error 4-wire RTD's if R_2 adjustment on the RTD Input Module is used. Otherwise, $0.04^\circ\text{C}/\Omega$ resistance of any one input lead if R_2 is not adjusted. | RTD EXCITATION CURRENT Nominal 0.5 mA. |
| DISPLAY $^\circ\text{F}$ or $^\circ\text{C}$, switch-selectable, 7-segment LEDs 1.1 cm high | COMMON MODE VOLTAGE 350V dc, 250V ac rms max. |
| RESOLUTION 0.01° below 204°C for platinum RTD's, automatically shifting to 0.1° above 204°C (93°C for nickel RTD's). If readings are decreasing, shift is at 77°C for platinum, 66°C for nickel. | NORMAL MODE REJECTION ≥ 90 dB at DC, 50, 60, and 400 Hz $\pm 0.1\%$. |
| MEASUREMENT METHOD Dual slope integration, under microcomputer control. 100 ms integration period, three readings per second. A/D Resolution is 100,000 counts at full-scale. | RESPONSE TIME 1 second typical. |
| LINEARIZATION TECHNIQUES Computer algorithm, 4th order curve fit. | ZERO DRIFT Automatic zero correction. RTD TYPES 100Ω 385 Pt (DIN), 390 Pt, 3902 Pt, 392 Pt, 100Ω Ni (DIN), 120Ω Ni, or 0 to 1000Ω resistance, selectable via switch located on the input module. |
| COMMON MODE REJECTION ≥ 160 dB at DC, 50, 60, and 400 Hz $\pm 0.1\%$ with 100Ω unbalance at inputs. | VOLTAGE RANGE (CALIBRATION ONLY) No annunciator or decimal point. $99999\mu\text{V}$ full scale (switch S2 in AUTO), resolution $1\mu\text{V}$ $999990\mu\text{V}$ full scale (switch S2 in .1), resolution $10\mu\text{V}$ |



static awareness



A Message From
John Fluke Mfg. Co., Inc.




Some semiconductors and custom IC's can be damaged by electrostatic discharge during handling. This notice explains how you can minimize the chances of destroying such devices by:

1. Knowing that there is a problem.
2. Learning the guidelines for handling them.
3. Using the procedures, and packaging and bench techniques that are recommended.


The Static Sensitive (S.S.) devices are identified in the Fluke technical manual parts list with the symbol




The following practices should be followed to minimize damage to S.S. devices.




1. MINIMIZE HANDLING




3. DISCHARGE PERSONAL STATIC
BEFORE HANDLING DEVICES




2. KEEP PARTS IN ORIGINAL CONTAINERS
UNTIL READY FOR USE.




4. HANDLE S.S. DEVICES BY THE BODY



5. USE ANTI-STATIC CONTAINERS FOR HANDLING AND TRANSPORT




6. DO NOT SLIDE S.S. DEVICES OVER ANY SURFACE




7. AVOID PLASTIC, VINYL AND STYROFOAM® IN WORK AREA

PORTIONS REPRINTED
WITH PERMISSION FROM TEKTRONIX, INC.
AND GENERAL DYNAMICS, POMONA DIV.



8. WHEN REMOVING PLUG-IN ASSEMBLIES, HANDLE ONLY BY NON-CONDUCTIVE EDGES AND NEVER TOUCH OPEN EDGE CONNECTOR EXCEPT AT STATIC-FREE WORK STATION. PLACING SHORTING STRIPS ON EDGE CONNECTOR USUALLY PROVIDES COMPLETE PROTECTION TO INSTALLED SS DEVICES.



9. HANDLE S.S. DEVICES ONLY AT A STATIC-FREE WORK STATION
10. ONLY ANTI-STATIC TYPE SOLDER-SUCKERS SHOULD BE USED.
11. ONLY GROUNDED TIP SOLDERING IRONS SHOULD BE USED.

Anti-static bags, for storing S.S. devices or pcbs with these devices on them, can be ordered from the John Fluke Mfg. Co., Inc.. See section 5 in any Fluke technical manual for ordering instructions. Use the following part numbers when ordering these special bags.

| John Fluke Part No. | Description |
|---------------------|---------------|
| 453522 | 6" X 8" Bag |
| 453530 | 8" X 12" Bag |
| 453548 | 16" X 24" Bag |
| 454025 | 12" X 15" Bag |
| Pink Poly Sheet | Wrist Strap |
| 30"x60"x60 Mil | P/N TL6-60 |
| P/N RC-AS-1200 | \$7.00 |
| \$20.00 | |

Section 2

Operating Instructions

2-1. INTRODUCTION

2-2. This section of the manual contains information regarding installation and operation of the 2180A Digital Thermometer. It is recommended that the contents of this section be read and understood before any attempt is made to operate the instrument. Should any difficulties arise during operation, please contact your nearest Fluke Technical Service Center, or the John Fluke Mfg. Co., Inc.; P.O. Box 43210; Mountlake Terrace, WA 98043; Tel (206) 774-2211. A list of Technical Service Centers is located in Section 7 of the manual.

2-3. SHIPPING INFORMATION

2-4. The 2180A is packaged and shipped in a foam-packed container. Upon receipt of the instrument, a thorough inspection should be made to reveal any possible shipping damage. Special instructions for inspection and claims are included on the shipping carton.

2-5. If reshipment of the instrument is necessary, the original container should be used. If the original container is not available, a new one can be obtained from the John Fluke Mfg. Co., Inc. Please reference the instrument model number when requesting a new shipping container.

2-6. INPUT POWER

2-7. The 2180A will operate at any of four switch selected input line voltages, all of which operate at frequencies from 50 to 440 Hertz. Before connecting the 2180A to the local ac line, verify that the present setting of the instrument matches the local line voltage. A decal on the instrument rear panel defines the original setting

required for operation. Refer to Section 4 of this manual for instructions on verifying or changing the input line voltage switch settings.

2-8. The rear panel ac input connector is a three-prong, U-ground connector which permits the instrument to be connected, via the power cord, to the applicable line voltage. The offset prong on this connector is attached to the 2180A power supply, and should be connected through the power cord to a high quality earth ground.

2-9. The 2180A will also operate on 12V dc power. A rear panel terminal block, with screw tightened connections, (TB1), allows for ease of attachment. Actual input voltage may vary from 11 to 15V dc; most 12V dc power supplies capable of supplying 1A (e.g., a car battery) can be utilized.

2-10. INSTALLATION

2-11. The 2180A is contained in a special molded plastic instrument case. Other associated accessories used with the 2180A will be packaged in similar PTI (Portable Test Instrument) cases varying only in size. The cases are, in all other respects, compatible and can be stacked vertically and latched together to form miniature portable test systems. Instrument stacks should be limited to a total of 40 pounds.

2-12. Use the following procedure when attaching PTI cases to each other:

1. For the top case, pull out latches found on either side of the instrument.
2. Nestle top and bottom cases together.
3. Push latches in to secure units together.

2-13. Prepare the 2180A for operation by plugging the input line power cord into the applicable power source or connecting the external input connector to an external 12V dc source.

2-14. OPERATING FEATURES

2-15. The location of the 2180A controls, indicators, and connectors is shown and described in Figure 2-1 and Table 2-1 respectively.




Figure 2-1. Controls, Indicators and Connectors

Table 2-1. Controls, Indicators and Connectors

| REF | NAME | FUNCTION |
|-----|-----------------------------|--|
| 1 | Digital Display | Displays a five digit readout of the measured input temperature. Leading zero suppression and a variable position decimal point are included. A minus sign is displayed for negative temperature measurements. Flashes when overranged. |
| 2 | Temperature Scale Indicator | Displays the temperature scale represented by the digital display data: °C or °F. |
| 3 | Power Switch | Push on/Push off. |
| 4 | SCALE | Selects the temperature scale for display: °C or °F. |
| 5 | LIMIT and FUNCTION | Part of the -006 Limits Option. When installed, the thumbwheels may be set to a four digit LIMIT value (+ or -). The FUNCTION thumbwheel can then be set to define the limit value and signal (LIMIT EXCEEDED) when the displayed temperature has exceeded the limit value (>, <). Display will read the difference between the thumbwheel setting and the actual temperature when (Δ) is set in FUNCTION. Set FUNCTION thumbwheel for storage of maximum (T) or minimum (L) measured since last initializing (no limit value settings). |
| 6 | LIMIT EXCEEDED | Part of the -006 Limits Option. Indicator illuminates when the preset limits have been exceeded. |
| 7 | CALIBRATION COVER | Sliding cover for calibration adjustments. |
| 8 | INITIALIZE MAX/MIN | Part of the -006 Limits Option. Resets the previous maximum and minimum readings stored by the microcomputer. |
| 9 | DIGITAL OUTPUT | Connector for the ASCII coded data for the Output Unit, if Option -002 is installed. |
| 9a | ANALOG OUTPUT | Banana jack connector for an Analog Output (1 mV per degree), if Option -002 is installed. |
| 10 | RTD INPUT MODULE | Removable module houses RTD input connections and type selection switch. |
| 11 | F2 | External 12V dc input fuse (3/4A MDL slo-blo). |
| 12 | ACCESSORY CONNECTOR | Cable connector for accessory bus connection from accessory units. |
| 13 | F1 | Input line power fuse 1/8A (100 or 120 VAC) 1/16A (220 or 240 VAC). MDL (slo-blo). |
| 14 | LIMITS | When the Limits Option is installed, it provides contact closure when the set limit has been exceeded. |
| 15 | ±12 VDC | Input terminals for the external 12V dc power source. |
| 16 | LINE VOLTAGE CONNECTOR | Input connector for the input line voltage. |

2-16. OPERATING NOTES

2-17. The following paragraphs describe various conditions that could affect operation of the thermometer. The operator should familiarize himself with these conditions prior to operating the 2180A.

2-18. Option Information

2-19. Supplementary operating instructions are necessary when operating the 2180A equipped with one of the available options. Detailed information regarding the operation of each available option is given in Section 6 of this manual, Option and Accessory Information.

2-20. Fuse Replacement

2-21. The ac line input and external dc input are individually fuse protected. Both fuses are readily accessible on the outside of the rear panel. The ac line input fuse (F1) should be replaced with a 1/8A MDL (slo-blo) fuse if either 100 or 120 volt operation has been selected. Use a 1/16A MDL (slo-blo) replacement for 220 or 240 volt operation. The external dc input (F2) requires a 3/4A MDL (slo-blo) fuse for a replacement.

CAUTION

Remove the power connector from the 2180A before changing fuses.

2-22. RTD Installation

2-23. Use the following procedure when installing an RTD and conducting temperature measurements:

1. Set POWER switch to OFF.
2. Remove the RTD Input Module from the instrument (rear panel).
3. Route the selected RTD lines through the Input Module's rear access port, and connect them to the input terminals; depending on the type of RTD, connections may involve 2, 3, or 4 wires. Refer to Figure 2-2 as a reference when connecting RTD lines to the Input Module (TB1). Lines of the same color usually go to the same polarity connections (+V and +S, or -V and -S). Refer to instructions included with the RTD for specific connection directions.

NOTE

When 2- or 3-wire RTDs are used, there is some error created due to the RTD excitation current in the Sense (S) wire leads. To minimize this error. The user should (when possible) use the 4-wire RTD connection as show in Figure 2-2.

4. On the Input Module, toggle the RTD Selector switch for the applicable position number shown in Table 2-2 or in the table printed on the pcb.

5. Slide the Input Module, RTD lines attached, back into the 2180A securely.

NOTE

Refer to Section 6 of this manual or applicable accessory manuals for instructions on the operation of any installed options or connected accessories.

6. Set POWER switch to ON.

7. Expose the RTD to a temperature within the RTD's specified range (see Specifications in Section 1).

8. The RTD temperature, in the scale selected, is displayed on the front panel.

9. Adjust R2 on the RTD Input Module to compensate for probe lead resistance. Refer to "RTD Input Module Adjustment" procedures in Section 4 of this manual. Adjustment must be performed whenever a different RTD probe is installed.

NOTE

When the RTD Input Selector Switch (S1) is set for Resistance, measurements greater than 196Ω cannot be made unless Autoranging is defeated. To do this, set S2 on the RTD Input Module for the ".1°" position. (See Table 2-3 for switch functions.)

2-24. OPERATING DIRECTIONS

2-25. Operate the 2180A Thermometer using the following procedure:

1. Verify the instrument has the correct RTD connected.
2. Connect the input line cord to the applicable power source.
3. Select the temperature scale desired for display by pressing the Front Panel SCALE switch (in for °C, and out for °F).
4. Set POWER switch to ON.




Figure 2-2. RTD Connections

2-26. Additional Features

2-27. The following paragraphs describe how the 2180A may be used to measure voltage or resistance. In both cases, the RTD will be replaced with a length of standard electrical wire. To connect the standard wire to the RTD Input Module, use steps 1-3 of the RTD Installation procedure, ignoring all reference to the RTD.

2-28. HOW TO MEASURE VOLTAGE

2-29. The 2180A can be used to measure positive voltages only up to +100 mV or +1V maximum in two ranges, with 1 μ V or 10 μ V resolution respectively. To obtain the desired range, refer to the following steps and Figure 2-3.

Table 2-2. RTD Input Module Switch Settings

| POS # | RTD TYPE | SWITCH POSITION | | | |
|-------|------------|-----------------|---|---|---|
| | | 1 | 2 | 4 | 8 |
| 0 | 385 Pt | 0 | 0 | 0 | 0 |
| 1 | 390 Pt | 1 | 0 | 0 | 0 |
| 2 | 3902 Pt | 0 | 1 | 0 | 0 |
| 3 | 392 Pt | 1 | 1 | 0 | 0 |
| 4 | 100 Ohm Ni | 0 | 0 | 1 | 0 |
| 5 | 120 Ohm Ni | 1 | 0 | 1 | 0 |
| 6 | --- | | | | |
| 7 | --- | | | | |
| 8 | Resistance | 0 | 0 | 0 | 1 |
| 9 | CAL | 1 | 0 | 0 | 1 |

Note: For switch segments 1, 2, 4 and 8: ON = 1, OFF = 0.

Table 2-3. RTD Input Module Switch Functions

| SWITCH NO. | SWITCH POSITION | SWITCH FUNCTIONS |
|------------|-----------------|---|
| S1 | 0 - 5 | Programs the microcomputer (μ c) for each RTD probe type (See Table 2-2.) |
| | 6, 7 | NOT USED |
| | 8 | "RESISTANCE", programs the μ c to read ohms. |
| | 9 | "CAL", programs the μ c to read μ V (bypasses the linearization program). |
| S2 | .1 | Causes the analog to digital converter circuitry (A/D) to have 10 μ V input sensitivity and displays temperature to 0.1° resolution only. |
| | AUTO | Causes the A/D to automatically change from .01° to 0.1° resolution for overrange or 0.1° to .01° resolution for underrange. |
| S3 | Scan | For future use only. |
| | Man | MUST BE LEFT IN THIS POSITION DURING NORMAL OPERATION. |

NOTE

The decimal point and temperature scale indicator ($^{\circ}\text{C}/^{\circ}\text{F}$) should be ignored during the following steps, the user must be aware of the selected range.

excitation $\approx 0.5\text{ mA}$). To set up the 2180A as a resistance measurement device, refer to the following steps and Figure 2-3.

NOTE

The temperature scale indicator ($^{\circ}\text{C}/^{\circ}\text{F}$) should be ignored during the following steps.

2-30. 100 millivolt Range

1. Install lead wire to the RTD Input Module, refer to RTD Installation procedures, steps 1-3 (this section).
2. Set RTD Input Module switches, S1 to position 9 and S2 to AUTO.
3. Replace RTD Input Module and turn 2180A on.
4. The 2180A is now ready to measure positive voltages up to +100 mV.

2-31. 1 Volt Range

1. Install lead wire to the RTD Input Module, refer to RTD Installation procedures, steps 1-3 (this section).
2. Set RTD Input Module switches, S1 to position 9 and S2 to .1 $^{\circ}$.
3. Replace RTD Input Module and turn 2180A on.
4. The 2180A is now ready to measure positive voltages up to +1V.

2-34. Resistance Measurements

1. Install lead wires to the RTD Input Module, refer to RTD Installation procedure, steps 1-3.
2. Set RTD Input Module switches, S1 to position 8 and S2 to .1 $^{\circ}$.
3. Connect a known resistance, less than 1 k Ω , to the wires connected to the RTD Input Module, and use the following steps to compensate for lead resistance.
4. Replace RTD Input Module and turn 2180A on.
5. Adjust R2 through the rear panel of the RTD's Input Module until the 2180A's display reads the same value as the known resistance.
6. Remove the known resistance, the 2180A is now calibrated and ready to measure positive resistances up to 999.9 Ω .

NOTE

For measuring resistances of less than 196 Ω , switch S2 on the RTD Input Module should be set to the AUTO position.

2-32. HOW TO MEASURE RESISTANCE

2-33. The 2180A can be used to measure positive resistances up to 999.9 Ω with 10 m Ω resolution (RTD




Figure 2-3. RTD Input Module Access

Section 3

Theory of Operation

3-1. INTRODUCTION

3-2. This section of the manual contains an overall functional description and a brief circuit analysis of the 2180A Digital Thermometer. Simplified circuit diagrams are provided, as necessary, to supplement the text. Detailed schematics are given in Section 8 of this manual.

3-3. The Model 2180A is a single point RTD Digital Thermometer with 0.1° and $.01^\circ$ resolution for either degrees F or C. This instrument features dual slope A/D conversion, microcomputer control logic, and a 5-digit display with temperature scale indicator. Various RTD types can be used over a temperature range of -394°F to 1435°F (-219°C to 664°C). Refer to Figure 3-1 for the following functional description. Mnemonic definitions are provided in Table 3-1.

3-4. FUNCTIONAL DESCRIPTION

3-5. The Model 2180A executes a continuous series of measurement cycles. These cycles, controlled entirely by a microcomputer, include three major periods: the Auto-Zero, the Integrate, and the Read periods. During each period, digital controls are applied to the analog section of a dual slope converter. The converter in turn generates a compare output. The configuration of the analog section during each phase of the measurement cycle is established by the condition of microcomputer controlled FET switches.

3-6. The measurement cycle begins with the Auto-Zero period. During this period, the input to the Buffer Amplifier is connected to ground through an FET switch and the accumulated dc offset voltages present in the analog section are sampled and held by the Auto-Zero capacitor. This voltage is used later in the measurement cycle to cancel measurement errors introduced by offset voltages in the analog circuitry. The final measurement is

therefore proportional to the RTD probe output voltage and does not include offset errors.

3-7. During the Integrate period, the RTD input voltage read across the RTD, is applied to the integrator. The algebraic sum of the AZ and RTD input voltages is integrated over a 100 ms period. At the end of this period, the RTD input voltage is removed from the integrator, and the Read period is started.

3-8. A reference voltage is applied to the integrator during the Read period, causing the integrator capacitor to be discharged at a linear rate. When the integrator output reaches zero, a compare signal is generated to end the Read period. The duration of the Read period is translated by the microcomputer, to provide a digital indication of the RTD temperature.




Figure 3-1. 2180A Simplified Block Diagram

Table 3-1. Mnemonics

| | |
|----------------|--|
| ANALOG COM | Measurement common |
| AZ | Auto-Zero |
| CM | Compare input to the microcomputer |
| <u>DATA</u> | Data on bus |
| <u>DCLK</u> | Data clock |
| DE+ | Positive read command |
| DE- | Negative read command |
| DIGITAL COM | -15V with respect to Analog Com |
| D.P./NEG | Drives decimal point, depending on reading and resolution |
| INT 1 | Causes the unknown voltage to be integrated |
| <u>LINEAR</u> | Used to command the microcomputer to display linear counts |
| <u>WRT</u> | Write |
| <u>WRT ADR</u> | Write address, signals that an address is being transmitted |
| X10 | Selects a buffer gain of X10 (0.1° resolution) |
| X100 | Selects a buffer gain of X100 (0.01° resolution) |
| $\Delta 2$ | Hold command |
| + SENSE | Voltage sense wires from RTD - no current flows in these wires |
| -SENSE | Voltage sense wires from RTD - no current flows in these wires |
| +Vm | An intermediate voltage - not used directly |
| -V | Current return |

3-9. CIRCUIT ANALYSIS

3-10. Circuit analysis of the 2180A is discussed in two sections: digital and analog. The digital section is covered first; particular attention is paid to digital control of the analog section. The analysis of the analog section covers the analog measurement circuitry and the 2180A power supply.

3-11. Digital Section

3-12. The digital section of the 2180A consists of a single-chip microcomputer with a self-contained, programmed, read only memory (U9), a hex CMOS open drain buffer (U13), and an LED display. This section, shown in Figure 3-2, will provide the following functions:

1. Conversion of the non-linear RTD probe voltage, as measured by the analog section, into a linear digital display.
2. Control of the analog section.
3. Control of all accessories on the accessory bus.

3-13. The microcomputer (U9) contains all of the 2180A programming, control logic, and linearizing capability. It also provides all signals necessary to update the display. Linearization of the RTD signal is accomplished by using a piece-wise, 4th order, curve-fit approximation for each

type of RTD. One of the seven operating programs is selected for the RTD type by setting S1 on the RTD Input Module. A table showing RTD switch setting numbers and corresponding RTD types is printed on the RTD Input Module PCB.

3-14. Measurement data is continuously strobed out of the microcomputer in decoded-seven-segment, bit-parallel, character-serial format. This data is then sent to the LED display.

3-15. The total measurement cycle takes 300 ms. The cycle consists of the following periods:

1. Auto-Zero period (100 to 200 ms).
2. Integrate period (100 ms). A 1 ms nominal hold signal is inserted at the beginning and end of the Integrate period to accommodate settling times in the analog section.
3. Read period (variable 0 to 100 ms).

3-16. Analog Section

3-17. ANALOG MEASUREMENT CIRCUIT

3-18. The analog measurement circuitry consists of an RTD input circuit, two voltage reference circuits, a ground sense amplifier, a buffer amplifier, a dual slope




Figure 3-2. Simplified Schematic – Digital

3-19. The RTD Input circuit comprises the RTD probe, the RTD Input Module, and a low pass filter on the Input Module's PCB. Source current flows through a series combination of the RTD probe, R2 (RTD Input Module), and R1 (Main PCB). The voltage sensed across the RTD is routed through the Input Module, and onto the Main PCB. The +Sense line (always a positive voltage) is then applied to the low pass filter.

3-20. The ground sense amplifier (Q20, U7 and associated circuitry) maintains the -Sense line at measurement ground. This amplifier compensates for noise and offsets on the -V and -Sense lines.

3-21. To achieve switching between 0.01° and .1° resolution, the buffer gain is shifted by a factor of ten. For 0.01° resolution, FET switch Q17 is on, and a reference voltage of -100 mV is applied to the buffer (Q19, U5). The buffer gain is set to 100. For 0.1° resolution, FET switch Q16 is on, and a reference voltage of -1.00V is applied and the buffer gain is 10.

3-22. The first voltage reference consists of a resistor network supplied by an accurate 6.2V dc reference voltage. The resistive divider network is set to provide 200 mV to Q14, 100 mV to Q15, 1.0V to Q11, and 2.0V to Q10.




Figure 3-3. Simplified Schematic – Analog

When 0.01° resolution is in use, Q12 will allow reference capacitor C19 to attain a -100 mV charge. For 0.1° resolution, Q8 will allow C20 to charge to $+1.0$ V. Either reference capacitor will be placed at the $-Sense$ level during Auto-Zero. Recovery deintegrate is applied to Q10 and Q14.

3-23. A second voltage reference (U15-6) provides an accurate 6.2 V across the series combination of R1 (Main Thermometer PCB), R2 (RTD Input PCB), and the RTD. This voltage therefore provides the source ($+V$) voltage for the RTD.

3-24. The Buffer, Integrator, Gain Stage, and Comparator Amplifiers combine to perform the analog functions of the Integrate, Read, and Auto-Zero periods. The Buffer is used to provide integrator inputs during all three periods. The Integrator integrates the Buffer output voltage during the Integrate and Read periods and, in combination with the Gain Stage, functions as a closed-loop amplifier during the Auto-Zero period.

3-25. An Auto-Zero period is commanded during the first phase of each measurement cycle. During this time, five auto-zero switches (Q4, Q5, Q11, Q15, and Q22) are closed by the microcomputer. Three of the switches (Q11, Q15, and Q22) charge the reference capacitors to $+100$ mV on C19 and $+1.0$ V on C20. Closing switch Q4 connects the Integrator and Gain Stage into a closed-loop configuration. This action also allows the Auto-Zero capacitor (C12) to charge to a value proportional to the algebraic sum of all the offset voltages in the Buffer, Integrator and Gain Stage. At the end of the Auto-Zero period, switches Q4, Q5, Q11, Q15, and Q22 are opened. The reference capacitors (C19 and C20) and the Auto-Zero capacitor retain their charges for later use in the measurement cycle.

3-26. The Integrate period (see Figure 4-4) starts on the leading edge of the integrate command from the microcomputer; switch Q21 is closed and switch Q7 is opened. The RTD input voltage is applied through switch Q21 to the Buffer input. After a 1 ms settling period, switch Q7 closes, and the Buffer output is applied to the Integrator for 100 ms. As the integrator capacitor C2 charges, the Integrator drives the comparator, through the gain stage to $+5$ V dc which indicates that the charge on C2 is more negative than the Auto-Zero Reference C12. At the end of the Integrate period, the integrate capacitor is charged to a level and polarity proportional to the RTD voltage, and switches Q21 and Q7 return to the open state.

3-27. The Read period starts at the end of the Integrate period. Depending upon the input polarity sensed by the comparator during the Integrate period, one of two Read modes is enabled if a positive input is sensed, a positive

Read mode is enabled. Similarly, a negative Read mode is enabled when a negative input is sensed.

3-28. When the positive Read mode is commanded, FET switches Q13 and Q9 are closed. If 0.1° resolution is in effect, Q8 will place the positive side of reference capacitor C20 at ground. With 0.01° resolution in effect, Q12 will place the positive side of reference capacitor C19 at ground. Reference capacitors C20 and C19 will then apply either -1.0 V or -100 mV, respectively, to the Buffer input.

3-29. When the negative Read mode is commanded, switches Q10 and Q14 are closed; Q9 and Q13 are open. With $.01^\circ$ resolution selected, approximately $+200$ mV will be applied to the positive side of reference capacitor C19. The algebraic sum of the voltage at the Buffer input will then be $+100$ mV. When 0.1° resolution is selected, approximately $+2.0$ V will be applied to the positive side of reference capacitor C20. Buffer input voltage will then be $+1.0$ V (only during recover deintegrate).

3-30. After a 1 ms settling time, switch Q7 closes and the Buffer output voltage is applied to the Integrator input. The integrator capacitor now begins to discharge at a linear rate (determined by the reference voltage). This discharge continues until the integrator voltage reaches the comparator trip point, which is referenced to the voltage on the Auto-Zero capacitor. When this level is reached, the comparator changes state, commanding the microcomputer to terminate the Read period. To facilitate auto-zero, the microcomputer then calls a reference voltage opposite in polarity to the one previously used (DE- or DE+). When the integrator reaches the trip point, the microcomputer immediately begins the Auto-Zero period.

3-31. Offset voltages present during the Integrate and Read periods are cancelled by offset voltages that were sampled and held during the Auto-Zero period.

3-32. POWER SUPPLY

3-33. The 2190A Power Supply consists of a DC to DC Converter and regulating circuitry. AC inputs are made via the input power cord, line fuse, and power transformer/rectifier. External $+12$ V dc inputs can also be made directly to the DC to DC Converter circuitry via line TB1 (see Main PCB schematic, Section 8). The function of the power supply is to provide $+5$ V, $+5$ V unregulated, $+15$ V, and -15 V dc operating voltages for the 2180A circuitry. The power supply can be driven from ac line or 12 V dc external source. The DC to DC conversion and voltage regulation is accomplished using conventional power supply design techniques.

Section 4

Maintenance

WARNING

THESE SERVICING INSTRUCTIONS ARE FOR USE BY QUALIFIED PERSONNEL ONLY. TO AVOID ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING OTHER THAN THAT CONTAINED IN THE OPERATING INSTRUCTIONS UNLESS YOU ARE QUALIFIED TO DO SO.

4-1. INTRODUCTION

4-2. This section of the manual provides information about warranty, factory service, maintenance, performance testing, routine recalibration and recalibration after repair. The performance test is recommended when the instrument is received and later as a preventive maintenance tool or for testing after repair. The test verifies performance at several temperatures within the range of a given RTD type. Specifications are provided both for annual and for a more precise 90-day performance-testing cycle.

4-3. SERVICE INFORMATION

4-4. The instrument is warranted for a period of 1 year upon delivery to the original purchaser. The WARRANTY is located on the back of the title page of this manual.

4-5. Factory authorized calibration and service for each Fluke product is available at various worldwide locations. A complete list of these service centers is included in Section 7 of this manual. If requested, an estimate will be provided to the customer before any work is begun on instruments that are beyond the warranty period.

4-6. GENERAL MAINTENANCE

4-7. Instrument Disassembly and Resassembly

4-8. Disassemble the thermometer using the following procedure (power cord disconnected):

1. Remove the RTD Input Module through its access port in the rear panel.
2. On the bottom of the instrument, remove the four securing screws. Lift the top cover free.
3. Remove the screw securing the center of the Main PCB to the bottom portion of the case.
4. Lift the Main PCB, complete with Front and Rear Panels, clear of the case.
5. Remove the Output Option, if installed and required, by removing the three screws connecting it to the Main PCB, disconnecting the interconnect cables at J1 and J3, and lifting the Output Option PCB clear.
6. Remove the Front Panel, if required, by disconnecting the guard screw at the lower right corner; disconnecting the Front Panel Interconnect cable at J6; disconnecting, if installed, the Limits Option interconnect cable at J4; and moving the Front Panel forward.
7. Remove the Rear Panel, if required, by removing the three screws attaching it to the Main PCB, disconnecting the wires from the input line power connector, unsoldering the wires from two fuse holders and moving the rear panel free.
8. Perform reassembly in the reverse order.

4-9. Input Power

4-10. Input line power voltage is selected by positioning the two switches on the right edge of the Main PCB. Each switch (S3 and S4) has a position identifying slot; Figure 4-1, shows these slots positioned for 120V ac operation. Table 4-1 lists the switch settings for other line voltages.




Figure 4-1. Line Voltage Selection

Table 4-1. Line Voltage Selection

| VOLTAGE | S3 SLOT (REAR SW) | S4 SLOT (FRONT SW) |
|---------|----------------------|-----------------------|
| 100 | Left | Right |
| 120 | Left | Left |
| 220 | Right | Right |
| 240 | Right | Left |

4-11. Cleaning

4-12. Clean the instrument periodically to remove dust, grease and other contamination. Use the following procedure:

CAUTION

Do not use aromatic hydrocarbons or chlorinated solvents for cleaning. They will react with plastic materials used in the manufacture of the instrument.

1. Clean the front panel and case with a soft cloth dampened with a mild solution of detergent and water.
2. Clean the surface of the pcb using clean, dry air at low pressure (≤ 20 psi). If grease is encountered, spray with Freon T.F. Degreaser or anhydrous alcohol and remove grime with clean, dry air at low pressure.

4-13. Fuse Replacement

WARNING

DISCONNECT THE UNIT FROM LINE POWER BEFORE ATTEMPTING FUSE REPLACEMENT.

4-14. The 2180A has two fuses, both accessible on the rear panel. F1 is for the input line power and should be replaced, when necessary, with a 1/8A MDL (slo-blo) fuse when the input line power selected is 100V or 120V. When the input power selected is 220V or 240V, F1 should be replaced with a 1/16A MDL fuse. F2 is for the 12V dc external power and requires a 3/4A MDL fuse.

4-15. Service Tools

4-16. No special tools are required for maintenance or repair.

4-17. Static Discharge Precautions

4-18. Static discharge can damage components contained in the 2180A. The following precautions should be observed when conducting adjustments or repairs with the instrument's top cover removed.

1. Never conduct repairs without first pressing power OFF, disconnecting the line cord and accessory bus cable from the ACCESSORY CONNECTOR.
2. Perform all repairs at a static-free work station.
3. Minimize bandling of ICs and the pcb; in no case handle them by their connectors.
4. Keep repair parts in their original container until ready for use.
5. Use static ground straps to discharge repair personnel.
6. Use conductive foam or anti-static containers to store replacement or removed ICs.
7. Remove all plastic, vinyl, and styrofoam products from the work area.
8. Do not slide static sensitive devices over any surface.
9. Use only anti-static type solder removal tools.
10. Use grounded tip soldering irons.

4-19. PERFORMANCE TEST

4-20. The Performance Test verifies instrument performance to specifications and may be used for initial acceptance, verifying calibration, or as an aid in troubleshooting. If the thermometer fails to meet specifications either the Calibration Adjust Procedure or Troubleshooting should be performed, as determined by qualified service personnel.

4-21. Table 4-2 lists the equipment required for the Performance Test and Calibration Adjust Procedure. If the recommended model of test equipment is not available, a substitute that meets the minimum use specifications may be used. The test should be conducted with an ambient temperature of $25 \pm 2^\circ\text{C}$ ($77.0 \pm 3.6^\circ\text{F}$).

4-22. Use the following procedure for the Performance Test:

1. Set the POWER switch to OFF and remove the line power cord from the line voltage source.
2. On the RTD Input Module, position S1 to 9 and S2 to AUTO.
3. Connect the equipment as shown in Figure 4-2. Refer to Table 4-2 for Recommended Test Equipment.
4. Verify the POWER switch is OFF, then adjust the line voltage transformer for the nominal input line voltage.
5. Set the POWER switch to ON.
6. Allow the thermometer to stabilize (at least 5 minutes).
7. On the Decade Resistance Box, select 100.00Ω and adjust R2 on the RTD Input Module for a display of "51240" (equivalent to 0°C or 32°F).
8. Refer to that portion of Table 4-3 pertaining to the RTD(s) in use.
9. On the Decade Resistance Box, select the first resistance listed in Table 4-3 for the RTD type being verified.
10. On the RTD Input Module, set the selector switch for the RTD type to be verified (0-5). Refer to Table 2-2 for switch settings.
11. Verify that the 2180A reading is within the tolerance listed in Table 4-3 (90-day or 1-year).
12. Repeat steps 9, 10, and 11 for the remaining resistances listed for the RTD type being verified.
13. Repeat steps 9-12 for as many RTD types as necessary.
14. Set the line voltage transformer for line voltage minus ten percent and repeat the test for one RTD type.
15. Set the line voltage transformer for line voltage plus ten percent and repeat the tests for one RTD type.
16. Set the line voltage transformer for the input line voltage.




Figure 4-2. Performance Test Connections

Table 4-2. Recommended Test Equipment

| TEST EQUIPMENT | MINIMUM USE SPECIFICATIONS | RECOMMENDED MODEL |
|--------------------------------------|---|---|
| Variable Line-Voltage Transformer | 100, 120, 220, 240V ac, as required, $\pm 10\%$ | General Radio VARIAC W5HM |
| Decade Resistance Box | .01 Ω resolution | General Radio 1433T, ESI Model RS925A, or equivalent. |
| Voltage Divider | 100:1 | Fluke Y2022 or equivalent |
| Calibrator (DC Source) | 10 μ V resolution | Fluke 343A or equivalent |
| Digital Voltmeter ($\pm 100 \mu$ V) | 100 μ V resolution, on 10V range | Fluke 8800A or equivalent |
| Lag Bath | Temperature Stable, .01 $^{\circ}$ resolution | Customer Constructed. (See Lag Bath Construction, this section) |

Table 4-3. 2180A Performance Tests

| Ω INPUT | SELECT SWITCH SETTING | READING | | 90-DAY TOLERANCE \pm | | 1-YEAR TOLERANCE \pm | |
|----------------|-----------------------|--------------|--------------|------------------------|--------------|------------------------|--------------|
| | | $^{\circ}$ F | $^{\circ}$ C | $^{\circ}$ F | $^{\circ}$ C | $^{\circ}$ F | $^{\circ}$ C |
| 100.00 | (0) | 32.00 | 0.00 | * | * | * | * |
| 18.53 | | -328.00 | -200.00 | 0.346 | 0.192 | 0.355 | 0.197 |
| 204.88 | | 536.0 | 280.0 | 0.395 | 0.221 | 0.407 | 0.226 |
| 345.21 | | 1292.0 | 700.0 | 0.871 | 0.484 | 0.900 | 0.500 |
| 100.00 | (1) | 32.00 | 0.00 | * | * | * | * |
| 17.30 | | -328.00 | -200.00 | 0.211 | 0.127 | 0.219 | 0.132 |
| 206.17 | | 536.0 | 280.0 | 0.259 | 0.161 | 0.271 | 0.166 |
| 347.83 | | 1292.0 | 700.0 | 0.385 | 0.224 | 0.417 | 0.240 |
| 100.00 | (2) | 32.00 | 0.00 | * | * | * | * |
| 16.99 | | -328.00 | -200.00 | 0.091 | 0.052 | 0.099 | 0.117 |
| 206.29 | | 536.0 | 280.0 | 0.259 | 0.161 | 0.271 | 0.166 |
| 316.54 | | 1112.0 | 600.0 | 0.345 | 0.208 | 0.381 | 0.222 |
| 100.00 | (3) | 32.00 | 0.00 | * | * | * | * |
| 17.05 | | -328.00 | -200.00 | 0.196 | 0.122 | 0.204 | 0.117 |
| 206.82 | | 536.0 | 280.0 | 0.259 | 0.161 | 0.271 | 0.166 |
| 317.80 | | 1112.0 | 600.0 | 0.354 | 0.208 | 0.381 | 0.222 |
| 100.00 | (4) | -32.00 | 0.00 | * | * | * | * |
| 71.80 | | -67.00 | -55.00 | 0.172 | 0.105 | 0.173 | 0.106 |
| 161.70 | | 212.0 | 100.0 | 0.215 | 0.144 | 0.218 | 0.145 |
| 219.00 | | 347.0 | 175.0 | 0.231 | 0.150 | 0.238 | 0.152 |
| 81.77 | (5) | -70.00 | -56.67 | 0.172 | 0.105 | 0.173 | 0.106 |
| 189.66 | | 190.0 | 87.78 | 0.213 | 0.143 | 0.216 | 0.154 |
| 271.14 | | 340.0 | 175.1 | 0.230 | 0.149 | 0.237 | 0.152 |

* Note: R2 on the RTD input card must be adjusted to give an indication of 32 $^{\circ}$ F or 0 $^{\circ}$ C with 100 Ω input (See Step 7 of Performance Test).

4-23. CALIBRATION

4-24. The thermometer should be calibrated at either 90-day or annual periods, depending upon the accuracy desired, and any time that repairs are made to the instrument. Conversion between Fahrenheit and Celsius scales is realized through a mathematical computation by the microcomputer. Calibration in °F is recommended. Calibration in either scale (°F or °C) insures the accuracy of the other. Either scale can be verified by executing the Performance Test.

4-25. Equipment Preparation

4-26. Prepare the equipment for calibration using the following procedure:

1. Remove the top cover from the instrument.
2. Apply power to 2180A and all test equipment to be used. Insure the 2180A warm-up period has been sufficient to reach rated accuracy (at least 5 minutes).
3. Select the desired temperature scale (°C or °F). If the Limits Option is installed select the LIMITS (\leq or $>$) function.

NOTE

Before removing the RTD Input Module, set power switch to OFF.

CAUTION

Do not connect analog common (0V) to digital common (-15V with respect to analog common). Instrument damage may result.

4-27. Reference Adjust

4-28. Perform Reference Adjust using the following procedure:

1. Connect the DVM between TP16 and TP1 (Analog Common).
2. Adjust R7 for a reading of $6.2V \pm 100 \mu V$.

4-29. Reference Adjust (+V)

4-30. Perform the Reference Adjust for the +V using the following procedure:

1. Connect the DVM to TP17 (HI) and TP1 (LO - Analog Common).
2. Adjust R44 to obtain a reading of $6.2V \pm 100 \mu V$.

4-31. Zero Adjust

4-32. Perform the Zero Adjust using the following procedure:

1. Connect the 2180A Digital Thermometer, DC Voltage Calibrator, and Voltage Divider as illustrated in Figure 4-3.
2. On the RTD Input Module, place a jumper between -V and -S on TBI. Select AUTO (S2 on the Input PCB).
3. Toggle the RTD the select switch for setting 9.
4. On the 2180A front panel, access calibration adjustments behind the cover in the lower left corner. Loosen the screw and slide the cover to the left.
5. Set the Calibrator output to 0.00102V (10.2 μV to 2180A). Note the 2180A reading. Now reverse the input polarity and again note the reading. Adjust R29 (access beneath front panel calibration cover - ZERO) until the readings in both directions are the same.
6. Adjust R14 (Main PCB) for a reading of +10. Reverse input polarity and look for a 2180A reading of -10. Repeat steps 4 and 5 if a reading of -10 is not obtained.




Figure 4-3. Calibration Connections

4-33. Resolution Adjustments

4-34. Use the following procedure to adjust the 2180A's .01° and .1° display and the verify autoranging operation.

1. Replace the 2180A's top cover. Leave test equipment connected (DC Voltage Calibrator, Voltage Divider) as described in Zero Adjust instructions.
2. On the 2180A front panel, access calibration adjustments by loosening the screw and sliding the cover to the left.
3. On the RTD Input Module, set S2 to AUTO. Set input switch S1 to setting 9 (CAL).
4. Set the DC Voltage Calibrator output to 9.9V (99 mV to the 2180A).
5. Adjust R27 (.01° cal potentiometer) for a reading of 99000 \pm 1.
6. Change the calibrator output to 99V (990 mV to 2180A) and position S2 out of AUTO.
7. Adjust R28 (.1° cal potentiometer) for a reading of 99000.

NOTE

If the Y2022 is being used, leave the calibrator output at 9.9V and change the Y2022 setting the 10.

8. Change the calibrator output to 45V. The 2180A should read 45000 (Y2022 in 100).
9. Change the calibrator output to 4.5V. Place S2 in AUTO position. The 2180A should read 45000.

4-35. RTD Input Module Adjustment

4-36. Use the following procedure whenever 2180A calibration or repair has been accomplished or when a different RTD probe is installed.

1. Connect the RTD probe to the RTD Input Module (TB1).
2. Select the applicable input switch setting (S1) and insert the probe into a lag bath. Refer to the following paragraph for a suggested method of constructing a lag bath.
3. Install the RTD Input Module in the 2180A. Apply power to the 2180A.

4. Adjust R2 (access through rear hole on RTD Input Module) until the 2180A displays the lag bath temperature.

5. Calibration of the 2180A is now complete. Disconnect all test equipment from the instrument.

4-37. Lag Bath Construction

4-38. The following instructions provide a recommended method of constructing a lag bath.

1. Required materials include:

- Any RTD probe acceptable to the 2180A Digital Thermometer.
- A mercury thermometer (.01° resolution). Princo Model ASTM 116C or equivalent for room temperatures (18.9° to 25.1°C).
- Insulated jar (unbreakable inner envelope). Thermos or equivalent.

2. Drill two holes in the insulated jar's lid (or in some other suitable fitting). These holes should be just large enough to accept the mercury thermometer and the RTD probe.

3. With the jar containing water at room temperature, attach the lid, with RTD and mercury thermometer installed. The RTD should be immersed as far as possible without touching the bottom. The mercury thermometer should be immersed to the same water depth as the RTD.

4. Allow the temperature displayed on the digital thermometer to stabilize (usually 5 minutes).

5. Perform calibration.

4-39. SELECTED COMPONENT REPLACEMENT

4-40. Certain components in the two 6.2V reference supplies are supplied as a matched set. If a component in either set is replaced, all the components in that set must be replaced with a matched set supplied by John Fluke Mfg. Co., Inc. The two sets include R4, R5, and VR2 in the 6.2V reference and R43, R46, and VR5 in the 6.2V (V+) reference.

4-41. TROUBLESHOOTING

4-42. Troubleshooting for the 2180A consists of the tabular flow chart in Table 4-4. When a step on the flow chart is completed check for a decision transfer. If no decision is required perform the next step of the table in sequence. Refer to Figure 4-4 for test point location and Table 4-5 for test point identification.

CHANGE/ERRATA INFORMATION

ISSUE NO: 5 8/84

This change/errata contains information necessary to ensure the accuracy of the following manual. Enter the corrections in the manual if either one of the following conditions exist:

1. The revision letter stamped on the indicated PCB is equal to or higher than that given with each change.
2. No revision letter is indicated at the beginning of the change/errata.

MANUAL

Title: 2180A
Print Date: June 1978
Rev.- Date: 1-6/79

C/E PAGE EFFECTIVITY

| Page No. | Print Date |
|----------|------------|
| 1 | 8/84 |
| 2 | 8/84 |
| 3 | 8/84 |
| 4 | 8/84 |
| 5 | 8/84 |
| 6 | 8/84 |
| 7 | 8/84 |
| 8 | 8/84 |
| 9 | 8/84 |
| 10 | 8/84 |
| 11 | 8/84 |
| 12 | 8/84 |
| 13 | 8/84 |
| 14 | 8/84 |
| 15 | 8/84 |

CHANGE #1 - 12307

Rev.-E, A4 Output Option PCB Assembly (2180A-4020T)

On page 602-8, Table 602-5,

CHANGE: R19|RES,VAR,100 +/-10%,1/2W|275735|11236|360T101A|1

TO: R19|RES,VAR,CERMET,100 +/-10%,1/2W|285130|89536|285130|1

On page 602-10, Figure 606-2, and page 8-10, Figure 8-4, rotate R19 90 degrees to face the outer edge of the PCB.

CHANGE #2 - 12526

On page 5-3, Table 5-1,

Add "1" in the USE CODE column for reference designators H5, MP16, MP17, MP18, MP19, and MP20.

At the bottom of the page,

ADD: 1 If the handle on your case is secured by a rivet, these components are included in one assembly (C-size Cover Assy). Order John Fluke P/N 516703.

ERRATA #1

On page 1-2, Table 1-1,

DELETE: Y2025 | Probe, RTD, 100 ohm, 385 PT

On page 1-4, Table 1-3,

ADD: PROTECTION CLASS 1

Relates solely to insulation or grounding properties further defined in IEC 348.

CHANGE #3 - 12964

Rev.-F, A4 Output Option -002 PCB Assembly (2180A-4020T)

On page 602-7, Table 602-5,

CHANGE: 002|Output Option -002 PCB Assembly|-002|89536|2190A-002|REF
Figure 602-2 (2180A-4020T)

TO: A4|Output Option -002 PCB Assembly|-002|89536|2190A-002|REF
Figure 602-2 (2180A-4020T)

A4A1|O.U. Adapter Assembly|539288|89536|539288|1

Add Table 1 and Figure 1 to the end of page 602-10.

Table 1. A4A1 O.U. Adapter Assy

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFR SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY |
|------------|---|-----------------------|---------------------|-------------------------|------------|------------|
| A4A1 | O.U. ADAPTER ASSY FIGURE 2. (2180A-4021) | 539299 | 89536 | 539288 | 1 | |
| Q1,3 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N904 | 2 | |
| R1 | RES, DEP, CAR, 10K +5%, 1/4W | 348839 | 80031 | CR251-1-5-10K | 1 | |
| U1 | IC, C-MOS, DUAL, "D"-TYPE | 340117 | 02735 | CD4012AE | 1 | |
| U2 | IC, C-MOS, HEX, INVERTER | 404681 | 02735 | CD4069BE | 1 | |




Figure 1. A4A1 O.U. Adapter Assy

On page 8-1,

ADD: 8-4a. A4A1 O.U. Adapter PCB Assy, 2180A-1021

On page 8-12, add Figure 2.




Figure 2. A4A1 O.U. Adapter Assy

CHANGE #4 - 12993

AN UPDATED MICROCOMPUTER (TYPE #2) MAY BE PRESENT IN YOUR INSTRUMENT. IF SO, YOUR INSTRUMENT AT TURN ON WILL DISPLAY: "8002.2" AND YOU SHOULD PROCEED WITH THIS CHANGE. HOWEVER, IF YOUR INSTRUMENT AT TURN ON DISPLAYS "2180A.1" THEN YOU HAVE MICROCOMPUTER TYPE #1 AND THIS CHANGE SHOULD BE IGNORED.

On page iii/iv,

CHANGE: 1-3 General Specifications 1-3

TO: 1-4 General Specifications 1-4

ADD: 1-3 IPTS 68 Coefficients* 1-3

* For 2180A Curve Fit Linearizations

On page 1-1, replace paragraph 1-11 with,

1-11. Specifications for the 2180A Digital Thermometer are given in Table 1-4. These specifications assume that microcomputer type #2 has been installed in your instrument and at turn on the display reads "8002.2".

On page 1-2 and 1-3, replace Table 1-2 with Table 2.

Table 2. Total Instrument Accuracy Specifications (MICROCOMPUTER TYPE #2)

| R T D T Y P E | R E S O L U T I O N | TEMPERATURE RANGE | | MAXIMUM ERROR* | | | | | |
|-------------------------------------|--|----------------------------|------------------------------|----------------|--------------------------------|------------------------------|--------------|--------------------------------|------------------------------|
| | | APPLICABLE PORTION OF | | ±DEGREES C | | | ±DEGREES F | | |
| | | °C | °F | AT CAL | 90 DAYS 20° to 30° | 1 YR. 15° to 35° | AT CAL | 90 DAYS 68° to 86° | 1 YR. 59° to 95° |
| 100 ohm | .01° | -190 to 0 0 to 204 | -309.9 to 32 32 to 399.2 | .043 .043 | .089 .132 | .112 .173 | .076 .076 | .161 .239 | .203 .314 |
| 385 Pt | .1° | -190 to 0 0 to 750 | -309.9 to 32 32 to 1382.0 | .11 .11 | .12 .26 | .14 .37 | .18 .18 | .21 .46 | .24 .62 |
| 100 ohm | .01° | -200 to 0 0 to 204 | -327.9 to 32 32 to 399.2 | .009 .009 | .055 .098 | .078 .139 | .015 .015 | .100 .177 | .142 .252 |
| 390 Pt | .1° | -200 to 0 0 to 750 | -327.9 to 32 32 to 1382.2 | .08 .08 | .10 .23 | .11 .32 | .13 .13 | .16 .41 | .19 .57 |
| 100 ohm | .01° | -200 to 0 0 to 204 | -327.9 to 32 32 to 399.2 | .040 .040 | .086 .13 | .109 .171 | .071 .071 | .156 .234 | .198 .309 |
| 3916 Pt | .1° | -200 to 0 0 to 750 | -327.9 to 32 32 to 1382.2 | .11 .10 | .12 .26 | .14 .34 | .17 .17 | .21 .46 | .24 .62 |
| 100 ohm | .01° | -200 to 0 0 to 204 | -327.9 to 32 32 to 399.2 | .008 .009 | .055 .098 | .078 .139 | .014 .014 | .099 .177 | .141 .252 |
| 392 Pt | .1° | -200 to 0 0 to 750 | -327.9 to 32 32 to 1382.2 | .08 .08 | .10 .23 | .11 .32 | .12 .12 | .16 .41 | .19 .57 |
| 100 ohm | .01° | -60 to 0 0 to 93 | -76 to 32 32 to 199.4 | .129 .129 | .157 .176 | .172 .199 | .230 .231 | .282 .317 | .308 .359 |
| 617 Ni | .1° | -60 to 0 0 to 177 | -76 to 32 32 to 350.6 | .19 .19 | .20 .22 | .21 .25 | .33 .33 | .35 .39 | .36 .44 |
| 10 ohm | .01° | N/A | | | | | | | |
| CU | .1° | -75 to 0 -75 to 150 | -103 to 32 -103 to 302 | .16 .16 | .18 .20 | .19 .23 | .27 .27 | .31 .35 | .34 .41 |
| OHMS | | 0 to 196.99 0 to 999.99 | .005 .05 | .042 .22 | .059 .31 | ALL UNITS IN OHMS | | | |

* Maximum error depends on the temperature measured and the resolution used. Of the four temperature ranges presented for each RTD, the first two represent .01° resolution. The above maximum error numbers represent instrument errors only, and do not include the RTD probe.

On page 1-3,

CHANGE: Table 1-3. General Specifications

TO: Table 1-4. General Specifications

Add Table 1-3, as shown in Table 3.

Table 3.

| Table 1-3. IPTS 68 Coefficients* (For Microcomputer Type #2 Curve Fit Linearization) | |
|---|---|
| RTD TYPE | RTD LINEARIZATION COEFFICIENTS |
| 100 OHM 385 Pt | DIN 43760 TABLE |
| 100 OHM 390 Pt | ALPHA = 0.0038994 DELTA = 1.494 A4 = -0.265668 X 10 ⁻⁴ C4 = -0.205984 X 10 ⁻¹¹ |
| 100 OHM 3916 Pt | ALPHA = 0.003916 DELTA = 1.505 A4 = -.099668 X 10 ⁻⁵ C4 = -0.192912 X 10 ⁻¹³ |
| 100 OHM NI | ALPHA = 0.00617 |
| 10 OHM CU | R0 = 9.042 OHM R25 = 10.005 OHM ALPHA = .004260 |
| * SEE NBS MONOGRAPH 126 | |

On page 1-4, replace the "RTD TYPES" specification with the following:

RTD TYPES
100 ohm 385 Pt (DIN),
100 ohm 390 Pt, 100 ohm 3916 Pt, 100 ohm 392 Pt,
100 ohm Ni (DIN), 10 ohm CU.

On page 2-4, paragraph 2-23:

Replace step 4 with,

4. On the Input Module toggle the RTD Selector Switch (S1) to obtain the desired RTD type, see Table 2-2.

NOTE

Your RTD Input Module may be printed with microcomputer Type #1 selector switch settings. Therefore we advise that you refer to Table 2-2 when changing RTD types.

Replace step 9 and the note following, with,

NOTE

R2 on the 2180A is adjusted at the factory with a 100 ohm input resistance. If the 2180A is used with a 100 ohm 385 Pt RTD probe meeting DIN standard #43760 then the R2 adjustment in the following paragraph may be skipped.

9. Adjust R2 on the RTD Input Module to compensate for variations in lead resistance and in RTD probe R_0 values. Refer to section 4 for RTD input module adjustment procedures. This adjustment must be performed when an RTD probe is initially installed and whenever the leads or the RTD are changed.

NOTE

The R2 adjustment can be used to calibrate the 2180A and the probe near a specific temperature. Adjust R2 for agreement between the 2180A and a customer supplied temperature reference at the temperatures of interest.

On page 2-5, replace Table 2-2 with Table 4.


Table 4. RTD Input Module Switch (S1) Settings

| TYPE UP | DISPLAY READING AT TURN ON | RTD SELECTOR SWITCH (S1) SETTINGS | | | | | | | | | |
|------------|-------------------------------------|-----------------------------------|---------------|----------------|---------------|------------|-----------|---|---|-----|-----|
| | | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| 2 | 8002.2 | 100* 385** | 100* 390** | 100* 3916** | 100* 392** | 100* NI | 10* CU | - | - | OHM | CAL |

* = OHMS

** = PLATINUM (PT)

EXAMPLE: To select a switch setting of 5, position the RTD selector switch (S1) as shown:



In Table 2-3, for SWITCH NO. S3,
 CHANGE: SCAN For future use only.
 TO: SCAN Not used.

On page 4-3, paragraph 4-21, change the last sentence,
 FROM: ... 25 +/-2 C (77.0 +/-3.6 F).
 TO: ... 25 +/-5 C (73.4 +/-9 F).

On page 4-4, replace Table 4-3 with Table 5.

Table 5. 2180A Performance Test

| MICROCOMPUTER #2 | | | | | | | |
|------------------|------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| OHM INPUT | SELECT SWITCH | READING | | 90 DAY | | 1 YEAR | |
| | | $^{\circ}\text{F}$ | $^{\circ}\text{C}$ | $^{\circ}\text{F}$ | $^{\circ}\text{C}$ | $^{\circ}\text{F}$ | $^{\circ}\text{C}$ |
| | (0) | | | | | | |
| 39.650 | 100 ohm | -238.00 | -150.00 | .100 | .054 | .104 | .057 |
| 212.030 | 385 Pt | 572.0 | 300.0 | .30 | .17 | .32 | .19 |
| 345.210 | | 1292.0 | 700.0 | .44 | .25 | .49 | .27 |
| | (1) | | | | | | |
| 38.777 | 100 ohm | -238.00 | -150.00 | .044 | .024 | .049 | .027 |
| 213.472 | 390 Pt | 572.0 | 300.0 | .25 | .14 | .28 | .16 |
| 348.446 | | 1292.0 | 700.0 | .39 | .22 | .44 | .25 |
| | (2) | | | | | | |
| 38.679 | 100 ohm | -238.00 | -150.00 | .100 | .055 | .105 | .058 |
| 213.929 | 3916 Pt | 572.0 | 300.0 | .28 | .16 | .30 | .17 |
| 349.323 | | 1292.0 | 700.0 | .42 | .24 | .47 | .26 |
| | (3) | | | | | | |
| 38.612 | 100 ohm | -238.00 | -150.00 | .044 | .024 | .049 | .027 |
| 214.135 | 392 Pt | 572.0 | 300.0 | .25 | .14 | .28 | .16 |
| 349.909 | | 1292.0 | 700.0 | .39 | .21 | .43 | .25 |
| | (4) | | | | | | |
| 71.80 | 100 ohm | -67 | -55.00 | .26 | .15 | .27 | .15 |
| 161.70 | NI | 212 | 100.0 | .37 | .21 | .38 | .22 |
| 219.00 | | 347 | 175.0 | .39 | .22 | .40 | .23 |
| | (5) | | | | | | |
| 6.201 | 10 ohm | -100 | -73.3 | .33 | .19 | .34 | .19 |
| 14.778 | CU | 300 | 148.9 | .35 | .20 | .37 | .21 |

On page 4-6:

Change all references of "lag bath", to "ice bath".

Replace paragraph 4-38 and the five steps following, with,
4-38. The following instructions provide a recommended method of constructing an ice bath.

NOTE

Distilled water must be used to make the ice and must also be used in the ice bath.

1. Required material; supply of ice, distilled water and an insulated jar with an unbreakable lid (thermos or equivalent).
2. Prepare the insulated jar by drilling one or more holes just large enough to accept the RTD Probe or Probes.
3. Fill the insulated jar with shaved or crushed ice.
4. Fill the insulated jar with enough distilled water so that the ice becomes slush but not enough to float the ice.

NOTE

As the ice melts, siphon off the excess water and add more ice. Allow about 5 to 10 minutes for the water to drop back to the freezing point.

On page 5-3, Table 5-1,

CHANGE: U9|IC, MICROPROCESSOR|455014|01295|TMS9901N|1
TO: U9|IC, MICROPROCESSOR|525659|04713|MC3870CP|1

On page 600-1, Table 600-1,

DELETE: Y2025 | Probe, RTD, 100 ohm, 385 Pt

ERRATA #2

On page 4-5, paragraph 4-32:

Step 3, delete the second "the" in the sentence.

Step 5, replace the first sentence, with,

5. Set the calibrator output to 0.00102V and divider to +100 (10.2 μ V to 2180A).

On page 4-6, paragraph 4-34:

Replace steps 6 through 9, with the following:

6. Change the calibrator output to 4.5V (45 mV to 2180A). The 2180A should read 45000 +/-2.
7. Set switch S2 out of AUTO. Set DC calibrator output to 9.9V and the divider to 10 (990 mV to 2180A).

8. Adjust R28 (.1 C cal potentiometer) for a reading of 99000 +/-1.
9. Change the calibrator output to 4.5V, the 2180A should read 45000 +/-2 (450 mV to 2180A).
10. Place S2 in the AUTO position

On page 8-13, Figure 8-4, in the table on the far right, change U22 pin 4,
 FROM: GND
 TO: GND ISOLATED

ERRATA #3

On page 602-3, paragraph 602-25, change the last sentence,
 FROM: The message formats are shown in Figure 602-1.
 TO: The message formats are shown in Figure 602-1, and a timing diagram is given in Figure 602-1a.

On page 602-4, add Figure 602-1a as shown in Figure 3.




Figure 3.

CHANGE #5 - 13540

Rev.-G, A4 Output Option -002 PCB Assembly (2180A-4020T)

On page 602-9, Table 602-5:

CHANGE: U2|OPTO-ISOLATOR |380014|01295|T1L116|3

TO: U2|XSTR PHOTO (OPTO-ISOLATOR)|536045|14936|MCT-26|3

CHANGE: U3|OPTO-ISOLATOR |380014|01295|T1L116|REF

TO: U3|XSTR PHOTO (OPTO-ISOLATOR)|536045|14936|MCT-26|REF

CHANGE: U4|OPTO-ISOLATOR |380014|01295|T1L116|REF

TO: U4|XSTR PHOTO (OPTO-ISOLATOR)|536045|14936|MCT-26|REF

ERRATA #4

On page 602-1, Table 602-1, add the following to the end of the Parallel ASCII Interface specification:

CMOS compatible, will drive one TTL load.

On page 602-4, paragraph 602-28, step 10,

CHANGE: ... R26 ...

TO: ... R15 ...

ERRATA #5

On page 602-2, paragraph 602-8, add the following to the end of step 6:

When using the RS-232-C interface, set the address switch S3 to address 1, 6, 7, 8 or 9. When using with the 2XXXA-522 Personality Card and the 1120A IEEE-488 Translator, set the baud rate to 2400 and follow all discussions regarding the RS-232-C interface.

On page 602-4, replace Figure 602-1, with Figure 4.

```

1| 2| 3| 4| 5| 6| 7| 8| 9| 10| 11| 12| 13 | 14 | 15| 16| 17| 18| 19| 20| 21
NORMAL TEMPERATURE MEASUREMENT DATA
CH|CH|SP|SP|± |SP|0 |0 |0 |0/.|0/.|D |SP |SP |F/C|SP|SP|SP|SP|CR|LF
OPEN THERMOCOUPLE OUTPUT (2190A only)
CH|CH|SP|SP|± |SP|0 |0 |0 |0/.|0/.|D |SP |SP |F/C|SP|SP|0 |C |CR|LF
OVERRANGE OUTPUT
CH|CH|SP|SP|± |SP|0 |0 |0 |0/.|0/.|D |SP |SP |F/C|SP|SP|0 |L |CR|LF

```

NOTE: If the limits option in the thermometer is installed (option 21X0A-006) and is indicating an out of limit condition, character slot 17 will be an exclamation point (!) for any of the three above modes.

SYMBOL DESCRIPTION

| | |
|-----|--|
| CH | Channel indent numbers (00 thru 99) |
| SP | Space |
| ! | Thermometer limits Option Setpoint exceeded symbol |
| ± | Plus or minus symbol |
| 0 | Temperature data values (0 thru 9) |
| . | Floating decimal point, will be in character slots 11 or 12 or slot 12 when used with 2180A or 2190A Thermometer resp. |
| F/C | Fahrenheit or Celsius |
| CR | Carriage Return |
| LF | Line Feed |
| ? | Question mark |
| OT | Open Thermocouple (Character slots 16 and 17) |
| OR | Over Range (Character slots 16 and 17) |

Figure 4. Measurement Data Output Format
for RS-232-C and Current Loop Ports

CHANGE #6 - 15520

Rev.-D, A1 Main PCB Assembly (Thermometer PCB Assy)

On pages 5-6 through 5-8, Table 5-2:

CHANGE: C26|CAP, ELECT, 4000 UF -10/+100%, 25V
|370734|80031|3044TS043U025|1|1

TO: C26|CAP, ELECT, 4700 UF -10/+30%, 25V
|615567|89536|615537 |1|1

Change the FLUKE STOCK NO. and the MFG PART NO. for R1,
FROM: 474338
TO: 603258

CHANGE: R33|RES, COMP, 330 +/-5%, 1/4W|147967|01121|CB3315 |2
TO: R33|RES, DEP. CAR, 330 +/-5%, 1/4W|368720|80031|CR251-4-5P330E|2

CHANGE: R53|RES, COMP, 330 +/-5%, 1/4W|147967|01121|CB3315 |REF
TO: R53|RES, DEP. CAR, 330 +/-5%, 1/4W|368720|80031|CR251-4-5P330E|REF

ADD: R55|RES, VAR, CER, 25K +/-20%, 1/2W|285213|11236|190PC253B|1

On page 5-10, Figure 5-2, add R55 as shown in Figure 5.




Figure 5.

On pages 8-3 and 8-5, Figure 8-1, add R55 as shown in Figure 6, and change the value of C26,

FROM: 4000
TO: 4700 uF




Figure 6.

CHANGE #7 - 15725

Rev.-E, A1 Main PCB Assembly (Thermometer PCB Assembly) (2180A-4001T)

On pages 5-6 and 5-7, Table 5-2,

CHANGE: C26|CAP, ELECT, 4700 UF -10/+30%, 25V

|615567|89536|615537|1|1

TO: C26|CAP, ELECT, 4700 UF -10/+30%, 25V

|614115|89536|614115|1|1

ADD: MP4|CLAMP, CABLE W/C26|172080|89536|172080|1

CHANGE #8 - 16011

Rev.-H, A4 Output Option PCB Assembly (2180A-4020T)

On pages 602-8 and 602-9, Table 602-5:

CHANGE: U14|TRANSISTOR, J-FET, N-CHANNEL|460014|89536|460014|1|1

TO: U14|XSTR, FET, DUAL N-CHAN |419283|89536|419283|1|1

On page 602-10, Figure 602-2, change the configuration of U14 as shown in Figure 7.




Figure 7.

On page 8-11, Figure 8-4, change the pin assignments as shown in Figure 8.




Figure 8.

ERRATA #6

On page 602-9, Table 602-5, change the MFG PART NO. for U10,
 FROM: MC1406BCP
 TO: MC14069UBCP

ERRATA #7

On page 4-5, paragraph 4-32, add the following to the end of step 3.
 Toggle S3 to manual position.

ERRATA #8

On page 4-3, paragraph 4-22, step 6:
 CHANGE: ... 5 minutes).
 TO: ...20 minutes).

On page 4-5, paragraph 4-26, step 2:
 CHANGE: ... 5 minutes).
 TO: ...20 minutes).

ERRATA #9

On page 5-7, Table 5-2:
 CHANGE: H5|WASHER, FLAT |147728|73734|1402 |2
 TO: H5|WASHER, FLAT #4|110775|89536|110775|2

ERRATA #10

On page 5-3, Table 5-1, change the FLUKE STOCK NO. and MFG PART NO. for MP9,
 FROM: 472282
 TO: 655522

CHANGE #9 - 16985

Rev.-G, A1 Main PCB Assembly (2180A-4001)

On page 5-9, Table 5-2, change the FLUKE STOCK NO. and MFG PART NO. for U6,
 FROM: 448480
 TO: 510628

CHANGE #10 - 17669

Rev.-D, A3 RTD Input PCB Assembly (2180A-4003)

On page 5-12, Figure 5-4 and page 8-9, Figure 8-3, remove the type select table from the middle of the board.

CHANGE #11 - 18905

Rev.-H, A1 Main PCB Assembly (2180A-4001)

On page 5-7, Figure 5-2:
 CHANGE: MP4|CLAMP, CABLE W/C26|172080|89536|172080|1
 TO: MP4|CLAMP, CABLE W/C26|530360|89536|530360|1

CHANGE #12 - 19720

Rev.-K, A1 Main PCB Assembly (2180A-4001)

On page 5-9, Table 5-2:

CHANGE: U6 |...

TO: U6A|...

ADD: U6B|RES, NETWORK|577536|89536|577536|1|1

On page 8-3, Figure 8-1, indicate three U6A's and three U6B's as shown in Figure 9.




Figure 9.

Table 4-4. 2180A Troubleshooting

| STEP NO. | ACTION | Go to the step number given for correct response | |
|----------|--|--|----|
| | | YES | NO |
| 1 | Input 0 volts from the divider to +S (HI); -S, -V (LO); leave +V disconnected. | | |
| 2 | Set the RTD selector switch to setting 9 (Cal). | | |
| 3 | Apply power to the thermometer. | | |
| 4 | Does the display read 2180.X for ten seconds and then change to 0°C (0°F)? | 14 | 5 |
| | <i>NOTE</i> <i>X = a numeral depending on the version of software installed.</i> | | |
| 5 | Does any portion of the display illuminate? | 13 | 6 |
| 6 | Measure between TP2 (REF) and TP4 for +5 ±10% VDC, between TP1 (REF) and TP3 for +15 ±5% VDC. | | |
| 7 | Are all voltages correct? | 12 | 8 |
| 8 | Measure between pin 8 of T2 and the negative end of C26 for a DC voltage greater than 10.3V and for a peak-to-peak wave form between pins 8 and 9 of T2 approximately twice the value of the DC voltage measured at pin 8. | | |
| 9 | Are both signals present and correct? | 11 | 10 |
| 10 | Check the inverter circuit that drives the transformer (T2). Repair as required then resume at step 3. | | |
| 11 | Check the transformer secondaries and if any are bad, check the individual regulators and their associated components. NOTE: Analog circuitry may load down the ±15V supplies. Repair as required then resume at step 3. | | |
| 12 | Check the +5V path to the Display PC8 and the Display PC8 Connector. Repair as required then resume at step 3. | | |
| 13 | Check the strobes (U9-3, 4, 5, 6, 19) and display seven segment control lines (U9-8, 9, 10, 11, 12, 13, 14). Repair as required then resume at step 3. | | |
| 14 | Set the RTD selector switch to the setting of the type RTD to be connected in the next step. | | |
| 15 | Connect an RTD to the thermometer and measure some known temperature. (A lag bath is suggested.) | | |
| 16 | Is the displayed temperature correct? | 37 | 17 |
| 17 | Check the RTD components and the ground sense buffer amp (U7, Q20 and their associated components). Repair as required then resume at step 14. | | |
| 18 | Can the Calibration Adjustment Procedure be performed? | 37 | 19 |
| 19 | Are control signals at U9 pins 26, 27, 30, 31, 32 toggling between high and low logic levels? NOTE: the X100 signal at pin 33 of U9 will remain low (0V) unless unit is in 0.1° Range. (Use TP2 as common.) | 21 | 20 |
| 20 | Replace the microcomputer U9, then resume at step 14. | | |
| 21 | Are the outputs of U13 toggling between high and low logic levels? NOTE: The output at pin 1 of U13 will remain low (0V) unless 2180 is in 0.1° Range. | 23 | 22 |

Table 4-4. 2180A Troubleshooting (cont)

| STEP NO. | ACTION | Go to the step number given for correct response | |
|----------|--|--|----|
| | | YES | NO |
| 22 | Check U13, Q27 and their associated components. Repair as required then resume at step 14. | | |
| 23 | Is the waveform at TP7 as shown in Figure 4-4 (Magnitude & Polarity varies with the input signal)? | 30 | 29 |
| 24 | Is there 6.2 Vdc at TP16? (Use TP1 as common.) | 26 | 25 |
| 25 | Check the Reference Circuit providing an input at U4-3 from the divider R4, R5, R6, R7 and VR2. Repair as required then resume at step 14. | | |
| 26 | Check from TP1 (analog ground) to U6-6 for 100 mV dc and for approximately 200 mV dc at U6-9. | | |
| 27 | Are both voltages present? | 29 | 28 |
| 28 | Check Q8, Q9, Q10, Q11, Q12, Q13, Q14, Q15 and their associated components. Repair as required then resume at step 14. | | |
| 29 | Check the RTD Input Module plus U5-1, Q19, Q21, Q22, and their associated components. Repair as required then resume at step 14. | | |
| 30 | Is the waveform at U5-7 as shown in Figure 4-4 (Magnitude & Polarity varies with the input signal)? | 34 | 31 |
| 31 | Check the operation of Q5, Q6, Q7, Q18, U5 and their associated components. If any defective components are found, repair as required and resume at step 13. If none are found proceed to the next step. | | |
| 32 | Connect TP2 and TP6 with a jumper to lock the instrument in the Auto Zero period. | | |
| 33 | Check U5, U3, U2, Q4 and their associated components. This circuit should now function as a closed loop amplifier. Repair as required. Remove the jumper between TP2 and TP6 and resume at step 14. | | |
| 34 | Does TP10 toggle between the high and low logic levels? | 36 | 35 |
| 35 | Check U1 and its associated components then resume at step 14. | | |
| 36 | Replace the microcomputer U9, then resume at step 14. | | |
| 37 | Troubleshooting of the 2180A is complete. Remove all test equipment, reconnect any cables removed and close the instrument. | | |

4-9

Table 4-5. Test Point Identification

| | |
|------|--|
| TP1 | Analog Common |
| TP2 | Digital Common ($-15V$) (refer to Analog Common) |
| TP3 | $+15V$ (refer to Analog Common) |
| TP4 | $+5V$ (refer to Analog Common) |
| TP6 | (U9-17) Trigger — S |
| TP7 | Buffer Amp out (U5-1) |
| TP8 | (U2-6) |
| TP9 | Gain Stage out (U3-6) |
| TP10 | Comparator out (U1-7) CM |
| TP11 | Δ 2 Settling Time Command |
| TP12 | INT 1 Integrate Command |
| TP13 | AZ Auto Zero Command |
| TP14 | DE— Read Command (Negative Input) |
| TP15 | DE+ Read Command (Positive Input) |
| TP16 | $6.2V (\pm 100 \mu V)$ |
| TP17 | $6.2V (\pm 100 \mu V)$ |

Section 5

List of Replaceable Parts

TABLE OF CONTENTS

| TITLE | TABLE | PAGE | FIGURE | PAGE |
|---|-------|------|--------|------|
| Final Assembly, 2180A Digital Thermometer | 5-1 | 5-3 | 5-1 | 5-4 |
| A1 Main PCB Assembly | 5-2 | 5-6 | 5-2 | 5-10 |
| A2 Display PCB Assembly | 5-3 | 5-11 | 5-3 | 5-11 |
| A3 RTD Input PCB Assembly | 5-4 | 5-12 | 5-4 | 5-12 |

5-1. INTRODUCTION

5-2. This section contains an illustrated parts breakdown of the instrument. A similar parts listing for each of the options will be found in Section 6. Components are listed alphanumerically by assembly. Both electrical and mechanical components are listed by reference designation. Each listed part is shown in an accompanying illustration.

5-3. Parts lists include the following information:

1. Reference Designation.
2. Description of each part.
3. FLUKE Stock Number.
4. Federal Supply Code for Manufacturers. (See Section 7 for Code-to-Name list.)
5. Manufacturer's Part Number.
6. Total Quantity per assembly or component.
7. Recommended Quantity: This entry indicates the recommended number of spare parts necessary to support one to five instruments for a period of two years. This list presumes an availability of common electronic parts at the maintenance site. For maintenance for one year or more at an isolated site, it is recommended that at least one of each assembly in the instrument be stocked. In the case of optional subassemblies, plug-ins, etc., that are not

always part of the instrument, or are deviations from the basic instrument model, the REC QTY column lists the recommended quantity of the item in that particular assembly.

5-4. HOW TO OBTAIN PARTS

5-5. Components may be ordered directly from the manufacturer by using the manufacturer's part number, or from the John Fluke Mfg. Co., Inc. factory or authorized representative by using the FLUKE STOCK NUMBER. In the event the part you order has been replaced by a new or improved part, the replacement will be accompanied by an explanatory note and installation instructions if necessary.

5-6. To ensure prompt and efficient handling of your order, include the following information.

1. Quantity.
2. FLUKE Stock Number.
3. Description.
4. Reference Designation.
5. Printed Circuit Board Part Number.
6. Instrument Model and Serial Number.

CAUTION



Indicated devices are subject to damage by static discharge.

Table 5-1. Final Assembly, 2180A Digital Thermometer

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|---------------------------------------|-----------------------|---------------------|-------------------------|------------|------------|------------|
| | FINAL ASSY, 2180A DIGITAL THERMOMETER | | | | | | |
| | FIGURE 5-1 | | | | | | |
| A1 | ⊗ MAIN PCB ASSEMBLY | 469312 | 89536 | 469312 | 1 | | |
| A2 | DISPLAY PCB ASSEMBLY | 464297 | 89536 | 464297 | 1 | | |
| A3 | RTD INPUT PCB ASSEMBLY | 464305 | 89536 | 464305 | 1 | | |
| F1 | FUSE, U.S. | | | | 1 | 5 | |
| | FOR 100/120V OPERATION | | | | | | |
| | SLO-BLO, 1/16 AMP | 163030 | 71400 | MDL1-16 | | | |
| | FOR 240V OPERATION | | | | | | |
| | SLO-BLO, 1/8 AMP | 166488 | 71400 | MDL1-8 | | | |
| F1 | FUSE, METRIC, 5 X 20 MM | | | | 1 | 5 | |
| | FOR 100/120V OPERATION | | | | | | |
| | SLO-BLO, 1/16 AMP | 467381 | 89536 | 467381 | | | |
| | FOR 200/240V OPERATION | | | | | | |
| | SLO-BLO, 1/8 AMP | 467233 | 89536 | 467233 | | | |
| F2 | FUSE, SLO-BLO, 3/4 AMP | 109256 | 71400 | MDL3-4 | 1 | 5 | |
| H1 | SCREW, PHP, 6-20 X 3/8 | 288266 | 89536 | 288266 | 1 | | |
| H2 | SCREW, PHP, 4-40 X 1/4 | 256156 | 89536 | 256156 | 3 | | |
| H3 | SCREW, PHP, 4-40 X 3/8 | 256164 | 89536 | 256164 | 2 | | |
| H4 | SCREW, FHP, 4-40 X 3/8 | 256024 | 89536 | 256024 | 1 | | |
| H5 | SCREW, FHP, 6-32 X 5/8 | 335158 | 89536 | 335158 | 2 | | |
| H6 | SCREW, FHP, 6-32 X 5/8 | 114876 | 89536 | 114876 | | | |
| MP1 | BASE, STD | 454702 | 89536 | 454702 | 1 | | |
| MP2 | GUARD, BASE | 464404 | 89536 | 464404 | 1 | | |
| MP3 | REAR PANEL | 464149 | 89536 | 464149 | 1 | | |
| MP4 | OUTPUT OPTION COVER | 464412 | 89536 | 464412 | 1 | | |
| MP5 | LIMITS COVER | 464156 | 89536 | 464156 | 1 | | |
| MP6 | LATCH | 467548 | 89536 | 467548 | 2 | | |
| MP7 | STAND, BAIL | 467555 | 89536 | 467555 | 1 | | |
| MP8 | FOOT, NON-SKID | 467571 | 89536 | 467571 | 4 | | |
| MP9 | FRONT PANEL | 472282 | 89536 | 472282 | 1 | | |
| MP10 | CALIBRATION COVER | 471490 | 89536 | 471490 | 1 | | |
| MP11 | DECAL, FRONT PANEL | 454629 | 89536 | 454629 | 1 | | |
| MP12 | DECAL, BASE SIDES | 473652 | 89536 | 473652 | 2 | | |
| MP13 | DECAL, REAR PANEL | 454645 | 89536 | 454645 | 1 | | |
| MP14 | DECAL, BOTTOM | 473637 | 89536 | 473637 | 1 | | |
| MP15 | CARD GUIDE | 464164 | 89536 | 464164 | 2 | | |
| MP16 | DECAL, RETAINER | 473645 | 89536 | 473645 | 2 | | |
| MP17 | HANDLE | 454751 | 89536 | 454751 | 1 | | |
| MP18 | RETAINER, HANDLE | 467563 | 89536 | 467563 | 2 | | |
| MP19 | GUARD, COVER, C-SIZE | 464115 | 89536 | 464115 | 1 | | |
| MP20 | COVER, C-SIZE | 454736 | 89536 | 454736 | 1 | | |
| MP21 | LUG, SOLDER | 151431 | 79963 | 329 | 1 | | |
| U9 | IC, MICROPROCESSOR | 455014 | 01295 | TMS9901N | 1 | | |
| W1 | CABLE ASSY | 475228 | 89536 | 475228 | 1 | | |
| W2 | POWER CORD (NOT SHOWN) | 343723 | 89536 | 343723 | 1 | | |
| XF1 | FUSEHOLDER, HIGH LEAD | 375188 | 89536 | 375188 | 2 | | |
| XF1-1 | FUSE CAP | 460238 | 89536 | 460238 | 2 | | |
| | FUSE CAP, METRIC | 461020 | 89536 | 461020 | 1 | | |
| | MANUAL, INSTRUCTION (NOT SHOWN) | 489211 | 89536 | 489211 | 1 | | |




Figure 5-1. Final Assembly, 2180A Digital Thermometer




Figure 5-1. Final Assembly, 2180A Digital Thermometer (cont)

Table 5-2. A1 Main PCB Assembly

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|---|-----------------------|---------------------|-------------------------|------------|------------|------------|
| A1 | ④ MAIN PCB ASSEMBLY (THERMOMETER PCB ASSEMBLY) FIGURE 5-2 (2180A-4001T) | 469312 | 89536 | 469312 | REF | | |
| C1 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | 16 | | |
| C2 | CAP, PLYPRLN, 0.47 UF +/-5%, 50V | 364042 | 84411 | JE78B | 1 | | |
| C3 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C4 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C5 | CAP, CER, 0.0012 UF +/-10%, 500V | 106732 | 71590 | CF122 | 1 | | |
| C6 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C8 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C9 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C10 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C11 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C12 | CAP, POLYCARB, 2.2 UF +/-10%, 100V | 306522 | 80031 | C280MCH/A2M2 | 1 | | |
| C13 | CAP, MICA 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | 6 | | |
| C14 | CAP, MICA, 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | REF | | |
| C15 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C16 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C17 | CAP, MICA, 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | REF | | |
| C18 | CAP, MICA, 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | REF | | |
| C19 | CAP, TA, 10 UF +/-20%, 35V | 417683 | 56289 | 196D106X0035PE4 | 2 | | |
| C20 | CAP, TA, 10 UF +/-20%, 35V | 417683 | 56289 | 196D106X0035PE4 | REF | | |
| C21 | CAP, MICA, 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | REF | | |
| C22 | CAP, MICA, 430 PF +/-5%, 500V | 177980 | 72136 | DM15F431J | REF | | |
| C23 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C24 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C25 | CAP, MICA, 5 PF +/-0.5%, 500V | 148577 | 72136 | DM15C050E | 1 | | |
| C26 | CAP, ELECT, 4000 UF -10/+100%, 25V | 370734 | 80031 | 3044TS043U025 | 1 | 1 | |
| C28 | CAP, TA, 39 UF +/-20%, 20V | 358234 | 56289 | 196D396X0020PE4 | 1 | | |
| C29 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C30 | CAP, TA, 22 UF +/-20%, 35V | 394775 | 56289 | 196D226X0035TE4 | 2 | | |
| C31 | CAP, TA, 22 UF +/-20%, 35V | 394775 | 56289 | 196D226X0035TE4 | REF | | |
| C32 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C33 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C35 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C36 | CAP, TA, 1 UF +/-20%, 35V | 161919 | 56289 | 196D105X0035JA1 | 1 | | |
| CR1 | DIODE, SI, HI-SPEED SWITCH | 203323 | D7910 | 1N4448 | 10 | 2 | |
| CR2 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR3 | RECTIFIER BRIDGE, 2 AMP | 392910 | 09423 | FB200 | 1 | 1 | |
| CR4 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR5 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR6 | DIODE, SI, RECTIFIER | 379412 | 04713 | 1N4933 | 2 | 1 | |
| CR7 | DIODE, SI, RECTIFIER | 379412 | 04713 | 1N4933 | REF | | |
| CR8 | DIODE, FET, CURRENT, REGULATOR | 348482 | 89536 | 348482 | 3 | 1 | |
| CR9 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR10 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR11 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR12 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR13 | DIODE, SI, RECTIFIER | 116111 | 05277 | 1N4817 | 1 | 1 | |
| CR14 | DIODE, FET, CURRENT, REGULATOR | 348482 | 89536 | 348482 | REF | | |
| CR15 | DIODE, FET, CURRENT, REGULATOR | 348482 | 89536 | 348482 | REF | | |

Table 5-2. A1 Main PCB Assembly (cont)


| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|------------------------------------|-----------------------|---------------------|-------------------------|------------|------------|------------|
| CR16 | DIODE, SI, MULTI-PELLET | 375477 | 09214 | MPD200 | 1 | | 1 |
| CR17 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR18 | DIODE, ZENER | 393579 | 04713 | 1N4567 | 1 | | 1 |
| CR19 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| H1 | SCREW, PHP, 4-40 X 1 1/2 | 156380 | 73734 | 19032 | 2 | | |
| H2 | SCREW, PHP, 4-40 X 1/2 | 152132 | 73734 | 19026 | 2 | | |
| H3 | SCREW, PHP, 4-40 X 3/8 | 152124 | 73734 | 19024 | 2 | | |
| H4 | LOCKWASHER, SPLIT, #4 | 110395 | 89536 | 110395 | 2 | | |
| H5 | WASHER, FLAT | 147728 | 73734 | 1402 | 2 | | |
| J1 | CONNECTOR, SOCKET, 4-POS. | 461756 | 00779 | 583773-1 | 1 | | |
| J2 | CONNECTOR, RECEPTACLE, 12-CONTACTS | 474007 | 05574 | 2VH6/1AKC15 | 1 | | |
| J3 | CONNECTOR, SOCKET, 6-POS. | 448209 | 00779 | 1-583773-3 | 1 | | |
| J4 | CONNECTOR, SOCKET, 7-POS. | 484030 | 00779 | 1-583773-4 | 1 | | |
| J5 | CONNECTOR, "D" SHELL, 25-CONTACTS | 461996 | 00779 | 206584-1 | 1 | | |
| J6 | CONNECTOR, SOCKET, 18-POS. | 435024 | 00779 | 583773-8 | 1 | | |
| K1 | RELAY, DRY REED | 357582 | 71707 | UF-40070 | 1 | | |
| MP1 | BUTTON, GREEN (TO S1) | 445197 | 89536 | 445197 | 1 | | |
| MP2 | BUTTON, LT. PUTTY GREY (TO S2) | 425900 | 89536 | 425900 | 1 | | |
| MP3 | SPACER, DISO-PAD (NOT SHOWN) | 296319 | 32559 | T0-8-06 | 2 | | |
| Q1 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | 9 | | 2 |
| Q2 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q3 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | 3 | | 1 |
| Q4 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | 8 | | 2 |
| Q5 | TRANSISTOR, 4 VOLT OFF FET | 429977 | 89536 | 429977 | 1 | | 1 |
| Q6 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q7 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q8 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q9 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q10 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q11 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q12 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q13 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q14 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q15 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q16 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q17 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q18 | TRANSISTOR, FET, DUAL N-CHANNEL | 419283 | 89536 | 419283 | 1 | | 1 |
| Q19 | TRANSISTOR, DUAL, FET | 476911 | 89536 | 476911 | 2 | | 1 |
| Q20 | TRANSISTOR, DUAL, FET | 476911 | 89536 | 476911 | REF | | |
| Q21 | TRANSISTOR, FET, N-CHANNEL | 376475 | 89536 | 376475 | REF | | |
| Q22 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | REF | | |
| Q23 | TRANSISTOR, SI, NPN, PWR | 477331 | 04713 | MDS01A | 2 | | 1 |
| Q24 | TRANSISTOR, SI, NPN, PWR | 477331 | 04713 | MDS01A | REF | | |
| Q25 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q26 | TRANSISTOR, SI, PNP, PWR | 473207 | 01295 | TIP30 | 1 | | 1 |
| Q27 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| R1 | RES, WW, 11.75K +/-0.5% | 474338 | 89536 | 474338 | 1 | | 1 |
| R2 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | 3 | | |
| R3 | RES, DEP. CAR, 1K +/-5%, 1/4W | 343426 | 80031 | CR251-4-5P1K | 1 | | |
| R4 | ZENER REFERENCE SET (VR2, R4, R5) | 377283 | 89536 | 377283 | 2 | | 1 |

Table 5-2. A1 Main PCB Assembly (cont)

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|--------------------------------------|-----------------------|---------------------|-------------------------|------------|------------|------------|
| R5 | ZENER REFERENCE SET (VR2, R4, R5) | 377283 | 89536 | 377283 | REF | | |
| R6 | RES, MTL. FILM, 61.9K +/-1%, 1/8W | 237230 | 91637 | CMF556192F | 2 | | |
| R7 | RES, VAR, 500 +/-10%, 1/2W | 325613 | 89536 | 325613 | 2 | 1 | |
| R8 | RES, DEP. CAR, 3.3K +/-5%, 1/4W | 348813 | 80031 | CR251-4-5P3K3 | 2 | | |
| R9 | RES, DEP. CAR, 43K +/-5%, 1/4W | 442418 | 80031 | CR251-4-5P43K | 1 | | |
| R10 | RES, DEP. CAR, 27K +/-5%, 1/4W | 441501 | 80031 | CR251-4-5P27K | 1 | | |
| R11 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | 6 | | |
| R12 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | REF | | |
| R13 | RES, MTL. FILM, 1K +/-1%, 1/8W | 168229 | 91637 | CMF551001F | 1 | | |
| R14 | RES, VAR, CER, 500K +/-10%, 1/2W | 474387 | 11236 | 360T-503A | 1 | 1 | |
| R15 | RES, MTL. FILM, 49.9 +/-1%, 1/8W | 305896 | 91637 | CMF554994F | 1 | | |
| R16 | RES, MTL. FILM, 169K +/-1%, 1/8W | 289454 | 91637 | CMF551693F | 1 | | |
| R17 | RES, MTL. FILM, 215K +/-1%, 1/8W | 289470 | 91637 | CMF552153F | 1 | | |
| R18 | RES, DEP. CAR, 12K +/-5%, 1/4W | 348847 | 80031 | CR251-4-5P12K | 1 | | |
| R19 | RES, MTL. FILM, 20K +/-1%, 1/8W | 291872 | 91637 | CMF552002F | 1 | | |
| R20 | RES, MTL. FILM, 2K +/-1%, 1/8W | 235226 | 91637 | CMF552210F | 1 | | |
| R21 | RES, MTL. FILM, 221 +/-1%, 1/8W | 340794 | 91637 | CMF552210F | 1 | | |
| R22 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | REF | | |
| R23 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | REF | | |
| R24 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | REF | | |
| R25 | RES, MTL. FILM, 10.02K +/-0.1%, 1/8W | 352245 | 89536 | 352245 | REF | | |
| R26 | RES, MTL. FILM, 100 +/-1%, 1/8W | 357400 | 91637 | CMF551000B | 1 | | |
| R27 | RES, VAR, 1K +/-20%, 1/2W | 267856 | 73578 | 190PC102B | 1 | 1 | |
| R28 | RES, VAR, 10K +/-20%, 1/2W | 267880 | 75378 | 190PC1038 | 2 | | |
| R29 | RES, VAR, 10K +/-20%, 1/2W | 267880 | 75378 | 190PC1038 | REF | | |
| R30 | RES, DEP. CAR, 47K +/-5%, 1/4W | 348896 | 80031 | CR251-4-5P47K | 2 | | |
| R31 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R32 | RES, DEP. CAR, 3.3K +/-5%, 1/4W | 348813 | 80031 | CR251-4-5P3K3 | REF | | |
| R33 | RES, COMP, 330 +/-5%, 1/4W | 147967 | 01121 | CB3315 | 2 | | |
| R35 | RES, DEP. CAR, 100 +/-5%, 1/4W | 348771 | 80031 | CR251-4-5P100E | 1 | | |
| R36 | RES, MTL. FILM, 9.09K +/-1%, 1/8W | 221663 | 91637 | CMF559091F | 1 | | |
| R37 | RES, MTL. FILM, 1.02K +/-1%, 1/8W | 223545 | 91637 | CMF551021F | 1 | | |
| R38 | RES, MTL. FILM, 4.23K +/-1%, 1/8W | 294819 | 91637 | CMF554321F | 1 | | |
| R39 | RES, MTL. FILM, 10K +/-1%, 1/8W | 168260 | 91637 | CMF551002F | 1 | | |
| R41 | RES, DEP. CAR, 47K +/-5%, 1/4W | 348896 | 80031 | CR251-4-5P47K | REF | | |
| R42 | RES, DEP. CAR, 5.1K +/-5%, 1/4W | 368712 | 80031 | CR251-4-5P5K1T | 1 | 1 | |
| R43 | ZENER REFERENCE SET (VR5, R43, R46) | 377283 | 89536 | 377283 | 2 | 1 | |
| R44 | RES, VAR, 500 +/-10%, 1/2W | 325613 | 89536 | 325613 | REF | | |
| R45 | RES, MTL. FILM, 61.9K +/-1%, 1/8W | 237230 | 91637 | CMF556192F | REF | | |
| R46 | ZENER REFERENCE SET (VR5, R43, R46) | 377283 | 89536 | 377283 | REF | | |
| R47 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R48 | RES, DEP. CAR, 39K +/-5%, 1/4W | 442400 | 80031 | CR251-4-5P39K | 1 | | |
| R49 | RES, MTL. FILM, 100K +/-1%, 1/8W | 248807 | 91637 | CMF551003F | 1 | | |
| R50 | RES, MTL. FILM, 64.9K +/-1%, 1/8W | 288530 | 91637 | CMF556492F | 1 | | |
| R51 | RES, MTL. FILM, 226K +/-1%, 1/8W | 320879 | 91637 | CMF552263F | 1 | | |
| R52 | RES, MTL. FILM, 309K +/-1%, 1/8W | 235283 | 91637 | CMF553093F | 1 | | |
| R53 | RES, COMP, 330 +/-5%, 1/4W | 147967 | 01121 | CB3315 | REF | | |
| S1/S2 | SWITCH ASSEMBLY | 483891 | 89536 | 483891 | 1 | | |
| S3 | SWITCH, SLIDE, DPDT | 234278 | 82389 | XW1649 | 2 | | |
| S4 | SWITCH, SLIDE, DPDT | 234278 | 82389 | XW1649 | REF | | |

Table 5-2. A1 Main PCB Assembly (cont)

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|--------------------------------------|-----------------------|---------------------|-------------------------|------------|------------|------------|
| T1 | TRANSFORMER, PWR | 464370 | 89536 | 464370 | 1 | | |
| T2 | TRANSFORMER, INVERTER | 461954 | 89536 | 461954 | 1 | | |
| TB1 | TERMINAL BLOCK | 479006 | 89536 | 479006 | 2 | | |
| TB2 | TERMINAL BLOCK | 479006 | 89536 | 479006 | REF | | |
| U1 | IC, VOLTAGE COMPARATOR | 352195 | 12040 | LM311CN | 1 | 1 | |
| U2 | IC, LINEAR, OP-AMP | 429837 | 12040 | LF356H | 1 | 1 | |
| U3 | IC, LINEAR, OP-AMP | 472779 | 12040 | LF356N | 2 | 1 | |
| U4 | IC, LINEAR, OP-AMP | 413740 | 12040 | LM307N | 2 | 1 | |
| U5 | IC, LINEAR, DUAL OP-AMP | 478032 | 04713 | MC4558NCP1 | 1 | 1 | |
| U6 | RES NETWORK | 448480 | 89536 | 448480 | 1 | 1 | |
| U7 | IC, LINEAR, OP-AMP | 472779 | 12040 | LF356N | REF | | |
| U8 | RES NETWORK, 47K | 413289 | 89536 | 413289 | 1 | 1 | |
| U10 | IC, LINEAR, OP-AMP | 418566 | 12040 | LM358N | 1 | 1 | |
| U11 | IC, LINEAR, NEG VOL REG | 413179 | 12040 | LM7915T | 1 | 1 | |
| U12 | IC, LINEAR, VOL REG, FXD | 413187 | 12040 | LM340T-15 | 1 | 1 | |
| U13 | ⊗ IC, C-MOS, HEX, OPEN DRAIN BUFFERS | 473389 | 12040 | MM74C906N | 1 | 1 | |
| U14 | RES NETWORK | 402644 | 89536 | 402644 | 1 | 1 | |
| U15 | IC, LINEAR, OP-AMP | 413740 | 12040 | LM307N | REF | | |
| U16 | IC, DUAL COMPARATOR | 478354 | 12040 | LM393N | 1 | 1 | |
| VR2 | ZENER REFERENCE SET (VR2, R4, R5) | 377283 | 89536 | 377283 | REF | | |
| VR3 | DIODE, ZENER | 186163 | 07910 | 1N974B | 2 | | |
| VR4 | DIODE, ZENER | 186163 | 07910 | 1N974B | REF | | |
| VR5 | ZENER REFERENCE SET (VR5, R43, R46) | 377283 | 89536 | 377283 | REF | | |
| XQ26 | HEATSINK (NOT SHOWN) | 428805 | 89536 | 428805 | 1 | | |
| XU4 | SOCKET, IC, 40-PIN (NOT SHOWN) | 418988 | 91506 | 340-AG39D | 1 | | |
| Y1 | CRYSTAL, QUARTZ | 474072 | 89536 | 474072 | 1 | 1 | |



* See U9 on Final Assembly

Figure 5-2. A1 Main PCB Assembly

Table 5-3. A2 Display PCB Assembly

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|--|-----------------------|---------------------|-------------------------|------------|------------|------------|
| A2 | DISPLAY PCB ASSEMBLY FIGURE 5-3 (2180A-4002T) | 464297 | 89536 | 464297 | REF | | |
| DS1 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | 7 | 2 | |
| DS2 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| DS3 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| DS4 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| DS5 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| DS6 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| DS7 | DIODE, LED DISPLAY, 7-SEGMENT, RED | 418012 | 28480 | 5082-7651 | REF | | |
| P6 | CABLE, FLAT, 18 POS, 6-INCH | 474411 | 00779 | 1-86947-1 | 1 | | |
| Q1 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | 13 | 1 | |
| Q2 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q3 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q4 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q5 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q6 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q7 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q8 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q9 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q10 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q11 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q12 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| Q13 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | REF | | |
| R1 | RES, DEP. CAR, 100 +/-5%, 1/4W | 348771 | 80031 | CR251-4-5P100E | 1 | | |
| R3 | RES, DEP. CAR, 1 +/-5%, 1/4W | 357665 | 80031 | CR251-4-5P1E | 1 | | |
| U1 | IC, LIN, NPN, 5 TRANSISTOR ARRAY | 418574 | 02735 | CA3083E | 1 | 1 | |
| U2 | RESISTOR NETWORK, 1K | 407445 | 89536 | 407445 | 1 | 1 | |
| U3 | RESISTOR NETWORK, 82 OHM | 478859 | 89536 | 478859 | 1 | 1 | |




Figure 5-3. A2 Display PCB Assembly

Table 5-4. A3 RTD Input PCB Assembly

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CODE |
|------------|--|-----------------------|---------------------|-------------------------|------------|------------|-------------|
| A3 | RTD INPUT PCB ASSEMBLY FIGURE 5-4 (2180A-4003T) | 469304 | 89536 | 469304 | REF | | |
| C1 | CAP, POLYCARB, 2.2 UF +/-10%, 100V | 306522 | 80031 | C280MCH/A2M2 | 1 | | |
| H1 | WASHER, FIBER #4 | 110890 | 12443 | 2508 | 2 | | |
| H2 | LOCKWASHER, SPLIT, #4 | 110395 | 89536 | 110395 | 2 | | |
| H3 | P-NUT, BROACHING, 4-40 | 380196 | 24347 | KF2-440 | 2 | | |
| H4 | SCREW, PHP, 4-40 X 3/8 | 403782 | 89536 | 403782 | 2 | | |
| R1 | RES, COMP, 47K +/-5%, 1W | 150219 | 01121 | GB4735 | 1 | | |
| R2 | RES, VAR, 500 +/-20%, 1/2W | 267849 | 75378 | 190PC501B | 1 | 1 | |
| S1 | SWITCH MODULE, DUAL-IN-LINE, SPST | 408559 | 00079 | 435166-2 | 1 | | |
| S2-1 | SWITCH, TOP HALF | 454835 | 10389 | 24-420-020 | 2 | | |
| S2-2 | SWITCH, BOTTOM HALF | 454777 | 10389 | 24-410-020 | 2 | | |
| S3-1 | SWITCH, TOP HALF | 454835 | 10389 | 24-420-020 | REF | | |
| S3-2 | SWITCH, BOTTOM HALF | 454777 | 10389 | 24-410-020 | REF | | |
| TB1 | TERMINAL BLOCK | 461475 | 89536 | 461475 | 1 | | |




Figure 5-4. A3 RTD Input PCB Assembly

Section 6

Option & Accessory Information

TABLE OF CONTENTS

| OPTION/ MODEL NO. | DESCRIPTION | PAGE |
|----------------------|--|-------|
| ACCESSORIES | | |
| Y2000 | RTD Multipoint Selector | 600-1 |
| Y2002 | Alarms Output | 600-1 |
| Y2009 | Battery Pack, 12V Rechargeable | 600-2 |
| Y2022 | Divider, Thermometer Calibration | 600-2 |
| | Rack Panels | 600-2 |
| | Rack Mounts | 600-2 |
| Y2023 | Accessory Case | 600-2 |
| Y2024 | Power Cord, 3-Way | 600-2 |
| Y2026 | Cable Output Unit, RS232C | 600-2 |
| OPTIONS | | |
| 21X0-002 | Output | 602-1 |
| 21X0-006 | Limits | 606-1 |

6-1. INTRODUCTION

6-2. This section of the manual contains information on the accessories and options available for the 2180A Digital Thermometer.

6-3. ACCESSORY INFORMATION

6-4. The portion of this section dealing with accessories contains the details of all accessories available for the 2180A.

6-5. OPTION INFORMATION

6-6. Each of the options available for the 2180A are described separately in a subsection identified with the option name and number. The option description contains the information on the operating instructions and maintenance not covered in the main body of the text, plus a complete list of replaceable parts for the option.

Accessories

600-1. GENERAL

600-2. Table 600-1 contains a list of the accessories available for use with the 2180A Digital Thermometer. The following paragraphs contain information on the types of accessories. Instructions for use accompany each accessory. In all cases order using the accessory number listed.

600-3. RTD MULTIPOINT SELECTOR, (Y2000)

600-4. The Multipoint Selector allows the operator to manually select and monitor the one of up to ten

channels; two separate thermocouple types (maximum of five each if two types used) may be connected to the unit. Up to ten multipoint selectors may be connected in series.

600-5. ALARMS OUTPUT (Y2002)

600-6. The Alarms Output accessory provides controls to permit up to four separate limits settings, so that there is an operator indication at more than one temperature point. The four thumbwheel controls allow the simultaneous setting of a high and low, in any combination.

Table 600-1. 2180A Accessories

| ACCESSORY | DESCRIPTION |
|-----------|--|
| Y2000 | Multipoint Selector, RTD |
| Y2002 | Alarms Output |
| Y2009 | Battery Pack, 12V Rechargeable |
| Y2010 | Rack Panel PTI, single, A size (for Y2000) |
| Y2011 | Rack Panel PTI, double, A size (for Y2000) |
| Y2012 | Rack Panel PTI, single, B size (for Y2009) |
| Y2013 | Rack Panel PTI, double, B size (for Y2009) |
| Y2014 | Rack Panel PTI, single, C size (for 2180A and Y2002) |
| Y2015 | Rack Panel PTI, double, C size (for 2180A and Y2002) |
| Y2018 | Panel Mount PTI-DIN, A size (for Y2000) |
| Y2019 | Panel Mount PTI-DIN, B size (for Y2009) |
| Y2020 | Panel Mount PTI-DIN, C size (for 2180A and Y2002) |
| Y2022 | Divider, Thermometer Calibrator |
| Y2023 | Accessory Case |
| Y2024 | Power Cord, 3-way |
| Y2025 | Probe, RTD, 100 Ω , 385 Pt |
| Y2026 | Cable, Output Unit, RS232C |

**600-7. BATTERY PACK, 12V
RECHARGEABLE (Y2009)**

600-8. The rechargeable battery pack provides the 2180A and its accessories with portability. The output is +12V dc at a maximum of 750 mA for a total of 2.2 ampere-hours.

**600-9. DIVIDER, THERMOMETER
CALIBRATION (Y2022)**

600-10. The device is a preset 100 to 1 divider to provide the precision millivolt outputs from a DC Calibrator required for calibration. The device wires into the RTD Input PCB in place of the RTD Probe during calibration. Refer to the Y2022 Instruction manual for the schematic and additional information.

600-11. RACK PANELS

600-12. Available are rack mounting panels in three sizes and two types for the standard 19-inch electronics equipment racks. The "A" size for the Multipoint Selector is available in panels that will accommodate either one or two instruments. The "B" size panel for the Calibrator and/or Battery Pack is also available for single or double instruments, as is the "C" size used for the 2180A Thermometer and the Alarms Output.

600-13. PANEL MOUNTS

600-14. The panel mounts provide the hardware to install the instrument in any panel in which a hole the size

of the instrument front panel can be cut. It is available for the three instrument sizes required, "A", "B", and "C".

600-15. ACCESSORY CASE (Y2023)

600-16. The accessory case is a "C" sized PTI case which contains a storage drawer. This provides the operator that has several instruments in a stacked group, storage space for test equipment and spare and/or alternate thermocouple probes and wires.

600-17. POWER CORD, 3-WAY (Y2024)

600-18. This accessory is a specially constructed power cord with three female and one male connectors that allow the operator to connect up to "C" size or smaller PTI instruments with one line power cord.

**600-19. CABLE OUTPUT UNITS,
RS232C (Y2026)**

600-20. The Y2026 is an interface device which allows direct mating between any RS232C device and the -002 Output Option. The Y2026 consists of two 25-pin connectors, one 36-pin connector and an accessory cable to provide connection between the 36-pin output and the -002 Output Option. It will be necessary for the user to provide the cable between the 25-pin outputs and the RS232C devices.

Option -002 Output

602-1. INTRODUCTION

602-2. The 21X0-002 Option is an analog and digital output unit. It provides either the 2180A or 2190A Model Digital Thermometers with a recording output for a permanent record when required. The option may be ordered with the unit for factory installation or is available as a kit for installation in the field.

602-3. The analog output is available on the rear panel at two flush banana jacks with the polarity indicated. The output is a scaled voltage source of 1 millivolt per degree of temperature, regardless of the temperature scale selected, with the polarity as read on the display. For example; a reading of 251°F would output +251 mV dc; 97.3°C would output +97.3 mV dc; and -31.9°F would output -31.9 mV dc.

602-4. The digital output is a clocked message that can be in two different formats to match the requirement of the customer's equipment. Output on one set of lines is a bit-parallel, byte-serial message format designed for printer interface. Also available are the standard EIA RS232C and current loop bit-serial outputs. Both formats provide the channel number, the current reading displayed, and any out of range or open thermocouple information.

602-5. SPECIFICATIONS

602-6. Specifications for the Output Option, 21X0-002, are as listed in Table 602-1.

602-7. INSTALLATION

602-8. Options for field installation can be installed using the following procedure:

1. Disconnect the thermometer from all input power sources.

Table 602-1. Specifications

Analog Output

Type: Linearized and isolated.

Voltage: 1.0 mV/°C or °F from -425 mV to 4.5V, 5 mA max.

Temperature Coefficient: 200 ppm/°C from 25°C.

Noise: ≤ 100 uV at 100 Hz bandwidth.

Accuracy: ±0.1% of reading ±1 mV.

Zero Drift: 200 uV/°C from 25°C.

Warm-Up Time: 5 minutes, to rated accuracy.

Digital Output

Types: Three, E.I.A. Standard RS-232-C Type 2, TTY current loop, and parallel ASCII.

Connector: 36-pin AMP "Champ".

Serial Baud Rates: 110, 150, 300, 600, 1200, 2400, 4800, 9600, switch-selectable.

RS-232-C Signals: Transmitted Data, Request to Send, Clear to Send, Data Set Ready, Signal Common.

Parallel ASCII Signals: Data 8 lines, instrument address 3 lines, Address Valid, Data Valid, Acknowledge, ground, +5V.

Parallel ASCII Data Rate: Three readings per second.

Parallel ASCII Interface: Plug-to-plug compatible with similar Fluke equipment.

TTY Current Loop Signals: Source and controlled sink, 20 mA.

Out-of-Limit Signal: Exclamation point transmitted with Option 21X0-006 only; not with Y2002.

Battery Operation: 4 to 5 hours typical at 25°C on fully charged Y2003 or Y2009.

2. Remove the screws on the bottom of the case that fasten the top and bottom of the PTI case together and remove the top half of the case.

3. Remove the center mounting screw that attaches the Main PCB to the case and lift the pcb clear of the case.

4. Attach the four spacers supplied with the option to the component side of the pcb in the holes forming a rough rectangular pattern (do not use the fifth hole on the corner, next to U1).

Table 602-2. Switch Selection

| SWITCH POSITION | SWITCH BANK | | | | S1 BAUD RATE | S2 FUNCTION | S3 ADDRESS |
|-----------------|-------------|-----|-----|-----|--------------|-------------|------------|
| | 1 | 2 | 3 | 4 | | | |
| 0 | OFF | OFF | OFF | OFF | 110 | OPERATE | ADR 0 |
| 1 | ON | OFF | OFF | OFF | 150 | CAL 1 | ADR 1 |
| 2 | OFF | ON | OFF | OFF | 300 | CAL 2 | ADR 2 |
| 3 | ON | ON | OFF | OFF | 600 | CAL 3 | ADR 3 |
| 4 | OFF | OFF | ON | OFF | 1200 | CAL 4 | ADR 4 |
| 5 | ON | OFF | ON | OFF | 2400 | CAL 1 | ADR 5 |
| 6 | OFF | ON | ON | OFF | 4800 | CAL 2 | ADR 6 |
| 7 | ON | ON | ON | OFF | 9600 | CAL 3 | ADR 7 |
| 8 | OFF | OFF | OFF | ON | 110 | PLOT 1 | ADR 8 |
| 9 | ON | OFF | OFF | ON | 150 | PLOT 2 | ADR 9 |

5. Reinstall the Main PCB in the bottom half of the case.

6. On the Output Unit PCB use Table 602-2 and S1 to select the desired BAUD rate, select position 0 on the Function switch S2, and select the PTI Bus Address using S3.

7. Connect the Output Unit cables to the connectors on the Main PCB.

8. Attach the Output Unit PCB to the spacers, component side down, and the connector to the rear panel access port.

9. Replace the PTI cover on the instrument and reconnect the input power sources, if required, at this time.

Table 602-3. Digital Output Connector Pin-Out

| PIN NO. | FUNCTION | MNEMONIC | USE |
|---------|------------------|----------|-----------------|
| 1 | Address Valid | ADRVAL | PTI Bus |
| 2 | Data Valid | DATVAL | PTI Bus |
| 3-6 | Printer Address | A0-A3 | PTI Bus |
| 7 | Acknowledge | ACK | PTI Bus |
| 8 | Not Used | | |
| 9-16 | Data | D0-D7 | PTI Bus |
| 17 | Ground | | PTI Bus |
| 18 | +5 Volts | | PTI Bus |
| 19-24 | Not Used | | |
| 30 | Transmitted Data | | RS232 Interface |
| 31 | Request to send | | RS232 Interface |
| 32 | Clear to send | | RS232 Interface |
| 33 | Data set ready | | RS232 Interface |
| 34 | Signal Common | | RS232 Interface |
| 35 | S0+ | | Current Loop |
| 36 | S0— | | Current Loop |

602-9. OUTPUT CONNECTIONS

602-10. All connections between the Output Unit Option and external instruments are made using the rear panel connectors previously described. The analog output is from standard banana jacks. The digital output female connector has a mating male connector accompanying the option. This allows the customer to custom make a cable between the thermometer output option and the receiving device. Table 602-3, is the pin-out data for the digital output connector.

NOTE

Standard RS232C signals are output on 25-pins, the connector on the -002 Output Option is 36-pins, therefore, the user must either hardwire the connection between the -002 Output Option or order the Y2026, Cable Adapter.

602-11. OPERATION

602-12. Once the Output Unit Option is installed, the only operator functions deal with the connection of external equipment to the analog or digital output connectors.

602-13. The positive and negative analog terminals have available a dc millivolt output with the same polarity, and proportional to the temperature displayed. For example, if the thermometer displayed +105.7°F the analog output would be +105.7 mV dc and for -53.1°C the output would be -53.1 mV dc. The full resolution of the temperature display (tenths or hundredths of degrees) is reflected on the output.

602-14. The digital output can be connected to a printer or any device accepting parallel ASCII data, or to a device accepting RS232C or Current Loop signals. Connections for all three types of signals are available simultaneously on the 36-pin output connector previously described.

602-15. THEORY OF OPERATION

602-16. The Output Unit Option converts the temperature displayed by the output into a format usable by the customer's equipment. The output may be available as a scaled analog voltage or as formatted parallel and serial ASCII digital output. The following paragraphs describe operation of the Accessory Bus that handles communication between the instrument and the options, the analog output circuitry and the digital output circuitry. Refer to the schematic in Section 8 during the following discussion.

602-17. Accessory Bus Communication

602-18. The option communicates with the thermometer on the clocked bit-serial accessory bus. Transmitted on the bus are channel number, range, conversion type, scale, and digits of the temperature reading. When the WRTADR line is held low, DCLK clocks the address of the Output Unit (4), followed by the thermometer data to the microprocessor on the DATA line. Once into the microprocessor, the data is converted, formatted, and output to the analog and digital output circuitry.

602-19. Analog Circuitry

602-20. The temperature reading received by the microcomputer is used to generate an integrate control signal, the length of which is proportional to the magnitude of the temperature reading. This signal is used to turn on (close) the FET switches Q6 and U12-2, open the switches U11-2, U11-3 and U12-3, and set the output polarity with switches at U12-9 and U12-10. (U12-9 is closed when a negative reading is being processed and U12-10 when a positive signal is being processed.)

602-21. With Q6 on, the capacitor C1 is charged linearly to a voltage proportional to the length of the control signal at Q6. When Q6 has been on for the time required, it is opened, and switch U11-13 is closed, so the output of U13-8 can be sampled and held on C2. After 10 ms switch U11-3 opens and switch U11-11 closes to zero the integrate capacitor C1, until the next conversion cycle.

602-22. The voltage held on C2 is buffered by U13-7. U13-14 either passes the voltage directly to the output stage, or amplifies it as controlled by switches U12-9 and U12-10, which alternate states to set the polarity. The output stage at U13-1 has a constant gain of -1.

602-23. Digital Output Circuitry

602-24. The thermometer reading transmitted on the accessory bus every 333 ms is formatted by the microcomputer and, if requested, made available on the PTI Bus, RS232C, and current loop outputs. Refer to the schematics in Section 8 during the following description.

602-25. Eight data, four address, a data valid, an address valid, and an acknowledge line are used by the PTI Bus Interface. The external device requests data from the Output Unit by applying the preselected address to the address lines. The address is preselected by setting switch S3 to the desired number (0-9). When the proper address is decoded the tri-state output buffers (U8 and U9) are enabled, and the microcomputer and external device notified that the Output Unit has a valid address. When the conversion process is complete, the microcomputer applies the first character of the formatted data to the output lines and pulls the DATVAL line low. The external device reads the data and pulls the ACK line low, causing the Output Unit to reply with a new character. The process is repeated until data transfer is complete. The message formats are shown in Figure 602-1.

602-26. After transfer to the printer lines is complete, the microcomputer checks the DATA SET READY and CLEAR TO SEND lines from the RS232C Interface. If both lines are high, the same message as was output on the print lines is output on the RS232C and current loop lines in a bit-serial format. Since the thermometer cycle rate of 333 ms is shorter than the time required to output data at BAUD rate of 1200 and less, a message is not transmitted during every instrument cycle.

602-27. CALIBRATION

602-28. Analog circuitry in the option should be calibrated every 90 days or after any repair of the unit. The procedure following assumes that power is supplied to the unit and that a Digital Voltmeter capable of reading 10 μ V on the 1 volt, or equivalent range, i.e., a Fluke Model 8800A, is available.

1. Remove power from the instrument.
2. Remove the top cover from the thermometer.
3. Remove the screws attaching the option pcb to the Main PCB.
4. Leaving the interconnect cables connected, turn the option pcb to the right, while facing the instrument, exposing the component side and making the switches and adjustment accessible.

| | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | 1 | 2 | 2 | 3 | 4 | 4 | 4 | 4 | 4 | 4 | 5 | 5 | 6 | 7 | 7 | 8 | 9 | * |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

- 1 Two digit channel number
- 2 Two blanks
- 3 Sign — plus or minus
- 4 Five Digit Numeric with a decimal point for either tanths or hundreds
- 5 Two character temperatura scale. Either °C or °F on PTI Bus and either blank C or blank F on RS 232C, the degrae symbol (°) is transmitted to the printer as a "d".
- 6 Character "I" when preset limits are exceeded. Ona blank if signal within limits
- 7 Two character display — "OL" for overload, "OC" for open circuit or open thermocouple or two blanks if operating normally
- 8 Carriage return
- 9 Line Feed

NOTE

This eighteen character ASCII coded message can be sent as; ASCII parallel, RS232C, or Current Loop.

*Each block represents one ASCII character. The parity bit is always sent as zero.

Figure 602-1. Message Format

5. Connect the DMM to the Analog Output Connector.
6. Apply power to the instrument and allow if to warm-up for a minimum of 5 minutes.
7. Set the FUNCTION switch (S2) to position 1 (CAL 1).
8. Adjust R26 for an output of 0 ± 0.1 mV dc.
9. Set the FUNCTION switch to position 2 (CAL 2).
10. Adjust R26 for an output of 0 ± 0.1 mV dc.
11. Set FUNCTION switch to position 3 (CAL 3).
12. Adjust R11 for an output of $-10V \pm 1$ mV dc.
13. Set FUNCTION switch to position 4 (CAL 4).

14. Adjust R19 for an output of $+10V \pm 1$ mV dc.

15. Remove power and the test DMM, then reinstall the option pcb on the Main PCB and the top cover on the instrument.

602-29. TROUBLESHOOTING

602-30. Troubleshooting for the 2180A Option -002, Output Unit, consists of the tabular flow chart in Table 602-4. When a step on the flow chart is completed, check for a decision transfer. If no decision is required, perform the next step of the table in sequence.

602-31. LIST OF REPLACEABLE PARTS

602-32. Table 602-5 is a list of replaceable parts for the Output Option. Refer to Section 5 for an explanation of the columnar entries.

Table 602-4. Output Option Troubleshooting

| STEP NO. | ACTION | Go to the step number given for correct response | |
|----------|--|--|----|
| | | YES | NO |
| | <p style="text-align: center;">NOTE</p> <p style="text-align: center;"><i>These tests are based on the assumption that the 2180A/2190A has been thoroughly checked out and is free of troubles prior to beginning the test of the Output Option -002.</i></p> | | |
| 1 | Obtain a reading on the 2190A (the input can be shorted for a display of approximately the ambient temperature). | | |
| 2 | Is the Output option's analog output equal to the 1 mV per degree specified? | 16 | 3 |
| 3 | From pin 20 (common isolated) on U7 is there +5 volts to pin 40 of U7, +15 volts to pin 4 of U13, and -15 volts to pin 11 of U13? | 5 | 4 |
| 4 | Check for a 12V dc input at P1 pins 1 and 4, an ≈ 20 kHz squarewave from T1 pin 8 to pins 7 and 9, $>5.5V$ at the emitter of O12, $>17.5V$ at the input of U19, and $<17.5V$ at the input of U20. Repair as required then resume at step 1. | | |
| 5 | Are the signals at pins 24, 25, and 38 of U7 toggling (vary between a logic high and logic low)? | 7 | 6 |
| 6 | Check the input, cabling and U1 if all signals are absent. Check the individual line's components if one is absent. Repair as required then resume at step 1. | | |
| 7 | Are the signals at pins 10 through 15 of U7 toggling? | 9 | 8 |
| 8 | Check U7 and its clock input from Y1 (4 MHz and opposite in phase from common to pin 1 and 2). Repair as required then resume at step 1. | | |
| 9 | Are the following signals on U6 as stated: pins 5 and 11 toggling; pins 1 and 3 opposite, and reverse when the output sign is changed; pin 13 low except in CAL 1 position; and pin 9 varying with the length of charge time? | 11 | 10 |
| 10 | Check U5 and U6. Repair as required then resume at step 1. | | |
| 11 | Is the signal at the gate of FET switch Q6 toggling between common and -15V? | 13 | 12 |
| 12 | Check Q14, CR17 and their associated components. Repair as required then resume at step 1. | | |
| 13 | Perform the Output Option Calibration procedure. | | |
| 14 | Are all points adjustable within the stated tolerance? | 16 | 15 |
| 15 | Check the components associated with each adjustment. Since the ICs U11, U12, and U13 are multi-parts units they effect all circuits. Repair as required then resume at step 1. | | |
| 16 | Obtain a reading and vary the BAUD rate selection switch through its range while observing the output at each BAUD rate setting. | | |
| 17 | Is the data transmitted correctly at all BAUD rates? | 34 | 18 |
| 18 | Is the data transmitted correctly at one or more BAUD rates? | 19 | 20 |
| 19 | Check the BAUD rate selection switch S1. Repair as required then resume at step 16. | | |
| 20 | Are CLEAR TO SEND (CTS) and DATA SET READY (DSR) at U7-8 and U7-9 respectively at a logic low? | 22 | 21 |

Table 602-4. Output Option Troubleshooting (cont)

| STEP NO. | ACTION | Go to the step number given for correct response | |
|----------|---|--|----|
| | | YES | NO |
| | <p style="text-align: center;">NOTE</p> <p style="text-align: center;"><i>This is with a receiving device attached. If not attached tie pins 32 and 33 of J7 high to simulate an accepting device.</i></p> | | |
| 21 | Check the interface from the RS232 device, Q8, Q9 and their associated components. Repair as required then resume at step 16. | | |
| 22 | Is the signal at pin 3 of U7 toggling? | 24 | 23 |
| 23 | Check U7. Repair as required then resume at step 16. | | |
| 24 | Does the signal at pin 30 of J7 in reference to pin 34 of J7 toggle while a message is transmitted? | 26 | 25 |
| 25 | Check Q4, Q5, U18, and their associated components. Repair as required then resume at step 16. | | |
| 26 | Is the output data available on the PTI Bus? | 26 | 27 |
| 27 | Is the signal at U10-6 low? | 29 | 28 |
| 28 | Verify that the input address and address switch setting are the same. Check the address decoding circuit in U10, U16, U17, U15, U21, S3 and their associated components. Repair as required then resume at step 26. | | |
| 29 | Is <u>ADRV</u> low at pin 1 of J7? | 31 | 30 |
| 30 | Check the tri-state buffer U8 and it's enabling signal. Repair as required then resume at step 26. | | |
| 31 | Do the <u>DATVAL</u> , <u>ACK</u> and D0 through D7 signals on pins 2, 7, and 9 through 16 of J7 respectively toggle? | 33 | 32 |
| 32 | Check the tri-state buffers U8 and U9, the microprocessor U7, and the <u>ACK</u> input from the PTI Bus. Since the RS232 output has already been checked, the input to U7 has been verified. Repair as required then resume at step 26. | | |
| 33 | Check the connector, interconnecting cable and receiving device. Repair as required then resume at step 26. | | |
| 34 | Troubleshooting of the Output Option is complete. | | |

Table 602-5. A4 Output Option PCB Assembly

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|--|-----------------------|---------------------|-------------------------|------------|------------|------------|
| 002 | ② OUTPUT OPTION-002 PCB ASSEMBLY FIGURE 602-2 (2180A-4020T) | -002 | 89536 | 2190A-002 | REF | | |
| C1 | CAP, POLYSTRN, 0.56 UF +/-10%, 100V | 284851 | 89536 | 284851 | 1 | | |
| C2 | CAP, POLYPRPLN, 0.47 UF +/-10%, 50V | 363085 | 89536 | 363085 | 1 | | |
| C3 | CAP, CER, 0.22 UF +/-20%, 50V | 309849 | 71590 | CW30C224K | 1 | | |
| C4 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | 8 | | |
| C5 | CAP, TA, 39 UF +/-20%, 20V | 358234 | 56289 | 196D396X0020PE4 | 1 | | |
| C6 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C7 | CAP, TA, 22 UF +/-20%, 35V | 394775 | 56289 | 196D226X0035TE4 | 2 | | |
| C8 | CAP, TA, 22 UF +/-20%, 35V | 394775 | 56289 | 196D226X0035TE4 | REF | | |
| C9 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C10 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C11 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C12 | CAP, TA, 1 UF +/-20%, 35V | 161919 | 56289 | 196105X0035JA1 | 2 | | |
| C13 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C14 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C15 | CAP, TA, 10 UF +/-20%, 20V | 330662 | 56289 | 196D106X0020KA1 | REF | | |
| C16 | CAP, TA, 1 UF +/-20%, 35V | 161919 | 56289 | 196105X0035JA1 | REF | | |
| C17 | CAP, CER, 0.025 UF +/-20%, 100V | 168435 | 56289 | C023B10H253M | 1 | | |
| CR1 | DIODE, ZENER | 393579 | 07910 | 1N4567 | 1 | 1 | |
| CR3 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | 10 | 2 | |
| CR4 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR5 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR6 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR7 | DIODE, ZENER, 36V | 186163 | 07910 | 1N974B | 2 | 1 | |
| CR8 | DIODE, ZENER, 36V | 186163 | 07910 | 1N974B | REF | | |
| CR9 | DIODE, SI, RECTIFIER | 379412 | 04713 | 1N4933 | 2 | 1 | |
| CR10 | DIODE, SI, RECTIFIER | 379412 | 04713 | 1N4933 | REF | | |
| CR11 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR12 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR13 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR14 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR15 | DIODE, ZENER, 6.2V | 325811 | 07910 | 1N752A | 1 | 1 | |
| CR16 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| CR17 | DIODE, SI, HI-SPEED SWITCH | 203323 | 07910 | 1N4448 | REF | | |
| H1 | SCREW, PHP, 4-40 X 3/8 (NOT SHOWN) | 152124 | 73734 | 19024 | 2 | | |
| H2 | LOCKWASHER (NOT SHOWN) | 110395 | 89536 | 110395 | 2 | | |
| H3 | NUT, HEXAGON (NOT SHOWN) | 147611 | 89536 | 147611 | 2 | | |
| H4 | HARDWARE KIT (FOR J7) | 435750 | 00779 | 552565-1 | 1 | | |
| J7 | CONNECTOR | 414409 | 00779 | 552241-1 | 1 | | |
| J8 | JACK, INPUT | 492314 | 89536 | 492314 | 2 | | |
| P1 | CABLE, JUMPER | 474148 | 00779 | 86942-3 | 1 | | |
| P3 | CABLE, JUMPER | 474155 | 00779 | 86942-5 | 1 | | |
| Q1 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | 8 | 2 | |
| Q2 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q3 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q4 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q5 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q6 | TRANSISTOR, FET, N-CHANNEL | 429977 | 89536 | 429977 | 1 | 1 | |
| Q7 | TRANSISTOR, FET, N-CHANNEL | 343830 | 89536 | 343830 | 1 | 1 | |

Table 602-5. A4 Output Option PCB Assembly (cont)

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|-----------------------------------|-----------------------|---------------------|-------------------------|------------|------------|------------|
| Q8 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q9 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q10 | TRANSISTOR, SI, NPN, PWR | 477331 | 04713 | MDS01A | REF | | |
| Q11 | TRANSISTOR, SI, NPN, PWR | 477331 | 04713 | MDS01A | REF | | |
| Q12 | TRANSISTOR, SI, PNP, PWR | 473207 | 01295 | T1P30 | 1 | 1 | |
| Q13 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q14 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | 1 | 1 | |
| R1 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | 12 | | |
| R2 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R3 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R4 | RES, DEP. CAR, 220K +/-5%, 1/4W | 348953 | 80031 | CR251-4-5P220K | 3 | | |
| R5 | RES, DEP. CAR, 2.2K +/-5%, 1/4W | 343400 | 80031 | CR251-4-5P2K2 | 4 | | |
| R6 | RES, DEP. CAR, 220K +/-5%, 1/4W | 348953 | 80031 | CR251-4-5P220K | REF | | |
| R7 | RES, DEP. CAR, 2.2K +/-5%, 1/4W | 343400 | 80031 | CR251-4-5P2K2 | REF | | |
| R8 | RES, DEP. CAR, 220K +/-5%, 1/4W | 348953 | 80031 | CR251-4-5P220K | REF | | |
| R9 | RES, DEP. CAR, 2.2K +/-5%, 1/4W | 343400 | 80031 | CR251-4-5P2K2 | REF | | |
| R10 | RES, MTL. FILM, 16.9K +/-1%, 1/8W | 267146 | 91637 | CMF551692F | 1 | | |
| R11 | RES, VAR, 25K +/-20%, 1/2W | 285213 | 75378 | 190PC2538 | 1 | 1 | |
| R12 | RES, MTL. FILM, 102K +/-1%, 1/8W | 291286 | 91637 | CMF551023F | 1 | | |
| R13 | RES, MTL. FILM, 2K +/-1%, 1/8W | 235226 | 91637 | CMF552001F | 1 | | |
| R14 | RES, MTL. FILM, 750K +/-1%, 1/8W | 271361 | 91637 | CMF55751F | 2 | | |
| R15 | RES, VAR, 100K +/-20%, 1/2W | 268581 | 75378 | 190PC104B | 2 | 1 | |
| R16 | RES, MTL. FILM, 60.4K +/-1%, 1/8W | 291419 | 91637 | CMF556042F | 2 | | |
| R17 | RES, MTL. FILM, 60.4K +/-1%, 1/8W | 291419 | 91637 | CMF556042F | REF | | |
| R18 | RES, MTL. FILM, 3.92K +/-1%, 1/8W | 294801 | 91637 | CMF553921F | 2 | | |
| R19 | RES, VAR, 100 +/-10%, 1/2W | 275735 | 11236 | 360T-101A | 1 | | |
| R20 | RES, MTL. FILM, 3.92K +/-1%, 1/8W | 294801 | 91637 | CMF553921F | REF | | |
| R21 | RES, MTL. FILM, 10K +/-1%, 1/8W | 168360 | 91637 | CMF551002F | 3 | | |
| R22 | RES, MTL. FILM, 10K +/-1%, 1/8W | 168360 | 91637 | CMF551002F | REF | | |
| R23 | RES, DEP. CAR, 100 +/-5%, 1/4W | 348771 | 80031 | CR251-4-5P100E | 2 | | |
| R24 | RES, MTL. FILM, 750K +/-1%, 1/8W | 271361 | 91637 | CMF55751F | REF | | |
| R25 | RES, MTL. FILM, 1K +/-1%, 1/8W | 168229 | 91637 | CMF551001F | 1 | | |
| R26 | RES, VAR, 100K +/-20%, 1/2W | 268581 | 75378 | 190PC104B | REF | | |
| R27 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R28 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R29 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R30 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R31 | RES, DEP. CAR, 2.2K +/-5%, 1/4W | 343400 | 80031 | CR251-4-5P2K2 | REF | | |
| R32 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R33 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R34 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R35 | RES, DEP. CAR, 5.1K +/-5%, 1/4W | 368712 | 80031 | CR251-4-5P5K1 | 1 | | |
| R36 | RES, DEP. CAR, 47K +/-5%, 1/4W | 348896 | 80031 | CR251-4-5P47K | 1 | | |
| R37 | RES, DEP. CAR, 240 +/-5%, 1/4W | 376624 | 80031 | CR251-4-5P240E | 1 | | |
| R38 | RES, DEP. CAR, 3.9K +/-5%, 1/4W | 342600 | 80031 | CR251-4-5P3K9 | 1 | | |
| R39 | RES, DEP. CAR, 6.8K +/-5%, 1/4W | 368761 | 80031 | CR251-4-5P6K8 | 2 | | |
| R40 | RES, DEP. CAR, 4.3K +/-5%, 1/4W | 441576 | 80031 | CR251-4-5P4K3 | 1 | | |
| R41 | RES, DEP. CAR, 6.8K +/-5%, 1/4W | 368761 | 80031 | CR251-4-5P6K8 | REF | | |
| R42 | RES, DEP. CAR, 3.3K +/-5%, 1/4W | 348813 | 80031 | CR251-4-5P3K3 | 1 | | |
| R43 | RES, DEP. CAR, 330 +/-5%, 1/4W | 368720 | 80031 | CR251-4-5P330E | 1 | | |

Table 602-5. A4 Output Option PCB Assembly (cont)

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|---|-----------------------|---------------------|-------------------------|------------|------------|------------|
| R44 | RES, MTL. FILM, 1.02K +/-1%, 1/8W | 223545 | 91637 | CMF551021F | 1 | | |
| R45 | RES, MTL. FILM, 10K +/-1%, 1/8W | 168360 | 91637 | CMF551002F | REF | | |
| R46 | RES, MTL. FILM, 9.09K +/-1%, 1/8W | 221663 | 91637 | CMF559091F | 1 | | |
| R47 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R48 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R49 | RES, MTL. FILM, 4.32K +/-1%, 1/8W | 294819 | 91637 | CMF554321F | 1 | | |
| R50 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R51 | RES, DEP. CAR, 39K +/-5%, 1/4W | 442400 | 80031 | CR251-4-5P39K | 1 | | |
| R52 | RES, MTL. FILM, 100K +/-1%, 1/8W | 248807 | 91637 | CMF551003F | 1 | | |
| R53 | RES, MTL. FILM, 64.9K +/-1%, 1/8W | 288530 | 91637 | CMF556492F | 1 | | |
| R54 | RES, MTL. FILM, 226K +/-1%, 1/8W | 320879 | 91637 | CMF552263F | 1 | | |
| R55 | RES, MTL. FILM, 309K +/-1%, 1/8W | 235283 | 91637 | CMF553093F | 1 | | |
| S1 | SWITCH MODULE, SPST | 408559 | 00779 | 435166-2 | 3 | | |
| S2 | SWITCH MODULE, SPST | 408559 | 00779 | 435166-2 | REF | | |
| S3 | SWITCH MODULE, SPST | 408559 | 00779 | 435166-2 | REF | | |
| T1 | TRANSFORMER, DC-DC CONV | 461954 | 89536 | 461954 | 1 | | |
| U1 | ⊗ IC, C-MOS, HEX BUFFER/INVERTER | 381830 | 04713 | MC14050CP | 1 | 1 | |
| U2 | OPTO-ISOLATOR | 380014 | 01295 | T1L116 | 3 | 1 | |
| U3 | OPTO-ISOLATOR | 380014 | 01295 | T1L116 | REF | | |
| U4 | OPTO-ISOLATOR | 380014 | 01295 | T1L116 | REF | | |
| U5 | RES, NETWORK | 413286 | 89536 | 413286 | 1 | 1 | |
| U6 | ⊗ IC, C-MOS, HEX, OPEN ORAIN BUFFERS | 473389 | 12040 | MM74C906N | 1 | 1 | |
| U7 | ⊗ IC, MICROPROCESSOR, MOS | 495309 | 04713 | MC3870/14 | 1 | 1 | |
| U8 | ⊗ IC, C-MOS, TRI-STATE, HEX, NON-INV BUFF | 407759 | 04713 | MC14503CP | 2 | 1 | |
| U9 | ⊗ IC, C-MOS, TRI-STATE, HEX, NON-INV BUFF | 407759 | 04713 | MC14503CP | REF | | |
| U10 | ⊗ IC, C-MOS, HEX INVERTERS | 404681 | 04713 | MC1406BCP | 1 | 1 | |
| U11 | ⊗ IC, C-MOS, QUAO, BI-LATERAL SW | 363838 | 02735 | C04016AE | 2 | 1 | |
| U12 | ⊗ IC, C-MOS, QUAD, BI-LATERAL SW | 363838 | 02735 | CD4016AE | REF | | |
| U13 | IC, LINEAR, OP-AMP, J-FET INPUT | 483438 | 89536 | 483438 | 1 | 1 | |
| U14 | TRANSISTOR, J-FET, N-CHANNEL | 460014 | 89536 | 460014 | 1 | 1 | |
| U15 | RES, NETWORK | 412726 | 89536 | 412726 | 2 | 1 | |
| U16 | ⊗ IC, C-MOS, QUAO, EXCLUSIVE OR | 355222 | 02735 | C04030AE | 1 | 1 | |
| U17 | ⊗ IC, C-MOS, DUAL 4-INPUT, NOR GATE | 363820 | 04713 | MC14025CP | 1 | 1 | |
| U18 | IC, LINEAR, OP-AMP, J-FET INPUT | 454454 | 89536 | 454454 | 1 | 1 | |
| U19 | IC, LINEAR, VOL REG, FXD | 413187 | 04713 | MC7815CP | 1 | 1 | |
| U20 | IC, LINEAR, NEG, VOL REG | 413179 | 04713 | MC7915CT | 1 | 1 | |
| U21 | RES, NETWORK | 412726 | 89536 | 412726 | REF | | |
| U22 | IC, LINEAR, LO-PWR DUAL VOL COMP | 478354 | 12040 | LM393N | 1 | 1 | |
| XU7 | SOCKET, IC, 40-PIN | 418988 | 91506 | 340-AG39D | 1 | | |
| XU14 | SOCKER, IC, 8-PIN | 478016 | 91506 | 308-AG39D | 1 | | |
| Y1 | CRYSTAL | 474072 | 89536 | 474072 | 1 | | |




Figure 602-2. A4 Output Option PCB Assembly

Option -006 Limits

606-1. INTRODUCTION

606-2. The 21X0-006 Limits Option gives the 2180A and 2190A Digital Thermometers the capability of providing both visual and electrical indications (alarms) when the temperature measurement exceeds either of a pair of selectable maximum/minimum limit values. Also selectable are, all for a single point, the delta function (displays the difference between the preset value and the temperature read), and the maximum/minimum display function (the highest or lowest temperature read since the last reset by the INITIALIZE MAX/MIN switch).

606-3. The Limits Option is available as factory installed with initial order or may be ordered as a field installable kit for addition to the instrument.

606-4. SPECIFICATIONS

606-5. Specifications for the Limits Option, 21X0-006, are as listed in Table 606-1.

Table 606-1. Specifications

Limits Function: lights LED and activates Form A (SPST) relay when a preset limit is exceeded. Contacts rated at 10 VA, 184V dc or 130V ac rms max, 0.5A max, resistive.
Min/Max Function: Store min or max readings, resettable from front panel.

△ Temperature Function: Reads ± temperature deviations from preset nominal temperature.

Installable: Factory or field, through pre-punched front panel.

| Function: | Limit: |
|--------------------|----------|
| ≤ Low Limit | -9999° |
| > High Limit | +9999° |
| Store min reading | Not used |
| Store max reading | Not used |
| △ ± Deviation from | Nominal |

606-6. INSTALLATION

606-7. Options for field installation can be installed using the following procedure:

WARNING

HAZARDOUS VOLTAGES MAY BE PRESENT WITHIN THE INSTRUMENT. ONLY QUALIFIED PERSONNEL SHOULD PERFORM THIS INSTALLATION PROCEDURE.

1. Disconnect the thermometer from all power sources.
2. Remove the screws on the bottom of the case that fasten the top and bottom of the PTI case together and remove the top half of the case.
3. Remove the hole plugs from the Limits section of the front panel and attach the standoffs supplied with the option to the front panel.
4. Position the Limits PCB so that the thumbwheel LED and pushbutton switch line up with the applicable front panel ports.
5. Attach the Limits PCB to the Main PCB using the screws supplied with the option.
6. Connect the cable on the Limits PCB to J4 on the Main PCB.
7. Replace the PTI cover on the instrument and reconnect to input power sources, if required, at this time.

606-8. OPERATING NOTES

606-9. Installation of the Limits Option enables the low current single contact relay (K1) on the thermometer Main PCB. The contact points are available on a rear panel connector block.

NOTE

Once installed, there are no provisions for disabling the Limits Option. If a temperature display is desired without the relay or LED indications, select one of the Limits functions ($>$ or \leq) and the maximum setting on the numeric thumbwheel switches.

606-10. OPERATION

606-11. The position and general description of the Limits Option front panel controls is given in Section 2. A more detailed description of the three functions is given in the following paragraphs. The term "thermocouple" = "RTD" for the 2180A.

606-12. Limits Function

606-13. The Limits function is enabled when the function portion of the thumbwheel is set in either the \leq or $>$ position. The front panel LED illuminates and the rear panel relay contacts close when either of the preset conditions are met. In the greater than ($>$) function the indications (LED and relay contacts) result from any temperature reading that exceeds the value set on the limits thumbwheels. The less than (\leq) function gives its indication when the temperature read by the thermometer is equal to, or less than, the value set on the limits thumbwheels. The thumbwheel LSD is a whole number, fractional entries cannot be made.

606-14. Delta Function

606-15. When the Delta (Δ) function is selected on the thumbwheel the thermometer display reads the difference between the temperature at the thermocouple and the whole number setting of the thumbwheels. The formula used for the computation is:

$T_{\text{displayed}} = T_{\text{at thermocouple}} - T_{\text{thumbwheel setting}}$
(in degrees)

606-16. MINIMUM/MAXIMUM Display Function

606-17. The microcomputer accumulates and stores the highest and lowest temperatures recorded since the last reset. When the Maximum (∇) function is selected the highest temperature recorded and stored in the microcomputer is displayed. Selection of the Minimum function (∇) displays the lowest recorded temperature since the last reset. To record the current temperature for either function, select the applicable function and depress the front panel reset switch.

606-18. THEORY OF OPERATION

606-19. The -006 Option supplies the thermometer with the function and numeric data selected on the front panel mechanical thumbwheel switches. When a Limits function is selected, the data is stored for comparison on the option pcb. All communication between the option and the thermometer is done on the clocked serial accessory bus. This bus transmits and receives addresses, thumbwheel data, reset data, and limit status. Refer to the schematic in Section 8 during the Theory of Operation discussion.

606-20. Addressing

606-21. Each of the options on the bus is addressed with a different code. The thermometer uses the address "6" to talk to the Limits Option. To talk to any option the WRTADR (P4-3) line must be brought low, with WRT (P4-4) high, followed by the applicable four address bits applied to the DATA (P4-5) line in succession, toggling DCLK (P4-6) for each bit. This clocks the address into the shift register (U2-15) where it is compared to the Limits Option address and, if valid, (U1-1 low) enables the gates required to shift data to the thermometer (U5-11) and into the Limits Option (U5-2). Details of the data transfer are in subsequent paragraphs.

606-22. Limits Option Outputs

606-23. Before the thermometer can input data from the Limits Option, the Limits circuitry must be addressed as described previously (U1-1 low). Once addressed the WRTADR and WRT lines go high. The low to high transition of WRTADR (U3-6) loads the shift registers from the thumbwheels and RESET switches. The two lines enable the output data line (U1-13) and as the thermometer accepts the data it clocks the serial output shift registers with DCLK, transferring the data from the shift register to the thermometer.

606-24. In the thermometer the data is processed by the microcomputer to perform the proper action. For the Limits function the output is compared to the state of the limits and, if exceeded, the indicator illuminated and the relay energized. For the Delta function the temperature is compared against the transmitted value and the difference displayed. If either the Maximum or Minimum function is selected the stored value is displayed, but, in addition, the status of the RESET switch is checked.

606-25. Limits Option Inputs

606-26. The thermometer transmits to the Limits Option only the Limits Exceeded status. After the option has been addressed (U1-1) WRTADR goes high to

disable the addressing circuit (U4-13) while \overline{WRT} stays low to enable the Limits Exceeded input (U5-8) so that \overline{DCLK} can clock the data into the latch (U5-1). A Limits Exceeded indication clocks a high into the latch resulting in a low at the output (U6-12) to turn on CR1. The limit not exceeded or another function selected, loads a low into the latch to turn off the indicator.

606-27. CALIBRATION

606-28. The Limits Option has no variable components and does not require calibration.

606-29. TROUBLESHOOTING

606-30. Troubleshooting for the 2180A Option -006, Limits, consists of the tabular flow chart in Table 606-1. When a step on the flow chart is completed, check for a decision transfer. If no decision is required, perform the next step of the table in sequence.

606-31. LIST OF REPLACEABLE PARTS

606-32. Table 606-2 is a list of replaceable parts for the Limits Option. Refer to Section 5 for an explanation of the columnar entries.

Table 606-2. Limits Option Troubleshooting

| STEP NO. | ACTION | Go to the step number given for correct response | |
|--|--|--|----|
| | | YES | NO |
| <p style="text-align: center;"><i>NOTE</i></p> <p style="text-align: center;"><i>These tests are based on the assumption that the 2180A/2190A has been thoroughly checked out and is free of troubles prior to beginning the test of the Limits Option -006.</i></p> | | | |
| 1 | Select the less than or equal function (\leq) and set the thumbwheels for a numeric such that the thermocouple input exceeds the preset numeric (e.g., thumbwheels set at +1111 and the ambient temperature used as the thermocouple input). | | |
| 2 | Does the LIMIT indicator illuminate and the rear panel relay contacts close? | 26 | 3 |
| 3 | Is the +4 Vdc input from the Main PCB present? | 5 | 4 |
| 4 | Check the +5 Vdc input, repair as required then resume at Step 1. | | |
| 5 | Does the signal at U1-1 toggle (vary between logic high and logic low) when viewed with a scope? | 13 | 6 |
| 6 | Do the \overline{WRT} , \overline{WRTADR} and \overline{DCLK} lines toggle? | 8 | 7 |
| 7 | Check the inputs on the cable from the microprocessor on the Main PCB. Repair as required then resume at Step 1. | | |
| 8 | Does the \overline{DATA} line toggle? | 10 | 9 |
| 9 | Check the cabling and Q1, Q2, U3-8 and their associated components. Repair as required then resume at Step 1. | | |
| 10 | Are the clock and data signals present at pins 1 and 15 of U2, respectively? | 12 | 11 |
| 11 | Check U1, U2-2, 11, 12, 13 and U3. Repair as required then resume at Step 1. | | |
| 12 | Check U4 for the clock and U6 for loading of the data line. Repair as required then resume at Step 1. | | |
| 13 | Is the function code (\leq) a BCD 0 with pins 4, 5, and 6 of U7 low, the sign (+) at U7-7 high, the numeric MSD BCD code as set at pins 1, 15, 14 and 13 of U9, the second MSD BCD code as set at pins 4, 5, 6, and 7 of U11? | 15 | 14 |
| 14 | Check the switches and their associated components. Repair as required then resume at Step 1. | | |
| 15 | Is the clock present at U7-10, U9-10, and U11-10? | 17 | 16 |
| 16 | Check U4-10, U1-13 and their inputs. Repair as required then resume at Step 1. | | |

Table 606-2. Limits Option Troubleshooting (cont)

| STEP NO. | ACTION | Go to the step number given for correct response | |
|----------|--|--|----|
| | | YES | NO |
| 17 | Does the signal at U11-3, U9-3, and U7-3 toggle? | 19 | 18 |
| 18 | Check U11, U9, and U7. Repair as required then resume at Step 1. | | |
| 19 | Does the <u>DATA</u> line toggle? | 21 | 20 |
| 20 | Check Q1, Q2, U3, U5-10 and their associated components. Repair as required then resume at Step 1. | | |
| 21 | Are the clock and data signals present at pins 11 and 9 of U6, respectively? | 23 | 22 |
| 22 | Check U5 for the clock, repair as required then resume at Step 1. | | |
| 23 | Is the collector of Q9 low? | 25 | 24 |
| 24 | Check Q9, Q3, U6-12 and their associated components. Repair as required then resume at Step 1. | | |
| 25 | Check the indicator CR1 and the relay on the Main PCB. Repair as required then resume at Step 1. | | |
| 26 | Set the FUNCTION switch to greater than (\triangleright) and input a temperature from the thermocouple that exceeds the preset limit. | | |
| 27 | Does the LIMIT indicator illuminate and the relay contacts close? | 29 | 28 |
| 28 | Check for a Function BCD code of 1 (001) at pins 4, 5, and 6 of U7. The sign at U7-7 is high for plus and low for minus. Check that the thumbwheel switches reflect the BCD codes set on them. Repair as required then resume at Step 1. | | |
| 29 | Set the FUNCTION switch to the Delta (Δ) position and set the thumbwheels to the desired base. | | |
| 30 | Is the difference between the thermocouple input and the preset base displayed? | 32 | 31 |
| 31 | Check for a Function of BCD code of 2 (010) at pins 4, 5, and 6 of U7. Check that the thumbwheel switches reflect the BCD codes set on them. Repair as required then resume at Step 29. | | |
| 32 | Set the FUNCTION switch to the minimum (∇) position and depress the INITIALIZE MIN/MAX switch. | in | |
| 33 | Does the thermometer display reflect the lowest temperature input from the thermocouple since the switch was depressed? | 35 | 34 |
| 34 | Check for a Function BCD code of 3 (011) at pins 4, 5, and 6 of U7. Check U2-4 and 5, U4-3 and 4, U6-1, the initialize switch S7 and their associated components. Repair as required then resume at Step 32. | | |
| 35 | Set the FUNCTION switch to the MAXIMUM (\Uparrow) position and depress the INITIALIZE MIN/MAX switch. | | |
| 36 | Does the thermometer display reflect the highest temperature input from the thermocouple since the switch was depressed? | 38 | 37 |
| 37 | Check for a Function BCD code of 4 (100) at pins 4, 5, and 6 of U7. Repair as required then resume at Step 35. | | |
| 38 | Troubleshooting of the 21X0-006 Limits Option is complete. | | |

Table 606-3. A5 Limits Option PCB Assembly

| REF DES | DESCRIPTION | FLUKE STOCK NO. | MFG SPLY CODE | MFG PART NO. OR TYPE | TOT QTY | REC QTY | USE CDE |
|------------|--|-----------------------|---------------------|-------------------------|------------|------------|------------|
| 006 | ② LIMITS OPTION-006 PCB ASSEMBLY FIGURE 606-3 (2180A-4060T) | -006 | 89536 | 2190A-006 | REF | | |
| CR1 | LED, RED | 385914 | 09214 | SSL-22 | 1 | 1 | |
| MP1 | LED, STANDOFF ASSY (NOT SHOWN) | 472548 | 89536 | 472548 | 1 | | |
| P4 | CABLE | 474379 | 00779 | 86946-6 | 1 | | |
| Q1 | TRANSISTOR, SI, PNP | 195974 | 04713 | 2N3906 | 1 | 1 | |
| Q2 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | 3 | 1 | |
| Q3 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| Q9 | TRANSISTOR, SI, NPN | 218396 | 04713 | 2N3904 | REF | | |
| R1 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | 6 | | |
| R2 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R3 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R4 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R5 | RES, DEP. CAR, 100K +/-5%, 1/4W | 348920 | 80031 | CR251-4-5P100K | 1 | | |
| R6 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R7 | RES, DEP. CAR, 240 +/-5%, 1/4W | 376624 | 80031 | CR251-4-5P240E | 1 | | |
| R8 | RES, DEP. CAR, 10K +/-5%, 1/4W | 348839 | 80031 | CR251-4-5P10K | REF | | |
| R9 | RES, DEP. CAR, 20K +/-5%, 1/4W | 441477 | 80031 | CR251-4-5P20K | 1 | | |
| R10 | RES, DEP. CAR, 2.2K +/-5%, 1/4W | 343400 | 80031 | CR251-4-5P2K2 | 1 | | |
| S1-6 | THUMBWHEEL SWITCH ASSEMBLY | 472803 | 89536 | 472803 | 1 | | |
| S7-1 | PUSHBUTTON, BLUE (NOT SHOWN) | 472332 | 89536 | 4723322 | 1 | | |
| S7-2 | SWITCH COVER (NOT SHOWN) | 401299 | 89536 | 401299 | 1 | | |
| S7-3 | SWITCH ACTUATOR (NOT SHOWN) | 412106 | 89536 | 412106 | 1 | | |
| S7-4 | SWITCH SPRING (NOT SHOWN) | 414516 | 00779 | 62312 | 1 | | |
| S7-5 | SWITCH CONTACT (NOT SHOWN) | 416875 | 00779 | 62313 | 1 | | |
| U1 | ② IC, C-MOS, DUAL 4-INPUT, POS NAND GATE | 355206 | 04713 | MC14012CP | 1 | 1 | |
| U2 | ② IC, C-MOS, DUAL 4-BIT STATIC SHIFT RESTR | 340125 | 04713 | MC14015BCP | 1 | 1 | |
| U3 | ② IC, C-MOS, HEX INVERTER | 404681 | 04713 | MC1406BCP | 1 | 1 | |
| U4 | ② IC, C-MOS, 3-INPUT, INV NOR GATE | 355172 | 04713 | MC14001CP | 1 | 1 | |
| U5 | ② IC, C-MOS, 3-INPUT, NOR GATE | 355180 | 04713 | MC14025CP | 1 | 1 | |
| U6 | ② IC, C-MOS, DUAL, D-TYPE F/F | 340117 | 04713 | MC14013CP | 1 | 1 | |
| U7 | ② IC, C-MOS, 8-STAGE, STATIC SHIFT REGSTR | 380766 | 12040 | MM5621AN | 3 | 1 | |
| U8 | RES, NETWORK, 100K | 412908 | 89536 | 412908 | 3 | 1 | |
| U9 | ② IC, C-MOS, 8-STAGE, STATIC SHIFT REGSTR | 380766 | 12040 | MM5621AN | REF | | 1 |
| U10 | RES, NETWORK, 100K | 412908 | 89536 | 412908 | REF | | 1 |
| U11 | ② IC, C-MOS, 8-STAGE, STATIC SHIFT REGSTR | 380766 | 12040 | MM5621AN | REF | | 1 |
| U12 | RES, NETWORK, 100K | 412908 | 89536 | 412908 | REF | | 1 |




Figure 606-1. A5 Limits Option PCB Assembly

Section 7

General Information

7-1. This section of the manual contains generalized user information as well as supplemental information to the List of Replaceable Parts contained in Section 5.

List of Abbreviations and Symbols

| | | | | | |
|-----------------|-----------------------------|-----------------------------|----------------------------|--------------------------------|---|
| A or amp | ampere | hf | high frequency | (+) or pos | positive |
| ac | alternating current | Hz | hertz | pot | potentiometer |
| af | audio frequency | IC | integrated circuit | p-p | peak-to-peak |
| a/d | analog-to-digital | if | intermediate frequency | ppm | parts per million |
| assy | assembly | in | inch(es) | PROM | programmable read-only memory |
| AWG | american wire gauge | Intl | Internal | psi | pound-force per square inch |
| B | bel | I/O | input/output | RAM | random-access memory |
| bcd | binary coded decimal | k | kilo (10^3) | rf | radio frequency |
| °C | Celsius | kHz | kilohertz | rms | root mean square |
| cap | capacitor | kΩ | kiloohm(s) | ROM | read-only memory |
| ccw | counterclockwise | kV | kilovolt(s) | s or sec | second (time) |
| cer | ceramic | lf | low frequency | scope | oscilloscope |
| cermet | ceramic to metal(seal) | LED | light-emitting diode | SH | shield |
| ckt | circuit | LSB | least significant bit | Si | silicon |
| cm | centimeter | LSD | least significant digit | serno | serial number |
| cmrr | common mode rejection ratio | M | mega (10^6) | sr | shift register |
| comp | composition | m | milli (10^{-3}) | Ta | tantalum |
| cont | continue | mA | milliampere(s) | tb | terminal board |
| crt | cathode-ray tube | max | maximum | tc | temperature coefficient or temperature compensating |
| cw | clockwise | mf | metal film | tcxo | temperature compensated crystal oscillator |
| d/a | digital-to-analog | MHz | megahertz | tp | test point |
| dac | digital-to-analog converter | min | minimum | u or μ | micro (10^{-6}) |
| dB | decibel | mm | millimeter | uhf | ultra high frequency |
| dc | direct current | ms | millisecond | us or μs | microsecond(s) (10^{-6}) |
| dmm | digital multimeter | MSB | most significant bit | uut | unit under test |
| dvm | digital voltmeter | MSD | most significant digit | V | volt |
| elect | electrolytic | MTBF | mean time between failures | v | voltage |
| ext | external | MTTR | mean time to repair | var | variable |
| F | farad | mV | millivolt(s) | vco | voltage controlled oscillator |
| °F | Fahrenheit | mv | multivibrator | vhf | very high frequency |
| FET | Field-effect transistor | MΩ | megohm(s) | vlf | very low frequency |
| ff | flip-flop | n | nano (10^{-9}) | W | watt(s) |
| freq | frequency | na | not applicable | ww | wire wound |
| FSN | federal stock number | NC | normally closed | xfmr | transformer |
| g | gram | (-) or neg | negative | xstr | transistor |
| G | giga (10^9) | NO | normally open | xtal | crystal |
| gd | guard | ns | nanosecond | xtio | crystal oscillator |
| Ge | germanium | opnl ampl | operational amplifier | Ω | ohm(s) |
| GHz | gigahertz | p | pico (10^{-12}) | μ | micro (10^{-6}) |
| gmV | guaranteed minimum value | para | paragraph | | |
| gnd | ground | pcb | printed circuit board | | |
| H | henry | pF | picofarad | | |
| hd | heavy duty | pn | part number | | |

Federal Supply Codes for Manufacturers

| | | | |
|---|--|---|---|
| 00213 Nytronics Comp. Group Inc. Subsidiary of Nytronics Inc. Formerly Sage Electronics Rochester, New York | 02660 Bunker Ramo Corp., Conn Div. Formerly Amphenol-Borg Electric Corp. Broadview, Illinois | 04946 Standard Wire & Cable Los Angeles, California | 06751 Components, Inc. Semcor Div. Phoenix, Arizona |
| 00327 Welwyn International, Inc. Westlake, Ohio | 02799 Aero Capacitors, Inc. Chatsworth, California | 05082 Replaced by 94988 | 06860 Gould Automotive Div. City of Industry, California |
| 00656 Aerovox Corp. New Bedford, Massachusetts | 03506 General Electric Co. Semiconductor Products Syracuse, New York | 05236 Jonathan Mfg. Co. Fullerton, California | 06961 Vernitron Corp., Piezo Electric Div. Formerly Clevite Corp., Piezo Electric Div. Bedford, Ohio |
| 00666 Film Capacitors, Inc. Passaic, New Jersey | 03614 Replaced by 71400 | 05245 Components Corp. now Corcom, Inc. Chicago, Illinois | 06960 Elmac Div. Varian Associates San Carlos, California |
| 00779 AMP Inc. Harrisburg, Pennsylvania | 03651 Replaced by 44655 | 05277 Westinghouse Electric Corp. Semiconductor Div. Youngwood, Pennsylvania | 07047 The Ross Milton Co. South Hampton, Pennsylvania |
| 01121 Allen-Bradley Co. Milwaukee, Wisconsin | 03797 Eldema Div. Genisco Technology Corp. Compton, California | 05278 Replaced by 43543 | 07115 Replaced by 14674 |
| 01281 TRW Electronic Comp. Semiconductor Operations Lawndale, California | 03877 Transistron Electronic Corp. Wakefield, Massachusetts | 05279 Southwest Machine & Plastic Co. Glendora, California | 07138 Westinghouse Electric Corp., Electronic Tube Div. Horsehead, New York |
| 01295 Texas Instruments, Inc. Semiconductor Group Dallas, Texas | 03888 KDI Pyrofilm Corp. Whippany, New Jersey | 05397 Union Carbide Corp. Materials Systems Div. New York, New York | 07233 TRW Electronic Components Cinch Graphic City of Industry, California |
| 01537 Motorola Communications & Electronics Inc. Franklin Park, Illinois | 03911 Clairex Electronics Div. Clairex Corp. Mt. Vernon, New York | 05571 Use 56289 Sprague Electric Co. Pacific Div. Los Angeles, California | 07256 Silicon Transistor Corp. Div. of BBF Group Inc. Chelmsford, Massachusetts |
| 01686 RCL Electronics Inc. Manchester, New Hampshire | 03980 Muirhead Inc. Mountainside, New Jersey | 05574 Viking Industries Chatsworth, California | 07261 Aumet Corp. Culver City, California |
| 01730 Replaced by 73586 | 04009 Arrow Hart Inc. Hartford, Connecticut | 05704 Replaced by 16258 | 07263 Fairchild Semiconductor Div. of Fairchild Camera & Instrument Corp. Mountain View, California |
| 01884 Use 56289 Sprague Electric Co. Dearborn Electronic Div. Lockwood, Florida | 04062 Replaced by 72136 | 05820 Wakefield Engineering Inc. Wakefield, Massachusetts | 07344 Bircher Co., Inc. Rochester, New York |
| 02114 Ferroxcube Corp. Saugerties, New York | 04202 Replaced by 81312 | 06001 General Electric Co. Electronic Capacitor & Battery Products Dept. Columbia, South Carolina | 07597 Burndy Corp. Tape/Cable Div. Rochester, New York |
| 02131 General Instrument Corp. Harris ASW Div. Westwood, Maine | 04217 Essex International Inc. Wire & Cable Div. Anaheim, California | 06136 Replaced by 63743 | 07792 Lerma Engineering Corp. Northampton, Massachusetts |
| 02395 Rason Mfg. Co. Brooklyn, New York | 04221 Aemco, Div. of Midtex Inc. Mankato, Minnesota | 06363 Panduit Corp. Tinley Park, Illinois | 07910 Teledyne Semiconductor Formerly Continental Device Hawthorne, California |
| 02533 Snelgrove, C.R. Co., Ltd. Don Mills, Ontario, Canada M3B 1M2 | 04222 AVX Ceramics Div. AVX Corp. Myrtle Beach, Florida | 06473 Bunker Ramo Corp. Amphenol SAMS Div. Chatsworth, California | 07933 Use 49956 Raytheon Co. Semiconductor Div. HQ Mountain View, California |
| 02606 Fenwal Labs Div. of Travenal Labs. Morton Grove, Illinois | 04423 Telonic Industries Laguna Beach, California | 06555 Beede Electrical Instrument Co. Penacook, New Hampshire | 08225 Industro Transistor Corp. Long Island City, New York |
| | 04645 Replaced by 75376 | 06739 Electron Corp. Littleton, Colorado | |
| | 04713 Motorola Inc. Semiconductor Products Phoenix, Arizona | 06743 Clevite Corp. Cleveland, Ohio | |

Federal Supply Codes for Manufacturers (cont)

| | | | |
|---|--|---|--|
| 08261 Spectra Strip Corp. Garden Grove, California | 11726 Qualidyne Corp. Santa Clara, California | 13606 Use 56289 Sprague Electric Co. Transistor Div. Concord, New Hampshire | 16299 Corning Glass Electronic Components Div. Raleigh, North Carolina |
| 08530 Reliance Mica Corp. Brooklyn, New York | 12014 Chicago Rivet & Machine Co. Bellwood, Illinois | 13839 Replaced by 23732 | 16332 Replaced by 28478 |
| 08806 General Electric Co. Miniature Lamp Products Dept Cleveland, Ohio | 12040 National Semiconductor Corp. Danbury, Connecticut | 14099 Semtech Corp. Newbury Park, California | 18473 Cambridge Scientific Ind. Div. of Chemed Corporation Cambridge, Maryland |
| 08883 Nylomatic Corp. Norrisville, Pennsylvania | 12060 Diodes, Inc. Chatsworth, California | 14140 Edison Electronic Div. Mc Gray-Edison Co. Manchester, New Hampshire | 18742 Peremount Plastics Fabricators, Inc. Downey, California |
| 08988 Use 53085 Skottie Electronics Inc. Archbald, Pennsylvania | 12136 Philadelphia Handle Co. Camden, New Jersey | 14193 Cal-R-Inc. formerly California Resistor, Corp. Santa Monica, California | 16758 Delco Electronics Div. of General Motors Corp. Kokomo, Indiana |
| 09214 G.E. Co. Semi-Conductor Products Dept. Power Semi-Conductor Products OPN Sec. Auburn, New York | 12300 Potter-Brumfield Div. AMF Canada LTD. Guelph, Ontario, Canada | 14298 American Components, Inc. an Insilco Co. Conshohocken, Pennsylvania | 17001 Replaced by 71468 |
| 09353 C and K Components Watertown, Massachusetts | 12323 Presin Co., Inc. Shelton, Connecticut | 14655 Cornell-Dublier Electronics Division of Federal Pacific Electric Co. Govt. Control Dept. Newark, New Jersey | 17069 Circuit Structures Lab. Burbank, California |
| 09423 Scientific Components, Inc. Santa Barbara, California | 12327 Freeway Corp. formerly Freeway Washer & Stamping Co. Cleveland, Ohio | 14752 Electro Cube Inc. San Gabriel, California | 17338 High Pressure Eng. Co., Inc. Oklahoma City, Oklahoma |
| 09922 Burndy Corp. Norwalk, Connecticut | 12443 The Budd Co. Polychem Products Plastic Products Div. Bridgeport, Pennsylvania | 14869 Replaced by 96853 | 17545 Atlantic Semiconductors, Inc. Asbury Park, New Jersey |
| 09969 Dale Electronics Inc. Yankton, S. Dakota | 12615 U.S. Terminals Inc. Cincinnati, Ohio | 14936 General Instrument Corp. Semi Conductor Products Group Hicksville, New York | 17856 Siliconix, Inc. Santa Clara, California |
| 10059 Barker Engineering Corp. Formerly Amerace, Amerace ESNA Corp. Kenilworth, New Jersey | 12617 Hamlin Inc. Lake Mills, Wisconsin | 15636 Elec-Trol Inc. Saugus, California | 17870 Replaced by 14140 |
| 11236 CTS of Berne Berne, Indiana | 12697 Clarostat Mfg. Co. Dover, New Hampshire | 15801 Fenwal Electronics Inc. Div. of Kidde Walter and Co., Inc. Framingham, Massachusetts | 18178 Vactec Inc. Maryland Heights, Missouri |
| 11237 CTS Keene Inc. Paso Robles, California | 12749 James Electronics Chicago, Illinois | 15816 Teledyne Semiconductors, formerly Amelco Semiconductor Mountain View, California | 18324 Signetics Corp. Sunnyvale, California |
| 11358 CBS Electronic Div. Columbia Broadcasting System Newburyport, Minnesota | 12856 Micrometals Sierra Madre, California | 15849 Litton Systems Inc. Useco Div. formerly Useco Inc. Ven Nuys, California | 18612 Vishay Resistor Products Div. Vishay Intertechnology Inc. Malvern, Pennsylvania |
| 11403 Best Products Co. Chicago, Illinois | 12954 Dickson Electronics Corp. Scottsdale, Arizona | 15908 International Business Machines Corp. Essex Junction, Vermont | 18736 Voltronics Corp. Hanover, New Jersey |
| 11503 Keystone Columbia Inc. Warren, Michigan | 12969 Unitrode Corp. Watertown, Massachusetts | 15909 Replaced by 14140 | 18927 GTE Sylvania Inc. Precision Meterial Group Perts Division Titusville, Pennsylvania |
| 11532 Teledyne Relays Hawthorne, California | 13103 Thermalloy Co., Inc. Dallas, Texas | 16258 Space-Lok Inc. Burbank, California | 19451 Perine Machinery & Supply Co. Seattle, Washington |
| 11711 General Instrument Corp. Rectifier Division Hicksville, New York | 13327 Solitron Devices Inc. Tappan, New York | 19701 Electro-Midland Corp. Mepco-Electra Inc. Mineral Wells, Texas | 20584 Enochs Mfg. Inc. Indianapolis, Indiana |

Federal Supply Codes for Manufacturers (cont)

| | | | |
|---|--|--|--|
| 20891 Self-Organizing Systems, Inc. Dallas, Texas | 28480 Hewlett Packard Co. Corporate HQ Palo Alto, California | 43543 Nytronics Inc. Transformer Co. Div. Geneva, New York | 70903 Belden Corp. Geneva, Illinois |
| 21604 Bucheys Stamping Co. Columbus, Ohio | 28520 Heyman Mfg. Co. Kenilworth, New Jersey | 44655 Ohmite Mfg. Co. Skokie, Illinois | 71002 Birnback Radio Co., Inc. Freeport, New York |
| 21845 Solitron Devices Inc. Transistor Division Riviera Beach, Florida | 29083 Monsanto, Co., Inc. Santa Clara, California | 48671 RCA Corp. New York, New York | 71400 Bussmann Mfg. Div. of McGraw-Edison Co. Saint Louis, Missouri |
| 22767 ITT Semiconductors Palo Alto, California | 29604 Stackpole Components Co. Raleigh, North Carolina | 49956 Raytheon Company Lexington, Massachusetts | 71450 CTS Corp. Elkhart, Indiana |
| 23050 Product Comp. Corp. Mount Vernon, New York | 30148 AB Enterprise Inc. Ahoskie, North Carolina | 50088 Mostek Corp. Carrollton, Texas | 71468 ITT Cannon Electric Inc. Santa Ana, California |
| 23732 Tracor Inc. Rockville, Maryland | 30323 Illinois Tool Works, Inc. Chicago, Illinois | 50579 Litronix Inc. Cupertino, California | 71482 Clare, C.P. & Co. Chicago, Illinois |
| 23880 Stanford Applied Engrng. Santa Clara, California | 31091 Optimax Inc. Colmar, Pennsylvania | 51605 Scientific Components Inc. Linden, New Jersey | 71590 Centrelab Electronics Div. of Globe Union Inc. Milwaukee, Wisconsin |
| 23936 Pamotor Div., Wm. J. Purdy Co. Burlingame, California | 32539 Mura Corp. Great Neck, New York | 53021 Sangamo Electric Co. Springfield, Illinois | 71707 Coto Coil Co., Inc. Providence, Rhode Island |
| 24248 Replaced by 94222 | 32767 Griffith Plastic Corp. Burlingame, California | 54294 Cutler-Hammer Inc. formerly Shallcross, A Cutter-Hammer Co. Selma, North Carolina | 71744 Chicago Miniature Lamp Works Chicago, Illinois |
| 24355 Analog Devices Inc. Norwood, Massachusetts | 32879 Advanced Mechanical Components Northridge, California | 55026 Simpson Electric Co. Div. of Am. Gage and Mach. Co. Elgin, Illinois | 71785 TRW Electronics Components Cinch Connector Operations Div. Elk Grove Village Chicago, Illinois |
| 24655 General Radio Concord, Massachusetts | 32897 Erie Technological Products, Inc. Frequency Control Div. Carlisle, Pennsylvania | 56289 Sprague Electric Co. North Adams, Massachusetts | 72005 Wibber B. Driver Co. Newark, New Jersey |
| 24759 Lenox-Fugie Electronics Inc. South Plainfield, New Jersey | 32997 Bourns Inc. Trimpot Products Division Riverside, California | 58474 Superior Electric Co. Bristol, Connecticut | 72092 Replaced by 06980 |
| 25088 Siemen Corp. Islip, New Jersey | 33173 General Electric Co. Products Dept. Owensboro, Kentucky | 60399 Torin Corp. formerly Torrington Mfg. Co. Torrington, Connecticut | 72136 Electro Motive Mfg. Co. Williamantic, Connecticut |
| 25403 Amperex Electronic Corp. Semiconductor & Micro-Circuits Div. Slatersville, Rhode Island | 34333 Silicon General Westminster, California | 63743 Ward Leonard Electric Co., Inc. Mount Vernon, New York | 72259 Nytronics Inc. Pelham Manor, New Jersey |
| 27014 National Semiconductor Corp. Santa Clara, California | 34335 Advanced Micro Devices Sunnyvale, California | 84834 West Mfg. Co. San Francisco, California | 72619 Dialight Div. Amperex Electronic Corp. Brooklyn, New York |
| 27264 Molex Products Downers Grove, Illinois | 34802 Electromotive Inc. Kenilworth, New Jersey | 65092 Weston Instruments Inc. Newark, New Jersey | 72653 G.C. Electronics Div. of Hydrometals, Inc. Brooklyn, New York |
| 28213 Minnesota Mining & Mfg. Co. Consumer Products Div. St. Paul, Minnesota | 37942 P.R. Mallory & Co., Inc. Indianapolis, Indiana | 66150 Winslow Tele-Tronics Inc. Eaton Town, New Jersey | 72665 Replaced by 90303 |
| 28425 Serv.-Link formerly Bohannon Industries Fort Worth, Texas | 42498 National Radio Melrose, Massachusetts | 70485 Atlantic India Rubber Works Chicago, Illinois | 72794 Dzus Fastener Co., Inc. West Islip, New York |
| 28478 Deltrol Controls Div. Deltrol Corporation Milwaukee, Wisconsin | | 70563 Amperite Company Union City, New Jersey | 72928 Gulton Ind. Inc. Gudeman Div. Chicago, Illinois |

Federal Supply Codes for Manufacturers (cont)

| | | | |
|--|---|--|--|
| 72982 Erie Tech. Products Inc. Erie, Pennsylvania | 75382 Kulka Electric Corp. Mount Vernon, New York | 80583 Hammarlund Mfg. Co., Inc. Red Bank, New Jersey | 83594 Burroughs Corp. Electronic Components Div. Plainfield, New Jersey |
| 73138 Bechman Instrument Inc. Helipot Division Fullerton, California | 75915 Littlefuse Inc. Des Plaines, Illinois | 80640 Arnold Stevens, Inc. South Boston, Massachusetts | 83740 Union Carbide Corp. Battery Products Div. formerly Consumer Products Div. New York, New York |
| 73293 Hughes Aircraft Co. Electron Dynamics Div. Torrance, California | 78854 Oak Industries Inc. Switch Div. Crystal Lake, Illinois | 81073 Grayhill, Inc. La Grange, Illinois | 84171 Arco Electronics Great Neck, New York |
| 73445 Amperex Electronic Corp. Hicksville, New York | 77342 AMF Inc. Potter & Brumfield Div. Princeton, Indiana | 81312 Winchester Electronics Div. of Litton Industries Inc. Oakville, Connecticut | 84411 TRW Electronic Components TRW Capacitors Ogallala, Nebraska |
| 73559 Carling Electric Inc. West Hartford, Connecticut | 77838 General Instrument Corp. Rectifier Division Brooklyn, New York | 81483 Therm-O-Disc Inc. Mansfield, Ohio | 84613 Fuse Indicator Corp. Rockville, Maryland |
| 73586 Circle F Industries Trenton, New Jersey | 77969 Rubbercraft Corp. of CA. LTD. Torrance, California | 81483 International Rectifier Corp. Los Angeles, California | 84682 Essex International Inc. Industrial Wire Div. Peabody, Massachusetts |
| 73734 Federal Screw Products, Inc. Chicago, Illinois | 78189 Shakeproof Div. of Illinois Tool Works Inc. Elgin, Illinois | 81590 Korby Mfg. Co. Seattle, Washington | 86577 Precision Metal Products of Malden Inc. Stoneham, Massachusetts |
| 73743 Fischer Special Mfg. Co. Cincinnati, Ohio | 78277 Sigma Instruments, Inc. South Braintree, Massachusetts | 81741 Chicago Lock Co. Chicago, Illinois | 86684 Radio Corp. of America Electronic Components Div. Harrison, New Jersey |
| 73899 JFD Electronics Co. Components Corp. Brooklyn, New York | 78488 Stackpole Carbon Co. Saint Marys, Pennsylvania | 82305 Palmer Electronics Corp. South Gate, California | 86928 Seastrom Mfg. Co., Inc. Glendale, California |
| 73949 Guardian Electric Mfg. Co. Chicago, Illinois | 78553 Eaton Corp. Engineered Fastener Div. Tinnerman Plant Cleveland, Ohio | 82389 Switchcraft Inc. Chicago, Illinois | 87034 Illuminated Products Inc. Subsidiary of Oak Industries Inc. Anahiem, California |
| 74199 Quan Nichols Co. Chicago, Illinois | 79136 Waldes Kohinoor Inc. Long Island City, New York | 82415 North American Phillips Controls Corp. Frederick, Maryland | 88219 Gould Inc. Industrial Div. Trenton, New Jersey |
| 74217 Radio Switch Corp. Marlboro, New Jersey | 79497 Western Rubber Company Goshen, Indiana | 82872 Roanwell Corp. New York, New York | 88245 Litton Systems Inc. Usecor Div. Van Nuys, California |
| 74276 Signalite Div. General Instrument Corp. Neptune, New Jersey | 79963 Zierick Mfg. Corp. Mt. Kisko, New York | 82877 Rotron Inc. Woodstock, New York | 88419 Cornell-Dubilier Electronic Div. Federal Pacific Co. Fuquay-Verien, North Carolina |
| 74308 Piezo Crystal Co. Carlisle, Pennsylvania | 80031 Electro-Midland Corp. Mepco Div. A North American Phillips Co. Norristown, New Jersey | 82879 ITT Royal Electric Div. Pawtucket, Rhode Island | 88486 Plastic Wire & Cable Jewitt City, Connecticut |
| 74542 Hoyt Elect. Instr. Works Penacook, New Hampshire | 80145 LFE Corp., Process Control Div. formerly API Instrument Co. Chesterland, Ohio | 83003 Vero Inc. Garland, Texas | 88690 Replaced by 04217 |
| 74970 Johnson E.F., Co. Waseca, Minnesota | 80183 Use 56289 Sprague Products North Adams, Massachusetts | 83058 The Cerr Co., United Can Div. of TRW Cambridge, Massachusetts | 89536 John Fluke Mfg. Co., Inc. Seattle, Washington |
| 75042 TRW Electronics Components IRC Fixed Resistors Philadelphia, Pennsylvania | 80294 Bourns Inc., Instrument Div. Riverside, California | 83298 Bendix Corp. Electric Power Div. Eatontown, New Jersey | 89730 G.E. Co., Newark Lamp Works Newark, New Jersey |
| 75376 Kurz-Kasch Inc. Dayton, Ohio | | 83330 Herman H. Smith, Inc. Brooklyn, New York | |
| 75378 CTS Knights Inc. Sandwich, Illinois | | 83478 Rubbercraft Corp. of America, Inc. West Haven, Connecticut | |

Federal Supply Codes for Manufacturers (cont)

| | | | |
|---|---|---|---|
| 90201 Mallory Capacitor Co. Div. of P.R. Mallory Co., Inc. Indianapolis, Indiana | 91836 King's Electronics Co., Inc. Tuckahoe, New York | 95354 Methode Mfg. Corp. Rolling Meadows, Illinois | 98291 Sealectro Corp. Mamaroneck, New York |
| 90211 Use 56365 Square D Co. Chicago, Illinois | 91929 Honeywell Inc. Micro Switch Div. Freeport, Illinois | 95712 Bendix Corp. Electrical Components Div. Microwave Devices Plant Franklin, Indiana | 98388 Royal Industries Products Div. San Diego, California |
| 90215 Best Stamp & Mfg. Co. Kansas City, Missouri | 91934 Miller Electric Co., Inc. Div. of Aunet Woonsocket, Rhode Island | 95987 Wackesser Co. Inc. Chicago, Illinois | 98743 Replaced by 12749 |
| 90303 Mallory Battery Co. Div. of Mallory Co., Inc. Tarrytown, New York | 92194 Alpha Wire Corp. Elizabeth, New Jersey | 96733 San Fernando Electric Mfg. Co. San Fernando, California | 98925 Replaced by 14433 |
| 91094 Essex International Inc. Suglex/IWP Div. Newmarket, New Hampshire | 93332 Sylvania Electric Products Semiconductor Products Div. Woburn, Massachusetts | 96853 Gulton Industries Inc. Measurement and Controls Div. formerly Rustrak Instruments Co. Manchester, New Hampshire | 99120 Plastic Capacitors, Inc. Chicago, Illinois |
| 91293 Johanson Mfg. Co. Boonton, New Jersey | 94145 Replaced by 49956 | 96881 Thomson Industries, Inc. Manhasset, New York | 99217 Bell Industries Elect. Comp. Div. formerly Southern Elect. Div. Burbank, California |
| 91407 Replaced by 58474 | 94154 Use 94988 Wagner Electric Corp. Tung-Sol Div. Newark, New Jersey | 97540 Master Mobile Mounts, Div. of Whitehall Electronics Corp. Ft. Meyers, Florida | 99392 STM Oakland, California |
| 91502 Associated Machine Santa Clara, California | 94222 Southco Inc. formerly South Chester Corp. Lester, Pennsylvania | 97913 Industrial Electronic Hardware Corp. New York, New York | 99515 ITT Jennings Monrovia Plant Div. of ITT Jennings formerly Marshall Industries Capacitor Div. Monrovia, California |
| 91506 Augat Inc. Attleboro, Massachusetts | 95146 Alco Electronic Products Inc. Lawrence, Massachusetts | 97945 Penwalt Corp. SS White Industrial Products Div. Piscataway, New Jersey | 99779 Use 29587 Bunker-Ramo Corp. Barnes Div. Landsdowne, Pennsylvania |
| 91637 Dale Electronics Inc. Columbus, Nebraska | 95263 Leecraft Mfg. Co. Long Island City, New York | 97966 Replaced by 11358 | 99800 American Precision Industries Inc. Delevan Division East Aurora, New York |
| 91662 Elco Corp. Willow Grove, Pennsylvania | 95264 Replaced by 98278 | 98094 Replaced by 49956 | 99942 Centrelab Semiconductor Centrelab Electronics Div. of Globe-Union Inc. El Monte, California |
| 91737 Use 71468 Gremar Mfg. Co., Inc. ITT Cannon/Gremar Santa Ana, California | 95275 Vitramon Inc. Bridgeport, Connecticut | 98159 Rubber-Teck, Inc. Gardena, California | Toyo Electronics (R-Ohm Corp.) Irvine, California |
| 91802 Industrial Devices, Inc. Edgewater, New Jersey | 95303 RCA Corp. Receiving Tube Div. Cincinnati, Ohio | 98278 Malco A Microdot Co., Inc. Connector & Cable Div. Pasadena, California | National Connector Minneapolis, Minnesota |
| 91833 Keystone Electronics Corp. New York, New York | 95348 Gordo's Corp. Bloomfield, New Jersey | | |

U.S. SALES AREAS for all Fluke products

| | | | |
|---|---|--|---|
| AL, Huntsville John Fluke Mfg. Co., Inc. 3322 S. Memorial Parkway Suite 96 Huntsville, AL 35801 (205) 881-6220 | IA, Iowa City (319) 354-2811 | NJ, Paramus John Fluke Mfg. Co., Inc. P.O. Box 930 West 75 Century Road Paramus, NJ 07652 (201) 262-9550 | TX, Dallas John Fluke Mfg. Co., Inc. 14400 Midway Road Dallas, TX 75234 (214) 233-9990 |
| AZ, Tempe John Fluke Mfg. Co., Inc. 2211 S. 48th Street Suite B Tempe, AZ 85282 (802) 438-8314 | IL, Chicago John Fluke Mfg. Co., Inc. 3740 Industrial Ave. Rolling Meadows, IL 60008 (312) 398-0850 | NM, Albuquerque John Fluke Mfg. Co., Inc. 1108 Alvarado Drive N.E. Albuquerque, NM 87110 (505) 881-3550 | Houston John Fluke Mfg. Co., Inc. 4240 Blue Bonnet Dr. Stafford, TX 77477 (713) 491-5995 |
| Tucson (602) 790-9881 | IN, Indianapolis John Fluke Mfg. Co., Inc. 8777 Purdue Road Suite 101 Indianapolis, IN 46268 (317) 875-7870 | NY, Rochester John Fluke Mfg. Co., Inc. 4515 Culver Road Rochester, NY 14822 (716) 323-1400 | San Antonio John Fluke Mfg. Co., Inc. 10417 Guldale San Antonio, TX 78216 (512) 340-2621 |
| CA, Los Angeles John Fluke Mfg. Co., Inc. 20902 South Bonita St. Carson, CA 90746 (213) 538-3900 | KS, Kansas City (913) 381-9800 | OH, Cleveland John Fluke Mfg. Co., Inc. 7830 Freeway Circle Middleburg Heights, OH 44130 (216) 234-4540 | UT, Salt Lake City (801) 268-9331 |
| San Diego John Fluke Mfg. Co., Inc. 4540 Kearny Villa Rd., Suite 115 San Diego, CA 92123 (619) 292-7656 | LA, New Orleans (504) 455-0814 | Columbus (614) 889-5715 | WA, Seattle John Fluke Mfg. Co., Inc. 5020 148th Ave. N.E. Suite 110 Redmond, WA 98052 (206) 881-6966 |
| Santa Clara John Fluke Mfg. Co., Inc. 2300 Walsh Ave., Bldg. K Santa Clara, CA 95051 (408) 727-0513 | MA, Burlington John Fluke Mfg. Co., Inc. 25 "B" Street Burlington MA 01803 (617) 273-4674 | Dayton John Fluke Mfg. Co., Inc. 4756 Fishburg Rd. Dayton, OH 45424 (513) 233-2238 | Service Center Areas |
| Tustin John Fluke Mfg. Co., Inc. 15445 Red Hill Ave., Suite F Tustin, CA 92680 (714) 838-8863 | MD, Baltimore (301) 792-7060 | OR, Portland John Fluke Mfg. Co., Inc. 2700 NW 185th Suite 2080 Portland, OR 97229 (503) 629-5928 | CA, Burbank (213) 849-4641 CA, Santa Clara (408) 727-8121 CO, Denver (303) 750-1228 FL, Orlando (305) 896-2296 IL, Chicago (312) 398-5880 MA, Burlington (617) 273-4678 MD, Rockville (301) 770-1576 NJ, Paramus (201) 262-9550 TX, Dallas (214) 233-9945 WA, Everett (206) 356-5560 |
| CO, Denver John Fluke Mfg. Co., Inc. 1980 South Quebec St. #4 Denver, CO 80231 (303) 750-1222 | Rockville John Fluke Mfg. Co., Inc. 5640 Fishers Lane Rockville, MD 20852 (301) 770-1570 | PA, Philadelphia John Fluke Mfg. Co., Inc. 1010 West 8th Ave., Suite H King of Prussia, PA 19406 (215) 265-4040 | |
| CT, Hartford John Fluke Mfg. Co., Inc. Glen Lochen East 41-C New London Turnpike Glastonbury, CT 06033 (203) 659-3541 | MI, Detroit John Fluke Mfg. Co., Inc. 33031 Schoolcraft Livonia, MI 48150 (313) 522-9140 | Pittsburgh (412) 261-5171 | |
| FL, Orlando John Fluke Mfg. Co., Inc. 940 N. Fern Creek Ave. Orlando, FL 32803 (305) 896-4881 | MN, Bloomington John Fluke Mfg. Co., Inc. 1801 E. 79th St., Suite 9 Bloomington, MN 55420 (612) 854-5526 | | |
| GA, Atlanta John Fluke Mfg. Co., Inc. 2700 Delk Rd., Suite 250 Marietta, GA 30067 (404) 953-4747 | MO, St. Louis John Fluke Mfg. Co., Inc. 2029 Woodland Parkway Suite 105 St. Louis, MO 63141 (314) 993-3805 | | |
| | NC, Greensboro John Fluke Mfg. Co., Inc. 1310 Beaman Place Greensboro, NC 27408 (919) 273-1918 | | |

For more information on Fluke products or Sales Offices you may dial (800) 426-0361 toll-free in most of the U.S.A. From Alaska, Hawaii, or Washington phone (206) 356-5400. From Canada and other countries phone (206) 356-5500.



John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, WA 98208
Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands. Phone (013) 673973
Litho in U.S.A. 4/84

INTERNATIONAL SALES OFFICES

Argentina *

Coasin S.A.
Virrey del Pino 4071
Buenos Aires, Argentina
Tel: 552-5248, TLX: 22284

Australia *

Elmeasco Instruments Pty Ltd.
P.O. Box 30, Concord, N.S.W.
Australia 2137
Tel: (2) 736-2888, TLX: (790) 25887

Elmeasco Instruments Pty Ltd.
21-23 Anthony Drive
Mt. Waverly, VIC 3149
Australia
Tel: 233-4044, TLX: (790) 36206

Elmeasco Instruments Pty Ltd.
Professional Suites Bldg.
G.P.O. Box 2360
Brisbane, 4001, Australia
Tel: (07) 389-8888

Elmeasco Instruments Pty Ltd.
G.P.O. Box 1240, Adelaide
South Australia 5001
Tel: (08) 271-1839

Elmeasco Instruments Pty Ltd.
P.O. Box 95, Gosnells
West Australia 6110
Tel: (09) 398-3362

Austria *

Walter Rekirsh
Elektronische Geräte GmbH & Co.
Vertrieb KG
Obachgasse 28
1220 Vienna, Austria
Tel: (0222) 235555, TLX: 134759

Bangladesh *

Motherland Corporation
24 Hathkolia Rd., Tikatuli
Dacca 3, Bangladesh
Tel: 257249 or 255776

Belgium *

Fluke (Belgium) S.A./N.V.
6, Rue de Geneve
1140 Brussels, Belgium
Tel: (2) 2164090, TLX: 26312

Bolivia *

Coasin Bolivia S.R.L.
Casilla 7295, La Paz, Bolivia
Tel: 40962, TLX: 3233

Brazil *

Fluke Brasil-Industria E
Comercio LTDA
Al. Amazonas 422,
Alphaville, Barueri,
CEP 06400 Sao Paulo, Brazil
Tel: (011) 421-5477, TLX: 01135589

Fluke Brasil-Industria E
Comercio LTDA
Av. Henrique Valadares, 23/401
Rio de Janeiro, Brazil
Tel: 252-1297

Brunei *

Rank O'Connor's (PTE) Limited
No. 8, B1k, D
Sufri Shop House Complex
Mile 1, Jalong Tutong
Bandar Seri Begawan, Brunei
Tel: 26680

Bulgaria *

Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Steines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Canada *

Allan Crawford Assoc., Ltd.
#14 1935 30th Ave. N.E.
Calgary, Alberta T2E 6Z5
Tel: (403) 230-1341, TLX: 03-821186

Allan Crawford Assoc., Ltd.
P.O. Bag 3967
Postal Station "D"
15043A - 118 Ave.
Edmonton, Alberta T5L 4K1
Tel: (403) 451-4893

Allan Crawford Assoc., Ltd.
3795 William Street
Burnaby, British Columbia V5C 3H3
Tel: (604) 294-1328, TLX: 04-54247

Allan Crawford Assoc., Ltd.
881 Lady Ellen Place
Ottawa, Ontario K1Z 5L3
Tel: (613) 722-7882, TLX: 0533600

Allan Crawford Assoc., Ltd.
6503 Northam Drive
Mississauga, Ontario L4V 1J2
Tel: (416) 678-1500, TLX: 08968769

Allan Crawford Assoc., Ltd.
7918 Cote de Liesse
St. Laurent, Quebec H4T 1E7
Tel: (514) 731-8564, TLX: 05824944

Chad *

Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Chile *

Intronica Chile Ltda.
Manuel Montt 024 - Of. D
Casilla 18228, Santiago 9, Chile
Tel: 44940, TLX: 240301
Attn: Intronica Chile

China, People's Republic of *

Fluke International Corporation
P.O. Box C9090
Everett, WA 98206, U.S.A.
Tel: (206) 356-5511
TLX: 152662 JOHN FLUKE EVT

Colombia *

Sistemas E Instrumentacion, Ltda.
Carrera 13, No. 37-43, Of. 401
Ap. Aereo 29583
Bogota DE, Colombia SA
Tel: 232-45-32, TLX: 45787

Cyprus *

Chris Radiovision Ltd.
P.O. Box 1989, Nicosia, Cyprus
Tel: 66121, TLX: 8262395

Czechoslovakia *

Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Steines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Denmark *

Tage Olsen A/S
Ballerup Byvej 222
OK - 2750 Ballerup, Denmark
Tel: (2) 658111, TLX: (855) 35293

Ecuador *

Proteco Coasin Cla., Ltda.
Edificio "Jarico"
Ave. 12 de Octubre #2285 y
Ave. Orellana (Plante Baja)
Quito, Ecuador
Tel: 529684, TLX: (393) 2865

Proteco Coasin Cla., Ltda.
Calderon 103 y Malecon
Casilla #9733
Guayaquil, Ecuador
Tel: 526083

Egypt and Sudan *

Electronic Engineering Liaison Office
P.O. Box 2891 Horreya
Heliopolis, Cairo, Egypt
Tel: 691588, TLX: (927) 92502

England *

Fluke (G.B.) Ltd.
Colonial Way
Watford, Herts, WD2 4TT
United Kingdom
Tel: (0923) 40511, TLX: (851) 934583
Rapifax: (0923) 25067

Ethiopia *

Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Fiji *

AWA Fiji
47 Forster Road, Walu Bay
Suva, Fiji
Tel: 312079, TLX: FJ2347

Finland *

Findip-Havulinna Instr. Oy
PL 84 - Vitikka 1
02631 Espoo 63
Finland
Tel: 5281, TLX: 124426

France *

M.B. Electronique S.A.
Rue Fourny 606
78530 BUC
B.P. No. 31
78530 BUC, France
Tel: (3) 9568131, TLX: (842) 695414

German Democratic Republic *

Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Steines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

German Federal Republic *

Fluke (Deutschland) GmbH
Oskar-Messter-Strasse 18
8045 Ismaning, West Germany
Tel: (089) 96050, TLX: 522472
Rapifax: (089) 9605166
Fluke (Deutschland) GmbH
Meineckestrasse 53
4000 Dusseldorf 30, West Germany
Tel: (0211) 450831, TLX: (841) 8585576

Greece *

Hellenic Scientific Representations Ltd.
11, Vratside Street
Athens 612, Greece
Tel: (1) 711140, TLX: (863) 219330

Hong Kong *

Schmidt & Co Ltd
18th Fl, Great Eagle Centre
23 Harbour Road
Wanchai, Hong Kong
Tel: 5-833-0222, TLX: 74766

Hungary *

Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Steines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Iceland *

Kristjan O. Skegfiord Ltd.
P.O. Box 906
Reykjavik, Iceland
Tel: 24120, TLX: 2133

India *

Hinditron Services Pvt. Ltd.
69/A.L. Jagmohandas Marg
Bombay 400 006, India
Tel: 812-1316, TLX: 112326

Hinditron Services Pvt. Ltd.
8th Main Road
33/44-A Raj Mahal Vilas Extension
Bangalore 560 080, India
Tel: 33139, TLX: (953) 0845741

Hinditron Services Pvt. Ltd.,
Shantiniketan, Office No. 6
8th Floor, 8 Camac Street
Calcutta 700 017, India
Tel: 434032, 447541

Hinditron Services Pvt. Ltd.
204-206 Hemkunt Tower
98 Nehru Place
New Delhi, 110019, India
Tel: 640380, TLX: (95) 314890

Hinditron Services Pvt. Ltd.
Srinath Complex, 5th Floor
1-1-58/1 to 1-1-58/11
Sarajini Devi Road
Secunderabad 500 003, India
Tel: 821117, TLX: (953) 0155 575

Indonesia *

P.T. Dwi Tunggal Jaya Saktil
Jin Panglima Polim Raya #29
Kebayoran Baru
Jakarta Selatan, Indonesia
Tel: 716374, TLX: 47308

Iraq *

Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Ireland *

Euro Instruments and
Electronics Ltd.
Euro House, Swords Road
Santry, Dublin 9
Tel: (01) 425666, TLX: 31821

Israel *

R.D.T. Electronics Engineering Ltd.
P.O. Box 75
46, Sokolov Street
Ramat Hasharon 47235, Israel
Tel: (3) 483216, TLX: (922) 32143

Italy *

Sistrel S.p.A.
Via Pelizza da Volpedo 59
20092 Cinisello Balsamo
Milan, Italy
Tel: (2) 6181893, TLX: (843) 334643

Sistrel S.p.A.
Via Giuseppe Armellini No. 39
00143 Rome, Italy
Tel: (6) 5915551, TLX: (843) 68356

Sistrel S.p.A.
Via Cintia
Parco S. Paolo 35
80126 Naples, Italy
Tel: (81) 7679700

Japan *

John Fluke Mfg. Co., Inc.
Japan Branch
Sumitomo Higashi
Shinbashi Bldg.
1-1-11 Hamamatsucho
Minato-ku, Tokyo, Japan
Tel: (03) 434-0181, TLX: 2424331



John Fluke Mfg. Co., Inc. / PO Box C9090 / Everett, WA 98206 / (206) 356 5400

Litho in U.S.A. 4/84

Kenya •
ADCOM Ltd.
P.O. Box 30070
Nairobi, Kenya, East Africa
Tel: 331955, TLX: 22639

Korea •
Electro Science
201 Hyunjin Bldg
251-19 Bangbae
Gangnam-Ku
Seoul, Korea
Tel: 683-7703, TLX: K25381

Kuwait •
Al-Bahar Int. Group
P.O. Box 26672 Safat
Kuwait, Arabian Gulf
Tel: 450108, TLX: 44822

Lebanon and Jordan •
Mehek (Electronics Division)
P.O. Box 11-3823
Beirut, Lebanon
Tel: 812523, TLX: (923) 22889

Libya •
Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Malaysia •
Mecomb Malaysia SDN BHD
Lot 20, Jalan 225
Petaling Jaya, Malaysia
Tel: 743422, TLX: MA37764

Mexico •
Electronica y Tecnologia
Avanzada S.A. de C.V.
Pafnucio Padilla 53
Circuito Comercial Satellite
Naucalpan Edo. De Mexico
Tel: 393 0902, TLX: (383) 017 2697

Nepal •
Associated Enterprises
GPO Box 790, Pyaphal Tole
Kathmandu, Nepal
Tel: 13868

Netherlands •
Fluke (Nederland) B.V.
Gasthuisring 14
5041 DS Tilburg
The Netherlands
P.O. Box 115
5000 AC Tilburg
The Netherlands
Tel: (013) 352455, TLX: 52683

New Zealand •
McLean Information Technology, Ltd.
P.O. Box 9464, Newmarket
Auckland 1, New Zealand
Tel: 501-801; TLX: (791) NZ 215 70
McLean Information Technology, Ltd.
P.O. Box 496
Wellington, New Zealand
Tel: 851-450 or 844-424

Nigeria •
Mofat Engineering Co., Ltd.
P.O. Box 6369
Lagos, Nigeria
Tel: 21353,
Cable: MOFATENG LAGOS

Norway •
Morgenstjerne & Co A/S
P.O. Box 8688, Rodelokka
Oslo 5, Norway
Tel: (2) 358110, TLX: (658) 71719

Oman •
OHI Telecommunications
P.O. Box 889
Muscat
Sultanate of Oman
Tel: 702866 or 703862
TLX: 3180

Pakistan •
International Operations (PAK)
505 Muhammadi House
I.I. Chundrigar Road
P.O. Box 5323, Karachi, Pakistan
Tel: 221127, TLX: (952) 24494

PDR Yemen •
Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Peru •
Importaciones Y Representaciones
Electronicas S.A.
Avda. Franklin D. Roosevelt 105
Lima 1, Peru
Tel: 288650, TLX: (394) 25683

Philippines •
Spark Radio & Electronics, Inc.
Greenhills P.O. Box 610
Matro-Manila, Philippines 3113
Tel: 704096, TLX: 27901

Poland •
Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Staines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Portugal •
Decada Espectral
Equipamentos de Electronica e
Cientificos, Sarl
Av. Bombeiros Voluntarios
Lote 102, B
Miraflores/Alges
1495 Lisboa, Portugal
Tel: (01) 2103420, TLX: 15515

Qatar •
Technology Organisation
P.O. Box 5549, Doha, Qatar
Tel: 321431, TLX: (957) 4581

Romania •
Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Staines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Saudi Arabia •
Electronic Equipment Marketing Co.
P.O. Box 3750
Riyadh, Saudi Arabia
Tel: (1) 477-165001
TLX: 201120

Singapore •
Rank O'Connor's (PTE) Ltd.
98 Pasir Panjang Road
Singapore 0511
Republic of Singapore
Tel: 637944
TLX: RS21023

Somalia •
Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

South Africa •
Fluke S.A. (Pty) Ltd.
P.O. Box 39797, Bramley 2018
Republic of South Africa
Tel: (011) 786-3170, TLX: 4-24326SA

Fluke S.A. (Pty) Ltd.
P.O. Box 7135
Roggebaal 8012
Cape Town
Republic of South Africa
Tel: (021) 21-1819, TLX: 57-21898

Spain •
ESSA
(Equipos y Sistemas S.A.)
Apolonio Morales 13-b
Madrid 16 - Spain
Tel: 4580150

Sri Lanka •
Jay-Es Electronics
180 Poorvarama Mawatha
Colombo 5, Sri Lanka
Tel: 073-2393

Sweden •
Teleinstrument AB
P.O. Box 4490
162 04 Vallingby, Sweden
Tel: (8) 380370, TLX: (854) 15770

Switzerland •
Traco Electronic AG
Jenatschstrasse 1
8002 Zurich, Switzerland
Tel: (1) 2010711, TLX: (845) 54318

Syria •
Mabek (Electronics Division)
P.O. Box 4238
Damascus, Syria

Taiwan •
Schmidt Electronics Corp.
6th Fl Cathay Min-Sheng
Commercial Bldg, 344
Min-Sheng East Road
Taipai 104, Taiwan
Tel: 501-3468, TLX: (785) 11111

Thailand •
Measuretronix Ltd.
2102/63 Ramkamhaeng Rd.
Huamark, Bangkok 24, Thailand
Tel: 3782516, TLX: 81143

Tunesia •
Selep S.A.R.L.
6, Rue de Sparte
Tunis - 1000 RP, Tunesia
Tel: (1) 248093, TLX: (934) 13030

Turkey •
Erkman Elektronik Aletler
Ticaret Anonim Sirketi
Necatibey Cad 92/3
Karakoy, Istanbul, Turkey
Tel: 441546, TLX: (821) 23353

United Arab Emirates •
Al Sanani Trad. Est.
P.O. Box 7187
Abu-Dhabi, United Arab Emirates
Tel: 821370 or 821371
TLX: 23966

United Kingdom •
Fluke (Great Britain) Ltd.
Colonial Way
Watford, Herts, WD2 4TT
United Kingdom
Tel: (0923) 40511, TLX: 934583
Rapifax: (0923) 25067

Uruguay •
Coasin Uruguay S.R.L.
Casilla de Correo 1400
Correo Central
Montevideo, Uruguay
Tel: 29-31-95, TLX: UY6571

U.S.S.R. •
Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Staines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

Venezuela •
Coasin C.A.
Calle 9 Con Calle 4, Edif. Ednurbil
Apartado De Correos
NR-70.138 Los Ruices
Caracas 1070A, Venezuela
Tel: 239-0967, TLX: (395) 21027

Yemen •
Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

Yugoslavia •
Amtest Associates Ltd.
Clarence House, 31, Clarence St.
Staines, Middlesex TW18 4SY
United Kingdom
Tel: (784) 63555, TLX: 928855

• Supplied and Supported by —
Fluke (Holland) B.V.
P.O. Box 5053, 5004 EB Tilburg
Zevenheuvelenweg 53, 5048 AN Tilburg
The Netherlands
Tel: (013) 673973, TLX: 52237

• Supplied and Supported by —
Fluke International Corporation
P.O. Box C9090
Everett, WA 98206 U.S.A.
Tel: (206) 356-5500
TLX: 152662 JOHN FLUKE EVT



TECHNICAL SERVICE CENTERS

U.S.A.

CA, Burbank
John Fluke Mfg. Co., Inc.
(213) 849-4641

CA, Santa Clara
John Fluke Mfg. Co., Inc.
(408) 727-8121

CO, Denver
John Fluke Mfg. Co., Inc.
(303) 750-1228

FL, Orlando
John Fluke Mfg. Co., Inc.
(305) 896-2298

IL, Rolling Meadows
John Fluke Mfg. Co., Inc.
(312) 398-5800

MA, Burlington
John Fluke Mfg. Co., Inc.
(617) 273-4676

MD, Rockville
John Fluke Mfg. Co., Inc.
(301) 770-1578

NJ, Paramus
John Fluke Mfg. Co., Inc.
(201) 262-9550

TX, Dallas
John Fluke Mfg. Co., Inc.
(214) 233-9945

WA, Everett
John Fluke Mfg. Co., Inc.
(206) 356-5560

Other Countries

Argentina, Buenos Aires
Coasin S.A.
Tel: 552-5248/3485
TLX: 122284 COASN AR

Australia, Concord
Elmeasco Instruments Pty Ltd.
Tel: (02) 736-2888
TLX: (790) 25887

Australia, Mount Waverley
Elmeasco Instruments Pty Ltd.
Tel: 03-233-4044
TLX: 36206

Australia, Brisbane
Elmeasco Instruments Pty Ltd.
Tel: (07) 229-3161

Austria, Vienna
Walter Rekersch Electronische Gerate
GmbH & Co.
Tel: (0222) 235555
TLX: 134759

Belgium, Brussels
Fluke (Belgium) SA/NA
Tel: (02) 2164090
TLX: 26312

Brazil, Sao Paulo
Fluke Brasil-Industria E Comercio Ltda.
Tel: (011) 421-3603
TLX: 01135569 FLKE BR

Canada, Calgary, AB
Allan Crawford Associates Ltd.
Tel: (403) 230-1341

Canada, Burnaby, BC
Allan Crawford Associates Ltd.
Tel: (604) 294-1326

Canada, Mississauga, ON
Allan Crawford Associates Ltd.
Tel: (416) 678-1500

Canada, St. Laurent, PQ
Allan Crawford Associates Ltd.
Tel: (514) 731-8564

Chile, Santiago
Intronica Chile Ltda.
Tel: 44940
TLX: 240301

China, Beijing
Beijing Radio Research Institute
Tel: 445612

Colombia, Bogota
Sistemas E Instrumentacion, Ltda.
Tel: 232-45-32
TLX: 45787 COASN CO

Denmark, Ballerup
Tage Olsen A/S
Tel: (02) 658111
TLX: 35293 TOAS SK

Ecuador, Quito
Edificio "Jerico"
Tel: 529684, 526759
TLX: 2865 Protec Ed

Egypt, Cairo
Electronic Engineering Liaison Office
Tel: 691588
TLX: (927) 92502

England, Watford, Herts
Fluke (Great Britain) LTD
Tel: 44-923-40511
TLX: 934583

Finland, Kaunialainen
Oy Findip AB
Tel: (0) 5052255
TLX: 123129

France, BUC
M.B. Electronique S.A.
Tel: (01) 9568131
TLX: 695414

Greece, Athens
Hellenic Scientific Representations
Tel: (01) 711140
TLX: 219330

Hong Kong, Hong Kong
Schmidt & Co. (H.K.) Ltd.
Tel: 5-455644
TLX: 74766 SCHMC HX

India, Bombay
Hinditron Services Pvt. Ltd.
Tel: 811316, 815344
TLX: 953-112326 HSPL IN

India, Bangalore
Hinditron Services Pvt. Ltd.
Tel: 33139
TLX: 0845741

India, New Delhi
Hinditron Services Pvt. Ltd.
Tel: 619118
TLX: 031 4890 SRMP IN

Indonesia, Jakarta Selatan
P.T. Dwi Tunggal Jaya Sekti
Tel: 718374
TLX: 47308 DIJS IA

Israel, Ramat Hasharon
R.D.T. Electronica Engineering Ltd.
Tel: (03) 483216
TLX: 32143

Italy, Milan
Sistrel S.p.A.
Tel: (02) 6181393
TLX: 334643

Italy, Rome
Sistrel S.p.A.
Tel: (06) 5915551
TLX: 68356

Japan, Tokyo
John Fluke Mfg. Co., Inc.
Japan Branch
Tel: (03) 434-0181
TLX: (761) 2424331 (FLUKJPJ)

Korea, Seoul
Electro-Science Korea Co.
Tel: 261-7702, 260-1908
TLX: K25381

Malaysia, Petaling Jaya
Mecomb Malaysia SDN BHD
Tel: 573455
TLX: MA37805

Mexico, Mexico D.F.
Electronica y Tecnologia
Avanzada S.A. de C.V. (ETA)
Tel: 393 09 02 or 393 57 62
TLX: 0172697 BLOSME

Netherlands, Maarssen
Fluke (Nederland) B.V.
Tel: (030) 436514
TLX: 47128

Netherlands, Tilburg
Fluke (Holland) B.V.
Tel: (013) 673973
TLX: 52237

New Zealand, Auckland
McLean Information Technology, Ltd.
Tel: 501-801, 501-219, 587-037
TLX: NZ21570 THERMAL

Norway, Oslo
Morgenstjerne & Co A/S
Tel: (02) 356110
TLX: 71719

Pakistan, Karachi
Pak International Operations
Tel: 221127, 239052
TLX: 24494 PIO PK

Peru, Lima
Importaciones Y Representaciones
Electronicas S.A.
Tel: 286650
TLX: 37425663

Philippines, Metro Manila
Spark Radio & Electronics Corp.
Tel: 78-78-16
TLX: 27901 RLA PH

Portugal, Lisboa
Decada-Equipamentos de
Electronica, Lda.
Tel: (19) 574964
TLX: 18469

Republic of Singapore, Singapore
Rank O'Connor's (PTE) Limited
Tel: 637944, 239052
TLX: OCONSIN RS21023

Republic of South Africa, Bramley
Fluke S.A. (Pty) Ltd.
Tel: (011) 786-3170
TLX: 424328

Spain, Alcorcon (Madrid)
Hispano Electronics S.A.
Tel: (01) 6194108
TLX: 22404/42634

Sweden, Vallingby
Teleinstrument AB
Tel: (08) 380370
TLX: 15770

Switzerland, Zurich
Traco Electronic AG
Tel: (01) 2010711
TLX: 54316

Taiwan, Taipei
Schmidt Scientific Far East Ltd.
Tel: 5414600
TLX: 11111 Schmidt

Thailand, Bangkok
Measurtronix Ltd.
Tel: 3143369, 3143430
TLX: 81143 DEJOBKK TH

Turkey, Istanbul
Erkman Elektronik Aletler
Tel: (01) 5461
TLX: 23353

Uruguay, Montevideo
Coasin Uruguay S.R.L.
Tel: 29-31-952
TLX: UY 6571 OROCUER

Venezuela, Caracas
Coasin, C.A.
Tel: 38-78-42, 38-78-66
TLX: 21027 EMVEN VE

West Germany, Ismaning
Fluke (Deutschland) GmbH
Tel: (089) 96050
TLX: 5022472



John Fluke Mfg. Co., Inc., P.O. Box C9090, Everett, WA 98206
Fluke (Holland) B.V., P.O. Box 5053, 5004 EB, Tilburg, The Netherlands. Phone (013) 673973
Litho in U.S.A. 4/84

Appendix 7A Manual Change Information

INTRODUCTION

This appendix contains information necessary to backdate the manual to conform with earlier pcb configurations. To identify the configuration of the pcb's used in your instrument, refer to the revision letter (marked in ink) on the component side of each pcb assembly. Table 7A-1 defines the assembly revision levels documented in this manual.

NEWER INSTRUMENTS

As changes and improvements are made to the instrument, they are identified by incrementing the

revision letter marked on the affected pcb assembly. These changes are documented on a supplemental change/errata sheet which, when applicable, is inserted at the front of the manual.

OLDER INSTRUMENTS

To backdate this manual to conform with earlier assembly revision levels, perform the changes indicated in Table 7A-1.

Table 7A-1. Manual Status and Backdating Information

| Ref Or Option No. | Assembly Name | Fluke Part No. | * To adapt manual to earlier rev configurations perform changes in descending order (by no.), ending with change under desired rev letter | | | | | | | | | | | | | | | | | |
|---|----------------------|----------------------|--|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--|--|--|
| | | | — | A | B | C | D | E | F | G | H | J | K | L | M | N | P | | | |
| A1 | Thermometer Assy | 469312 | • | • | • | X | | | | | | | | | | | | | | |
| A2 | Display Assy | 464297 | • | • | • | • | • | X | | | | | | | | | | | | |
| A3 | RTD Assy | 469304 | • | • | • | X | | | | | | | | | | | | | | |
| A4 | Output Option (-002) | | • | • | 1 | 2 | X | | | | | | | | | | | | | |
| A5 | Limits Option (-006) | | • | • | • | • | • | X | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| * X = The PCB revision levels documented in this manual. • = These revision letters were never used in the instrument. — = No revision letter on the PCB. | | | | | | | | | | | | | | | | | | | | |

CHANGE #1, ECO -12081

On page 602-7, Table 602-5, make the following changes:

FROM: J8/Jack, Input/492314/89536/492314/2

TO: J8/Jack, Input/454058/89536/454058/2

CHANGE #2, ECO -12144

On page 602-8, Table 602-5, make the following changes:

Change TOT QTY of R24, FROM: 1 TO: Ref.

FROM: R14/Res, mf, 750k $\pm 1\%$, 1/8W/271361/91637/CMF557503F/1

TO: R14/Res, mf, 1M $\pm 1\%$, 1/8W/268797/91637/CMF551004F/2

DELETE: XU14/Socket, IC, 8-pin/478016/91506/308-AG39D/1

On page 8-11, Figure 8-4, make the following changes:

FROM: R14, 750k

TO: R14, 1M.

Section 8

Schematic Diagrams

TABLE OF CONTENTS

| FIGURE NO. | TITLE | DRAWING NO. | PAGE |
|------------|---------------------------------|-------------|------|
| 8-1. | A1 Main PCB Assembly | 2180A-1001 | 8-2 |
| 8-2. | A2 Display PCB Assembly | 2180A-1002 | 8-4 |
| 8-3. | A3 RTD Input PCB Assembly | 2180A-1003 | 8-9 |
| 8-4. | A4 Output Option | 21X0A-1020 | 8-10 |
| 8-5. | A5 Limits Option | 21X0A-1060 | 8-14 |
| 8-6. | Mnemonics | | 8-16 |




Figure 8-1. A1 Main PCB Assembly